Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 2753

Ariete 2753 J-Force Bagless Multi-Cyclonic Vacuum Cleaner User Manual

Model: 2753

1. Introduction and Safety Information

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Ariete 2753 J-Force Bagless Multi-Cyclonic Vacuum Cleaner. Please read these instructions carefully before using the appliance and retain them for future reference.

1.1 General Safety Precautions

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not use the vacuum cleaner to pick up water or wet substances, flammable or combustible liquids, hot ashes, or sharp objects.
- Always unplug the appliance from the power outlet before cleaning, performing maintenance, or when not in use.
- Do not operate the vacuum cleaner with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- This appliance is intended for domestic use only.

2. Product Overview

The Ariete 2753 J-Force is a powerful bagless multi-cyclonic vacuum cleaner designed for effective cleaning across various floor types. It features a transparent dustbin, a telescopic tube, and a washable HEPA filter for improved air quality.



This image displays the Ariete 2753 J-Force vacuum cleaner, showcasing its compact design, transparent dustbin, flexible hose, and standard floor brush attachment. The main unit is red and black with silver wheels.

2.1 Main Components

- Main Unit with Motor and Dustbin
- Flexible Hose
- Telescopic Tube
- Floor Brush (Multi-function for hard floors and carpets)
- HEPA Filter (located in a dedicated compartment)
- Power Cord with Automatic Rewind

3. Setup and Assembly

Follow these steps to assemble your vacuum cleaner before first use:

1. **Attach the Flexible Hose:** Insert the end of the flexible hose into the suction inlet on the main unit until it clicks securely into place.
2. **Connect the Telescopic Tube:** Attach the handle end of the flexible hose to the telescopic tube.

3. **Attach the Floor Brush:** Connect the floor brush to the other end of the telescopic tube. Ensure it is firmly attached.



A side perspective of the vacuum cleaner, illustrating how the flexible hose connects to the main unit and the floor brush attaches to the telescopic tube. This view emphasizes the maneuverability of the cleaning head.

4. **Power Cord:** Pull out the power cord to the desired length and plug it into a suitable electrical outlet. Do not pull the cord beyond the yellow mark.



This image shows the back of the vacuum cleaner, highlighting the power cord and plug. The cord can be retracted into the unit for storage.

4. Operating Instructions

4.1 Powering On/Off

- To turn on the vacuum cleaner, press the ON/OFF foot pedal located on the main unit.
- To turn off, press the ON/OFF foot pedal again.

4.2 Adjusting Suction Power

The vacuum cleaner features adjustable suction power. Use the slider on the handle to regulate the suction strength according to the cleaning task and surface type.

4.3 Cleaning Different Surfaces

- **Hard Floors:** For hard floors such as tiles, wood, or laminate, ensure the brush setting on the floor tool is retracted (bristles down) to prevent scratching and optimize suction.
- **Carpets and Rugs:** For carpets and rugs, extend the brush setting (bristles up) on the floor tool to allow for deeper cleaning and easier gliding.
- **Telescopic Tube Adjustment:** Adjust the length of the telescopic tube for comfortable use and to reach different areas.

4.4 Power Cord Rewind

After use, unplug the vacuum cleaner from the power outlet. Press the cord rewind button (usually located near the power pedal) to automatically retract the power cord into the unit.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

5.1 Emptying the Dustbin

The Ariete 2753 J-Force features a 3-liter bagless dustbin. It is recommended to empty the dustbin after each use or when the MAX fill line is reached to maintain strong suction.

1. Ensure the vacuum cleaner is unplugged.
2. Press the dustbin release button (refer to product diagrams for exact location) and carefully lift the dustbin from the main unit.
3. Position the dustbin over a waste bin. Press the bottom release button to open the dustbin flap and empty the contents.
4. Close the dustbin flap securely and reattach the dustbin to the main unit until it clicks into place.

5.2 Cleaning the HEPA Filter

The HEPA filter is washable and crucial for trapping fine dust and allergens. Clean the filter regularly, approximately every 3-6 months, depending on usage.



A detailed view of the vacuum cleaner's side, showing the accessible compartment for the HEPA filter. The filter is visible, indicating ease of removal for cleaning or replacement.

1. Unplug the vacuum cleaner.
2. Locate the filter compartment (typically at the rear or side of the unit) and open it.
3. Remove the HEPA filter.
4. Rinse the filter under cold running water until the water runs clear. Do not use detergents or hot water.
5. Allow the filter to air dry completely for at least 24 hours before reinserting it. Do not use a hairdryer or other heating devices.
6. Once completely dry, reinsert the filter into its compartment and close the cover securely.

5.3 General Cleaning

Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure no water enters the motor housing.

6. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply; power cord not plugged in; power outlet faulty.	Check if the plug is securely in the outlet. Test the outlet with another appliance.
Low suction power.	Dustbin full; filter clogged; hose/tube/brush blocked.	Empty the dustbin. Clean the HEPA filter. Check hose, tube, and brush for obstructions and remove them.

Problem	Possible Cause	Solution
Unusual noise during operation.	Obstruction in the hose/brush; motor issue.	Check for and remove any obstructions. If the noise persists, contact customer support.
Dust escaping from the unit.	Dustbin not properly closed; filter not correctly installed or damaged.	Ensure the dustbin is securely closed. Check the HEPA filter for proper installation and damage. Replace if damaged.

If the problem persists after attempting these solutions, please contact Ariete customer support.

7. Specifications

Brand	Ariete
Model Number	2753
Type	Bagless Multi-Cyclonic Vacuum Cleaner
Power	700 Watts
Voltage	220 Volts
Dustbin Capacity	3 Liters
Filter Type	Washable HEPA Filter
Cable Length	5 meters
Dimensions (L x W x H)	36.5 x 29 x 31.5 cm
Weight	4.85 Kilograms
Material	Plastic
Energy Class	A (Triple A for energy, filtration, hard floor/carpet suction)
Special Features	Bagless, Multi-cyclonic Technology, Telescopic Tube
Included Components	Dustbin, HEPA Filter

8. Warranty and Support

Information regarding the specific warranty period for the Ariete 2753 J-Force vacuum cleaner is not available in this document. Please refer to the warranty card included with your purchase or contact the retailer for details.

8.1 Customer Support

For technical assistance, spare parts, or any other inquiries, please contact Ariete customer support through their official

website or the contact information provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BYW1BD1

More documents and user manuals: **https://manuals.plus/**