Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ourokhome C315-3

Ourokhome Rotary Cheese Grater Instruction Manual

Model: C315-3

Introduction

Thank you for choosing the Ourokhome Rotary Cheese Grater. This manual provides essential information for the safe and efficient use, assembly, and maintenance of your new kitchen appliance. Please read these instructions carefully before first use and retain for future reference.

Product Components

Your Ourokhome Rotary Cheese Grater package includes the following:

- Suction base ×1
- Transparent barrel ×1
- Handle ×1
- Food pusher ×1
- Slicing blade ×1
- Coarse shredding blade ×1
- Fine shredding blade ×1
- Peeler ×1
- Cleaning brush ×1

Setup Instructions

Follow these steps to assemble your rotary grater:

1. **Step 1: Secure the Suction Base.** Place the grater on a clean, smooth, and dry countertop. Turn the rotary knob on the base clockwise to lock the suction base firmly in place. Ensure it is stable before proceeding.



Image: Step 1 of assembly, showing how to lock the suction base.

2. **Step 2: Install the Transparent Barrel and Blade.**Insert the desired blade (slicing, coarse, or fine shredding) into the transparent barrel. Then, align the transparent barrel with the main unit and push it into place.



Image: Step 2 of assembly, showing the transparent barrel and blade being inserted.

3. **Step 3: Attach the Handle.** Align the handle with the blade and push it firmly until it clicks into place.



Image: Step 3 of assembly, showing the handle being fixed.

4. **Step 4: Ready for Use.** Your Ourokhome Rotary Cheese Grater is now assembled and ready for use.



Image: Step 4 of assembly, showing the grater in action.

Operating Instructions

The Ourokhome Rotary Cheese Grater comes with three interchangeable blades for various food preparation tasks:

- **Slicing Blade:** Ideal for thin slices of vegetables like cucumbers, carrots, or potatoes, and for slicing cheese.
- **Coarse Shredding Blade:** Best for grating hard cheeses, carrots, potatoes, and other firm vegetables for salads or cooking.
- **Fine Shredding Blade:** Perfect for finely grating nuts, chocolate, or softer cheeses.

General Operation:

1. Ensure the grater is securely attached to a clean, smooth surface using the suction base.
2. Select the appropriate blade for your task and install it as per the setup instructions.
3. Place a bowl or plate beneath the grater's output chute.
4. Insert the food item into the transparent barrel. For safety, always use the food pusher to guide the food towards the blade. **Never use your fingers.**
5. Turn the handle clockwise to grate or slice the food. Apply gentle, consistent pressure with the food pusher.



Image: Demonstrating the slicing blade with cucumbers.



Image: Demonstrating the coarse shredding blade with carrots.



Image: Demonstrating the fine shredding blade with peanuts.

Helpful Tips:

- For soft cheeses, refrigerate them for at least 30 minutes before grating to achieve better results.
- Cut larger food items into smaller pieces that fit comfortably into the transparent barrel.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your Ourokhome Rotary Cheese Grater.

1. **Disassembly:**
    - To remove the handle, push down the red knob on the handle and pull it off.
    - To remove the transparent barrel, push down the white release button on the side of the base and pull the barrel upwards.
    - Remove the blade from the transparent barrel.



Image: Steps for detaching the handle and transparent barrel for cleaning.

2. **Cleaning:**
    - Wash all disassembled parts (blades, transparent barrel, handle, food pusher) with warm, soapy water immediately after use.
    - Use the provided cleaning brush to remove any food residue from the blades. Exercise caution as blades are sharp.
    - The suction base can be wiped clean with a damp cloth. Do not immerse the entire base in water.
    - Rinse thoroughly and allow all parts to air dry completely before reassembling or storing.



Image: Cleaning the grater blades and barrel with the provided brush.

3. **Storage:** Store the grater and its components in a dry place.

Troubleshooting

Problem	Possible Cause	Solution
Grater slides on countertop.	Suction base not properly engaged or surface is not clean/smooth.	Ensure the countertop is clean and dry. Turn the rotary knob clockwise until the suction base is firmly locked.
Food is not grating/slicing effectively.	Incorrect blade selected, food item too large, or insufficient pressure.	Verify the correct blade is installed. Cut food into smaller, manageable pieces. Apply consistent pressure with the food pusher. For soft cheeses, pre-chill them.
Handle is difficult to turn.	Food jammed in the barrel or blade.	Disassemble the unit and clear any obstructions. Ensure food pieces are not too large.

Specifications

- **Model Number:** C315-3
- **UPC:** 651721213387
- **Material:** Plastic, Stainless Steel
- **Product Dimensions:** 10.24"L x 9.45"W x 4.53"H
- **Item Weight:** 0.93 kg
- **Included Components:** Suction base, Transparent barrel, Handle, Food pusher, Slicing blade, Coarse shredding blade, Fine shredding blade, Peeler, Cleaning brush



Image: Product dimensions diagram.

Warranty and Support

Ourokhome is committed to providing high-quality products. For any questions, concerns, or warranty claims regarding

your Rotary Cheese Grater, please contact Ourokhome customer support through the retailer where you purchased the product or visit the official Ourokhome store online.
For more information and other products, visit theOurokhome Store.

Product Videos

Every Kitchen Needs This!

Your browser does not support the video tag.

Video: A demonstration of the Ourokhome Rotary Cheese Grater in action, highlighting its ease of use for various kitchen tasks. Creator: Chaotic Charm with Mama Kate.

Everything You Need To Know | Demo

Your browser does not support the video tag.

Video: A detailed demonstration and overview of the Ourokhome Rotary Cheese Grater, covering its features and how to use it. Creator: LeAnn Aguilera.

Fast and Easy Rotary Grater for Everyday Cooking

Your browser does not support the video tag.

Video: Showcasing the speed and ease of using the rotary grater for daily cooking tasks. Creator: Lucas and Lina V.

Great grater and slicer for your kitchen ad

Your browser does not support the video tag.

Video: A promotional video demonstrating the grater and slicer's capabilities in the kitchen. Creator: The Urban Brie.

Why I Use THIS Vegetable Slicer!

Your browser does not support the video tag.

Video: A user review and demonstration explaining the benefits of this vegetable slicer. Creator: My Top Picks.

Watch this before buying!

Your browser does not support the video tag.

Video: A detailed overview and user experience video for potential buyers. Creator: Alexis Sullivan.

Rotary Cheese Grater

Your browser does not support the video tag.

Video: A demonstration focusing on the cheese grating capabilities of the product. Creator: Rebecca Stevens.

Perfect for Quick Snack Prep, No Electric Needed

Your browser does not support the video tag.

Video: Highlighting the manual grater's efficiency for quick snack preparation without electricity. Creator: Chire Reviews.

MUST HAVE! Honest Review and DEMO of Rotary Grater

Your browser does not support the video tag.

Video: An honest review and demonstration of the rotary grater's performance. Creator: Reviews with Michelle.

Watch this! Rotary grater for slicing vegetables

Your browser does not support the video tag.

Video: A demonstration focused on using the rotary grater for slicing various vegetables. Creator: Val's Picks.

© 2026 Ourokhome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07C15HMD3

More documents and user manuals: **https://manuals.plus/**