Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fisher RDAC-2403 DAC-2403

Fisher RDAC-2403 CD Remote Control User Manual

Model: RDAC-2403 / DAC-2403
Part Number: 6142534977

Introduction

This manual provides comprehensive instructions for the proper use and maintenance of your Fisher RDAC-2403 CD Remote Control. This remote is an original equipment manufacturer (OEM) replacement designed specifically for the Fisher DAC-2403 CD player model. Please read this manual thoroughly before operating the remote control to ensure optimal performance and longevity.

Product Overview



Figure 1: Front view of the Fisher RDAC-2403 CD Remote Control. This image displays the full layout of the remote, including the numeric keypad, function buttons for disc selection, playback controls, and other operational keys.

The Fisher RDAC-2403 remote control is designed to provide full functionality for your Fisher DAC-2403 CD player. It features a compact, ergonomic design for comfortable handling and intuitive button placement for ease of use.

Key Features:

- Direct disc selection (1-3)

- Numeric keypad for track selection
- Playback controls (Play, Pause, Stop, Skip, Fast Forward, Rewind)
- Program and Repeat functions
- Category and Main menu access
- Random play function
- Infrared (IR) connectivity

Setup

Battery Installation:

The remote control requires two (2) AA batteries for operation. Ensure correct polarity when inserting batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AA batteries, matching the positive (+) and negative (-) terminals with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: *Always use fresh batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.*

Operating Instructions

The Fisher RDAC-2403 remote control operates via infrared (IR) signals. Ensure there is a clear line of sight between the remote's IR emitter and the IR receiver on your Fisher DAC-2403 CD player.

Basic Playback Controls:

- **PLAY (►):** Press to start disc playback.
- **PAUSE ( ):** Press to temporarily stop playback. Press again to resume.
- **STOP (■):** Press to stop disc playback.
- **SKIP FORWARD (►►):** Press to skip to the next track.
- **SKIP BACKWARD (◄◄):** Press to skip to the beginning of the current track or the previous track.
- **FAST FORWARD (►►►):** Press and hold to fast forward through the track.
- **REWIND (◄◄◄):** Press and hold to rewind through the track.

Disc Selection:

Use the numeric buttons (1, 2, 3) under "DISC SELECT" to directly select a specific disc if your CD player supports multiple discs.

Advanced Functions:

- **PROGRAM:** Use to program a custom playback order for tracks. Refer to your CD player's manual for detailed programming instructions.
- **REPEAT:** Press to repeat the current track, disc, or programmed sequence. Press multiple times to cycle through repeat modes.
- **RANDOM:** Press to enable random or shuffle playback of tracks on the disc.
- **CATEGORY / MAIN:** These buttons may provide access to different menu options or categories on your CD player, depending on its features.

Maintenance

Cleaning:

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the remote's finish or internal components.

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops functioning. Refer to the "Battery Installation" section under Setup for instructions.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not responding.	Dead or weak batteries. Incorrect battery polarity. Obstruction between remote and CD player. Remote out of range.	Replace batteries with new ones. Check battery orientation (+/-). Remove any objects blocking the signal path. Move closer to the CD player (within 20 feet/6 meters).
Remote works intermittently.	Low battery power. Interference from other electronic devices.	Replace batteries. Move the CD player or remote away from potential sources of interference.

Specifications

- **Model:** RDAC-2403
- **Compatible CD Player:** Fisher DAC-2403
- **Part Number:** 6142534977
- **Connectivity:** Infrared (IR)
- **Power Source:** 2 x AA Batteries (not included)
- **Button Types:** Numeric Keypad, Disc Select, Playback Controls (Play, Pause, Stop, Skip, Fast Forward, Rewind), Function Buttons (Program, Repeat, Random, Intro, Shuffle, Category, Main)
- **Dimensions:** (Approximate) 7.5 x 2 x 1 inches (19 x 5 x 2.5 cm)
- **Weight:** (Approximate, without batteries) 3 oz (85 g)

Specifications are subject to change without notice.

Warranty and Support

Warranty Information:

This product is an OEM replacement part. Warranty coverage, if any, is typically provided by the seller or the original equipment manufacturer (Fisher). Please refer to your purchase documentation or contact the seller for specific warranty terms and conditions. The product was first available on April 12, 2018, and is noted as discontinued by the manufacturer.

Customer Support:

For technical assistance or inquiries regarding the Fisher RDAC-2403 remote control, please contact the seller from whom you purchased the product. For issues related to your Fisher DAC-2403 CD player, please refer to its original user manual or contact Fisher customer support.

Disclaimer: *This remote control is designed for the specified Fisher CD player model. Compatibility with other models is not guaranteed.*

© 2024 Fisher. All rights reserved.
Manual Version: 1.0

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07C5BTYW2

More documents and user manuals: **https://manuals.plus/**