Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 4615GE

Ariete Airy Fryer Mini Instruction Manual

Brand: Ariete | Model: 4615GE

1. Introduction

The Ariete Airy Fryer Mini is a compact air fryer designed to prepare delicious, crispy fried foods with significantly less oil. Utilizing hot air circulation, it allows you to cook a variety of dishes, including meat, fish, and vegetables, with up to 80% less fat compared to traditional deep frying. This appliance is ideal for preparing mini-portions and side dishes, offering a healthy and convenient cooking solution without the lingering smell of fried oil in your home. Its compact design and easy-to-clean, dishwasher-safe parts make it a practical addition to any kitchen.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure adequate ventilation around the appliance during use.

3. Product Overview

The Ariete Airy Fryer Mini features a compact and user-friendly design. Familiarize yourself with its main components:

- **Main Unit:** The primary housing containing the heating element and fan.
- **Removable Basket:** Non-stick basket where food is placed for cooking.
- **Handle:** For safely pulling out and inserting the basket.
- **Temperature Control Knob:** Adjusts the cooking temperature up to 200°C.
- **Timer Knob:** Sets the cooking time.



Figure 3.1: Ariete Airy Fryer Mini showing key features like maximum temperature (200°C), 2-liter capacity, and the benefit of cooking with only one spoon of oil.

4. Setup

1. **Unpacking:** Carefully remove the air fryer and all its components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, clean the removable basket and any other removable parts with warm soapy water. Wipe

the main unit with a damp cloth. Ensure all parts are completely dry before assembly.

3. **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls and other appliances to ensure proper ventilation. Ensure there is at least 10 cm of free space on the back and sides, and 10 cm above the appliance.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

The Ariete Airy Fryer Mini makes cooking simple and efficient. Follow these steps for optimal results:

1. **Prepare Food:** Place your desired food items into the removable basket. For best results with certain foods like fries, a small amount (e.g., one spoon) of oil can be added and mixed with the food.
2. **Insert Basket:** Slide the basket back into the main unit until it clicks securely into place.
3. **Set Temperature:** Turn the temperature control knob to your desired cooking temperature. The fryer can reach up to 200°C.
4. **Set Timer:** Turn the timer knob to the recommended cooking time for your food. The appliance will automatically turn off when the timer reaches zero.
5. **Cooking Process:** The hot air circulation will begin, cooking your food evenly. For some recipes, shaking the basket halfway through the cooking time is recommended to ensure even crisping.
6. **Remove Food:** Once cooking is complete and the timer has sounded, carefully pull out the basket using the handle. Use tongs or a spatula to remove the cooked food.



Figure 5.1: Adding a minimal amount of oil to food for enhanced crispiness.



Figure 5.2: Illustration of the hot air circulation technology within the fryer, ensuring even cooking.



Figure 5.3: Example of various foods prepared using the Ariete Airy Fryer Mini.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your Ariete Airy Fryer Mini.

- **Before Cleaning:** Always unplug the appliance from the power outlet and allow it to cool down completely before cleaning.
- **Removable Parts:** The basket and other removable parts are dishwasher-safe for convenient cleaning. Alternatively, they can be washed by hand with warm water and a non-abrasive sponge.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
- **Interior:** Clean the interior of the appliance with a damp cloth and mild detergent if necessary. Avoid using abrasive cleaning materials.
- **Storage:** Store the appliance in a dry place when not in use.

7. Troubleshooting

If you encounter any issues with your Ariete Airy Fryer Mini, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Timer not set; Power outage.	Ensure the appliance is securely plugged into a working outlet. Set the timer to the desired cooking duration. Check your home's power supply.
Food is not crispy.	Too much food in the basket; Temperature too low; Insufficient cooking time.	Do not overfill the basket; cook in smaller batches if necessary. Increase the temperature. Extend the cooking time. Ensure a small amount of oil is used for foods like fries.
White smoke coming from the appliance.	Greasy residue from previous use; Excess oil on food.	Clean the basket and interior thoroughly after each use. Reduce the amount of oil used on food.
Basket does not slide in properly.	Basket is not aligned correctly.	Ensure the basket is properly aligned with the grooves before pushing it into the main unit. Do not force it.

8. Specifications

Technical details for the Ariete Airy Fryer Mini:

Feature	Detail
Brand	Ariete
Model Number	4615GE
Color	Yellow
Dimensions (L x W x H)	23 x 23 x 30 cm (9.06 x 9.06 x 11.81 inches)
Capacity	2 Liters
Power	1000 Watts
Voltage	220 Volts
Material	Plastic
Noise Level	44 dB
Item Weight	2.6 Kilograms (5.73 lbs)

9. Warranty and Support

The Ariete Airy Fryer Mini comes with a **2-year availability of spare parts**. For warranty claims, technical support, or further assistance, please contact Ariete customer service through their official website or the retailer from whom you purchased the product. Please have your model number (4615GE) and proof of purchase ready when contacting support.

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07C7YZSRR

More documents and user manuals: **https://manuals.plus/**