Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY GA608WJSA

ALLIMITY GA608WJSA Replacement Remote Control User Manual

For Sharp LED LCD TV Models

Setup Operating Instructions Maintenance Troubleshooting Specifications

Introduction

This manual provides instructions for the ALLIMITY GA608WJSA replacement remote control, designed for use with various Sharp LED LCD TV models. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your remote control.

Compatible Sharp TV Models:

- LC-19D1E, LC-19D1E-BK, LC-19D1E-WH
- LC-24LE210E, LC-24LE220E
- LC-32DH500E, LC-32DH500S, LC-32DH510E
- LC-32FH510E, LC-32FS510E
- LC-32LB220E, LC-32LE210E, LC-32LE220E, LC-32LS220E
- RRMC-GA608WJSA, RRMCGA608WJSA

Setup

1. Battery Installation

The ALLIMITY GA608WJSA remote control requires two AA 1.5V batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.



Image: Rear view of the remote control showing the open battery compartment with two AA 1.5V batteries correctly inserted. This illustrates the proper orientation for battery placement.

2. Initial Use

This replacement remote control is pre-programmed and typically requires no setup or pairing. Once batteries are installed, it should function immediately with compatible Sharp LED LCD TV models.
Point the remote control directly at the infrared receiver on your Sharp TV and press any button to test its functionality.

Operating Instructions

The ALLIMITY GA608WJSA remote control features standard buttons for navigating and controlling your Sharp LED LCD TV. Refer to the image below for button layout and functions.



Image: Front view of the ALLIMITY GA608WJSA remote control. Key buttons include Power, DTV Menu, Number Pad (0-9), Volume Up/Down, Channel Up/Down, Mute, Input/Source, Navigation (Up, Down, Left, Right, OK), Menu, Return, and colored function buttons (Red, Green, Yellow, Blue).

Key Button Functions:

Button	Function
Power (Red)	Turns the TV on or off.
DTV MENU	Accesses the digital TV menu.
Number Pad (0-9)	Direct channel selection.
VOL +/-	Adjusts the volume level.
CH +/-	Changes the TV channel.

Button	Function
MUTE	Mutes or unmutes the TV audio.
AV MODE	Selects the input source (e.g., HDMI, AV).
MENU	Opens the TV's main menu.
Navigation (Up/Down/Left/Right/OK)	Navigates through menus and confirms selections.
RETURN	Goes back to the previous menu or screen.
EPG	Accesses the Electronic Program Guide.
Colored Buttons (Red, Green, Yellow, Blue)	Perform specific functions depending on the TV menu or application.

Maintenance

Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild cleaning solution. *Do not use abrasive cleaners, alcohol, or solvents, as these can damage the remote's surface or internal components.*

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AA 1.5V batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.

Troubleshooting

Problem	Possible Cause	Solution
Remote control does not work.	• Batteries are dead or incorrectly inserted. • Obstruction between remote and TV. • Remote control is too far from the TV.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the line of sight to the TV's IR receiver. • Move closer to the TV (within 10 meters).
Some buttons do not respond.	• Specific button malfunction. • Remote control is not fully compatible with all TV functions.	• Ensure the remote is pointed directly at the TV. • Verify your TV model is listed as compatible. While this remote is designed for broad compatibility, some advanced or model-specific functions may not be supported.

Specifications

- **Brand:** ALLIMITY
- **Model Name:** GA608WJSA
- **Connectivity Technology:** Infrared
- **Compatible Devices:** Sharp LED LCD TVs (Specific models listed in Introduction)
- **Color:** Black
- **Special Feature:** Ergonomic design
- **Maximum Range:** 10 Meters
- **Number of Buttons:** 20
- **Controller Type:** Button Control
- **Power Source:** 2 x AA 1.5V Batteries (not included)

Warranty and Support

Information regarding specific warranty terms is not provided in the product details. For any issues or support inquiries, please contact the seller or manufacturer directly through your purchase platform.
Manufacturer: allimity factory

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07C8J581T

More documents and user manuals: **https://manuals.plus/**