Royalty Line RL-SSK17L

Royalty Line RL-SSK17L Electric Kettle User Manual

Model: RL-SSK17L

Introduction | Safety Instructions | Features | Specifications | Setup | Operation | Warranty & Support | Maintenance | Troubleshooting

1. Introduction

Thank you for purchasing the Royalty Line RL-SSK17L Electric Kettle. This manual provides important information regarding the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.
The RL-SSK17L is a 1.7-liter, 1500W electric kettle designed for efficient water boiling. It features a stainless steel body, a wireless design with 360° rotation, and multiple safety protection systems.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions carefully before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the kettle base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.
- Ensure the lid is securely closed before operating.
- This appliance is for household use only.

3. Product Features

- **Generous 1.7 Liter Capacity:** Ideal for preparing large amounts of hot water for various uses.
- **Powerful 1500W Heating Element:** Ensures rapid boiling for quick hot beverages and cooking needs.
- **Wireless Design with 360° Rotational Base:** Allows for easy lifting, pouring, and placement from any angle.
- **Durable Stainless Steel Construction:** The inner layer is food-grade stainless steel for safety and longevity.
- **Cool-Touch Handle:** Ergonomically designed polypropylene plastic handle remains cool during operation for safe handling.
- **Multiple Protection System:** Includes automatic shut-off upon boiling, boil-dry protection, and an overheating fusion system for enhanced safety.
- **Indicator Light:** Illuminates when the kettle is in operation, providing a clear visual cue.
- **Integrated Cable Storage:** For neat and space-saving storage of the power cord.



Image 1: Separable Design Base. The kettle features a wireless design with a base that allows 360-degree rotation, making it easy to lift and place the kettle from any direction.



Image 2: Double Material Construction. The kettle is constructed with an inner layer of food-grade stainless steel for water contact and an outer layer of PP plastic for safety and insulation.



Image 3: Fast Boiling with 1500W. The powerful 1500W heating element ensures water boils quickly and efficiently.



Image 4: Key Features. This image highlights the On/Off button with automatic shut-off, the ergonomic cool-touch handle to prevent burns, and the practical cable storage for a tidy countertop.



Image 5: Large Capacity and Boiling Time. The kettle has a generous capacity of 1.7 liters (approximately 8 cups) and boils water in 3-8 minutes, depending on the water volume.

4. Setup

1. **Unpack:** Carefully remove the kettle and its base from the packaging. Retain packaging for future storage or disposal.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the MAX level. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a flat, stable, heat-resistant surface, away from the edge of the counter. Ensure the power cord is not dangling where it can be pulled or tripped over.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet (220-240V, 50/60Hz).

5. Operating Instructions

1. **Fill the Kettle:** Press the lid release button to open the lid. Fill the kettle with the desired amount of fresh water. Do not fill below the MIN mark or above the MAX mark. Close the lid securely.
2. **Place on Base:** Place the kettle firmly onto its power base.
3. **Start Boiling:** Press the ON/OFF switch located at the bottom of the handle downwards. The indicator light will illuminate, indicating that the kettle is heating.
4. **Automatic Shut-off:** Once the water reaches a rolling boil, the kettle will automatically switch off, and the indicator light will extinguish.
5. **Pouring:** Carefully lift the kettle from its base and pour the hot water. Always pour slowly and steadily to avoid splashing.
6. **Re-boiling:** If you need to re-boil water immediately after it has switched off, wait a few seconds for the internal thermostat to reset before pressing the switch again.

Safety Features:

- **Boil-Dry Protection:** If the kettle is accidentally switched on without sufficient water, the boil-dry protection system will automatically switch it off to prevent damage. Allow the kettle to cool down before refilling with water.
- **Overheating Fusion System:** Provides an additional layer of safety against overheating.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your kettle.

1. **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface. Never immerse the kettle or its power base in water or any other liquid.
3. **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. This can affect performance.
    - Fill the kettle with a mixture of one part white vinegar and two parts water.
    - Bring the mixture to a boil and let it stand for at least 30 minutes, or longer for heavy scale.
    - Empty the kettle and rinse thoroughly with fresh water several times.
    - If necessary, repeat the process. Alternatively, commercial descaling solutions designed for kettles can be used following their instructions.
4. **Filter Cleaning:** If your kettle has a removable filter, gently remove it and rinse under running water. Use a soft brush if necessary to remove any deposits. Reinsert the filter securely after cleaning.

7. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in. Power outlet not working. Kettle not properly seated on base. Boil-dry protection activated.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker or try another outlet. Ensure the kettle is correctly placed on the power base. Allow the kettle to cool down for 10-15 minutes, then refill with water and try again.

Problem	Possible Cause	Solution
Kettle switches off before boiling.	Too much limescale buildup. Lid not closed properly.	Descale the kettle as per the "Maintenance and Cleaning" section. Ensure the lid is securely closed.
Water tastes metallic or has an odor.	New kettle odor. Limescale buildup.	Perform initial cleaning (boil and discard water 2-3 times). Descale the kettle.

8. Specifications

Model:	RL-SSK17L
Brand:	Royalty Line
Capacity:	1.7 Liters
Power:	1500W
Voltage:	220-240V
Frequency:	50/60Hz
Case Material:	Stainless Steel
Handle Material:	PP Plastic
Color:	Red
Item Weight:	0.1 Kilograms

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact Royalty Line customer service directly. Keep your proof of purchase for any warranty claims.

© 2023 Royalty Line. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question