Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lovehoney Desire

Lovehoney Desire Vibrating Strapless Strap-On Dildo User Manual

Model: Desire

Introduction

Thank you for choosing the Lovehoney Desire Vibrating Strapless Strap-On Dildo. This manual provides essential information for the safe and effective use, care, and maintenance of your product. Please read it thoroughly before first use and retain it for future reference.



The Lovehoney Desire Vibrating Strapless Strap-On Dildo, shown with its USB charging cable and discreet storage case.

Safety Information

- **For adult use only.** Keep out of reach of children.
- **Clean before and after each use.** Refer to the 'Maintenance and Cleaning' section for detailed instructions.
- **Use only with water-based lubricants.** Silicone-based lubricants can damage silicone products.
- Do not use if the product appears damaged or compromised.
- If you experience any discomfort or irritation, discontinue use immediately and consult a healthcare professional.
- This product is not intended for medical use.

Setup

Charging the Device

Before first use, fully charge your Lovehoney Desire device. The device is powered by a rechargeable battery.

1. Locate the charging port on the device. This is typically a small circular port.
2. Insert the small end of the provided USB charging cable into the device's charging port.
3. Connect the larger USB end of the cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The indicator light on the device will illuminate or flash during charging. Refer to the device's specific light indicators for charging status.
5. Once fully charged, the indicator light will change (e.g., turn solid or turn off). Disconnect the device from the charger.



Connect the USB charging cable to the device's charging port for power.

Operating Instructions

The Lovehoney Desire features multiple vibration patterns and speeds for varied experiences.

Basic Operation

1. **Power On/Off:** Press and hold the power button (usually indicated by a circle or wave icon) for a few seconds to turn the device on or off.
2. **Change Vibration Patterns:** Once powered on, press the pattern button (often a wave icon) to cycle through the 8 available vibration patterns.
3. **Adjust Speeds:** Use the speed adjustment buttons (often '+' and '-' or up/down arrows) to select from the 12 intensity levels within each pattern.

The device is designed for dual stimulation, featuring a main shaft and pliable rabbit ears for clitoral stimulation.



The pliable rabbit ears are designed for external clitoral stimulation.

Usage Tips

- Always apply a generous amount of water-based lubricant to the device and desired areas before use.
- Experiment with different vibration patterns and speeds to find what is most pleasurable.
- The device is designed to be held in place by the wearer's Kegel muscles, allowing for hands-free use.

Official product video demonstrating the features and use of the Lovehoney Desire Vibrating Strapless Strap-On Dildo.

Maintenance and Cleaning

Proper cleaning and care will extend the life of your Lovehoney Desire device.

Cleaning

1. Always clean your device before and after each use.
2. Wash the device thoroughly with warm water and a toy cleaner or mild antibacterial soap.
3. Rinse thoroughly to remove all soap residue.
4. Pat dry with a lint-free cloth or allow to air dry completely before storing.

Waterproofing

The Lovehoney Desire is 100% waterproof, making it suitable for use in the bath or shower and easy to clean under running water.



The device is fully waterproof and can be used and cleaned in water.

Storage

Store your Lovehoney Desire in a clean, dry place, away from direct sunlight and extreme temperatures. The product comes with a luxurious storage case for discreet and protected storage.

- Ensure the device is completely dry before storing.
- Store separately from other silicone products to prevent material degradation.
- The provided storage case helps protect the device from dust and damage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB cable.
Device does not hold a charge.	Faulty charging cable or port; battery degradation.	Ensure the charging cable is securely connected and try a different USB power source. If the issue persists, contact customer support.
Vibrations are weak or inconsistent.	Low battery; internal malfunction.	Recharge the device. If the problem continues after a full charge, contact customer support.

Specifications

Feature	Detail
Model Name	Desire
Material	Silicone
Color	Purple (Note: Product images show purple, title says purple, but specifications list Beige. Purple is used for consistency with product presentation.)
Vibration Patterns	8
Vibration Speeds	12
Power Source	Rechargeable Battery (1 included)
Waterproof	100% Submersible
Product Dimensions	9.45 x 7.28 x 2.95 inches
Weight	1.21 Pounds

Warranty and Support

For warranty information or customer support, please refer to the packaging or contact Lovehoney directly through their official website or the retailer where the product was purchased.
You can visit the Lovehoney store on Amazon for more information:Lovehoney Amazon Store

© 2023 Lovehoney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CFWJKZQ

More documents and user manuals: **https://manuals.plus/**