Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NIXON Passport Watch

NIXON Men's Passport Watch User Manual

Model: Passport Watch

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your NIXON Men's Passport Watch. Please read this manual carefully to ensure proper use and longevity of your timepiece.

Product Overview



Figure 1: Placeholder image for the NIXON Men's Passport Watch, indicating that a specific product image is not available at this time.

The NIXON Men's Passport Watch is designed for reliability and style. It features a robust construction suitable for daily wear. This section provides a general overview of the watch's components and basic functions.

Setup

1. Setting the Time

1. Pull the crown (the small knob on the side of the watch) out to the first or second click position, depending on the model. Refer to specific model instructions if available.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to start the watch movement.

2. Adjusting the Strap/Bracelet

For optimal comfort, ensure the watch strap or bracelet is adjusted to fit your wrist securely but not too tightly. For metal bracelets, links may need to be added or removed by a professional jeweler. Leather or silicone straps typically feature multiple holes and a buckle for easy adjustment.

Operating Instructions

Reading the Time

The watch displays time using traditional hour, minute, and second hands. The hour hand is shorter and thicker, the minute hand is longer, and the second hand is typically thin and sweeps around the dial.

Date Function (if applicable)

If your Passport Watch includes a date display, it will typically be located in a small window on the dial. To set the date, pull the crown out to the first click position (if it has two clicks) and rotate it to advance the date. Always avoid setting the date between 9 PM and 3 AM, as this can damage the movement.

Maintenance

Cleaning Your Watch

Regular cleaning helps maintain the appearance of your watch. Use a soft, lint-free cloth to wipe the case and crystal. For water-resistant watches, a damp cloth can be used, but ensure the crown is pushed in completely before cleaning with moisture.

Water Resistance

The water resistance rating of your NIXON Passport Watch is typically engraved on the case back. Refer to this rating before exposing your watch to water. Common ratings include:

- **3 ATM (30 meters/100 feet):** Suitable for splashes or brief immersion in water. Not suitable for swimming or bathing.
- **5 ATM (50 meters/165 feet):** Suitable for short periods of recreational swimming. Not suitable for diving.
- **10 ATM (100 meters/330 feet):** Suitable for swimming and snorkeling.

Always ensure the crown is fully pushed in before any contact with water. Do not operate the crown or pushers while the watch is wet.

Battery Replacement

For quartz watches, the battery typically lasts several years. When the watch stops or the second hand begins to skip (indicating a low battery), it is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and prevent damage to the movement.

Troubleshooting

Problem	Possible Cause	Solution
Watch not running	Dead battery (quartz) / Not wound (mechanical) / Crown pulled out	Replace battery / Wind the watch / Push crown in fully
Time is incorrect	Time not set correctly / Watch stopped	Reset the time / Refer to "Watch not running" solutions
Condensation under crystal	Moisture ingress / Temperature change	Seek professional service immediately to prevent damage. Avoid extreme temperature changes.

If the problem persists after attempting these solutions, please contact NIXON customer support or a certified watch repair center.

Specifications

Feature	Detail
Brand	NIXON
Model	Passport Watch
ASIN	B07CKLJBKD
Manufacturer	Nixon
Date First Available	November 29, 2013
Movement Type	*(Not specified, typically Quartz or Automatic)*
Water Resistance	*(Refer to case back for specific rating)*

Warranty and Support

NIXON products are manufactured to high standards. For detailed information regarding the warranty period and terms for your Passport Watch, please refer to the official NIXON website or the warranty card included with your purchase.
For technical support, service, or inquiries about your watch, please contact NIXON customer service directly. Contact information can typically be found on the official NIXON website:

Visit Nixon Official Website

© 2024 NIXON. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CKLJBKD

More documents and user manuals: **https://manuals.plus/**