Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY HA-HA-06-02

YING RAY Replacement Remote Control HA-HA-06-02 for Emerson Air Conditioners

User Instruction Manual

1. Introduction

This document provides instructions for the YING RAY replacement remote control, model HA-HA-06-02, designed for use with specific Emerson air conditioner models. This remote control functions as a direct replacement for the original Emerson remote control model 112150010001. It is important to note that this remote is not a universal remote and is only compatible with the listed Emerson air conditioner models.

2. Setup

2.1 Battery Installation

The remote control requires two AAA 1.5V ordinary batteries (not included). Follow these steps for proper battery installation:

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Close the battery compartment cover securely.



This diagram illustrates the two common types of AAA batteries found in the USA and Canada markets, labeled 'A' (longer positive pole) and 'B' (shorter positive pole). For type 'B' batteries, if the remote does not function, gently pull out the positive pole spring in the battery compartment to ensure proper contact. The images below show the battery compartment and the spring adjustment process.

2.2 First Use

Once batteries are installed, the remote control is ready for immediate use. No programming or pairing is required.

3. Operating Instructions

3.1 Remote Control Layout





This image displays the front of the YING RAY replacement remote control. Key buttons include ON/OFF (red), MODE, SPEED, TIMER, and TEMP/TIME (up/down arrows). The model number 'HA-HA-06-02' is printed at the bottom.

3.2 Button Functions

- **ON/OFF:** Powers the air conditioner on or off.
- **MODE:** Cycles through various operating modes (e.g., Cool, Fan, Dry, Heat, Auto).
- **SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TIMER:** Sets the timer for automatic power on or off.
- **TEMP/TIME (▲ / ▼):** Adjusts the temperature setting or timer duration.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's range decreases or if it stops responding. Always replace both batteries simultaneously with new AAA 1.5V batteries. Do not mix old and new batteries or different battery types.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA 1.5V batteries.
  - Refer to Section 2.1 regarding battery type 'B' and adjusting the positive pole spring if necessary.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- **Short operating range:**
  - This typically indicates low battery power. Replace the batteries.
  - Ensure you are within the maximum operating range of 10 meters.

6. Specifications

Feature	Detail
Brand	YING RAY
Remote Model Number	HA-HA-06-02
Replacement for Emerson Model	112150010001
Compatible Devices	Emerson Air Conditioner
Connectivity Technology	Infrared
Maximum Range	10 Meters
Battery Type	AAA (1.5V)
Controller Type	Button Control

7. Compatible Air Conditioner Models

This remote control is compatible with the following Emerson air conditioner models:

- 12MJ46, 12MJ46-B
- 16MD17, 16MD17-A, 16MD17-B
- 18KD46, 18KD46-A, 18KD46-B, 18KD46-C, 18KD46-D, 18KD46-EM
- 24MD46, 24MD46-A, 24MD46-B, 24MD46-HA

8. Warranty and Support

For any questions regarding the compatibility or functionality of this remote control, please contact the seller or manufacturer directly. Specific warranty details may vary and should be confirmed with your point of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CMVSD1V

More documents and user manuals: **https://manuals.plus/**