Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY HA-HA-06-01

YING RAY Replacement Remote Control User Manual

Model: HA-HA-06-01 (Replacement for FEDDERS Air Conditioner Remote Control)

Introduction

This user manual provides detailed instructions for the operation and maintenance of your YING RAY HA-HA-06-01 replacement remote control. This remote is specifically designed as a compatible replacement for various FEDDERS air conditioner models. Please read this manual thoroughly before use to ensure proper functionality and to extend the life of your remote control.

Safety Information

- Do not expose the remote control to direct sunlight, high temperatures, or high humidity.
- Avoid dropping or subjecting the remote control to strong impacts.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.

Product Overview

The YING RAY HA-HA-06-01 remote control is designed for ease of use, featuring essential buttons for controlling your FEDDERS air conditioner.


ON/OFF
MODE
SPEED
TIMER
▲
TEMP/TIME
▼
HA-HA-06-01

Figure 1: Front view of the YING RAY HA-HA-06-01 replacement remote control.



Figure 2: Remote control with compatibility and no programming needed information.

Button Functions:

- **ON/OFF:** Powers the air conditioner on or off.
- **MODE:** Cycles through operating modes (e.g., Cool, Fan, Dry, Heat, Auto).
- **SPEED:** Adjusts fan speed (e.g., Low, Medium, High, Auto).
- **TIMER:** Sets the timer for automatic on/off operations.
- **TEMP/TIME (▲/▼):** Adjusts temperature settings or timer duration.

Setup

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two (2) AAA 1.5V ordinary batteries, ensuring the correct polarity (+ and -) as indicated inside the

compartment. *(Batteries are not included)*

4. Close the battery cover securely.

The remote control is ready for use immediately after battery installation. No programming is required.

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating.

Basic Operation:

- **To Turn On/Off:** Press the **ON/OFF** button.
- **To Change Mode:** Press the **MODE** button repeatedly to cycle through available modes (e.g., Cool, Fan, Dry).
- **To Adjust Fan Speed:** Press the **SPEED** button repeatedly to select desired fan speed.
- **To Set Temperature:** Use the **TEMP/TIME ▲** button to increase temperature and **TEMP/TIME ▼** button to decrease temperature.

Timer Function:

The TIMER button allows you to set a specific time for the air conditioner to turn on or off automatically.

1. Press the **TIMER** button.
2. Use the **TEMP/TIME ▲** or **▼** buttons to adjust the desired time.
3. Press the **TIMER** button again to confirm the setting.

Compatibility

This YING RAY HA-HA-06-01 remote control is a direct replacement for FEDDERS air conditioner remote control model 112150010006. It is compatible with the following FEDDERS air conditioner models:

A2D24E7DG-B

A2D24E7DG-D

A2D24E7E-E

A2D24E7E-F

A2D24E7E-G

A3D18E7B-D

A3Q05F2AG-L

A3Q08F2E-D

A6D18E7A-C

A6D18E7A-D

A6D18E7A-E

A6D24E7A

A6D24E7A-A

A6D24E7A-B

A6D24E7A-C

A6D24E7A-K

A6D24E7A-L

A6D24E7C

A6D24E7C-A

A6D24E7D

A6J12E2A-A

A6J12E2A-B

A6J12E7A-A

A6J12E7A-B

A6K32E7B

A6K32E7C

A6K32E7C-C

A6P09S2A

A6Q08F2A

A6Q08F2A-A

A6Q08F2A-C

A6Q10F2A

A6Q10F2A-A

A6Q10F2A-B

A6Q10F2A-C

A6Q10F2A-D

A6Q10F2A-E

A6Q10F2D

A6T12F2A

A6T12F2A-A

A6T12F2A-E

A6T12F2A-F

A6U10W2A-B

A6U10W2A-C

A6U10W7A-A

A6U10W7A-B

A6U10W7A-C

A6U10W7A-D

A6U12W2B-A

A6U12W2B-B

A6U12W2B-C

A6U12W2B-D

A6U12W7B-A

A6U12W7B-B

A6U12W7B-C

A6U12W7B-D

A6U12W7F-A

A6U12W7F-B

A6U12W7F-C

Note: This is not a universal remote control. It is only compatible with the models listed above and those that use the original remote control model 112150010006.

Maintenance

- Clean the remote control regularly with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- If the remote control is not responding, check the batteries. Replace them if they are depleted or if the remote has been stored for a long time.
- Ensure there are no obstructions between the remote control and the air conditioner's receiver.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Batteries are dead or inserted incorrectly.	Replace batteries with new AAA 1.5V batteries, ensuring correct polarity.
Remote control range is poor.	Weak batteries or obstruction.	Replace batteries. Ensure no objects are blocking the signal path to the air conditioner.
Air conditioner does not respond to commands.	Remote control incompatibility or air conditioner issue.	Verify your air conditioner model is listed in the compatibility section. If it is, ensure the air conditioner is powered on and functioning correctly.

Specifications

- **Model:** HA-HA-06-01
- **Compatible with:** FEDDERS Air Conditioner Remote Control Model 112150010006 and listed AC models.
- **Power Source:** 2 x AAA 1.5V Batteries (Not Included)
- **Material:** ABS Plastic
- **Color:** White (as per item picture)
- **Special Feature:** Ergonomic design

Warranty and Support

For any questions or concerns regarding your YING RAY replacement remote control, please contact the seller or manufacturer directly. Information regarding specific warranty terms may be provided at the point of purchase or by contacting the manufacturer.
Manufacturer: ZHUHAI YINGRAY TRADING CO., LTD.
If you are unsure about compatibility or require further assistance, please reach out to customer support with your air conditioner's model number.

© 2024 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CMZG2BH

More documents and user manuals: **https://manuals.plus/**