Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RC-1120

ZdalaMit RC-1120 Remote Control User Manual

For Denon AV Receivers: AVR-590, DHT590BA, AVR-1610

1. Introduction

This manual provides instructions for the ZdalaMit RC-1120 replacement remote control. This remote is designed to be compatible with specific Denon AV Receiver models, including AVR-590, DHT590BA, and AVR-1610. It offers direct functionality without the need for programming or pairing.

2. Package Contents

- 1x ZdalaMit RC-1120 Remote Control

Note: Batteries and a separate user manual are not included in the package.

3. Setup

3.1 Battery Installation

The RC-1120 remote control requires two (2) AAA alkaline batteries for operation.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the RC-1120 remote control with the battery compartment open, illustrating the correct placement for two AAA batteries.

3.2 Initial Use

Once batteries are installed, the remote control is ready for immediate use with compatible Denon AV Receivers. No programming or pairing is required.

4. Operating Instructions

The ZdalaMit RC-1120 remote control provides full functionality for your compatible Denon AV Receiver. Below is a general overview of key button functions.



Image: Front view of the RC-1120 remote control, displaying its layout and various function buttons.

4.1 Power Control

- **ON/SOURCE** (Red button, top right): Powers on the AV Receiver and cycles through input sources.
- **OFF** (Red button, top left): Powers off the AV Receiver.
- **TV POWER** (Red button, top right, below ON/SOURCE): Controls the power of a connected TV (if programmed, though this remote is primarily for the AV receiver).

4.2 Input Selection

Use the numbered buttons (1-7) or dedicated source buttons to select your desired input source.

- **DVD, TV, TUNER, V.AUX, HDP, iPod, DVR, VCR, SAT/CBL, SPEAKERS** Direct access buttons for various audio/video sources.

- **SOURCE SELECT**: Cycles through available input sources.

4.3 Volume and Mute

- **VOLUME ▲ / ▼**: Adjusts the master volume level of the AV Receiver.
- **MUTE**: Toggles the audio mute function on/off.

4.4 Navigation and Menu Control

- **MENU**: Accesses the AV Receiver's main menu.
- **Directional Arrows (▲, ▼, ◄, ►)**: Navigate through menu options.
- **ENTER**: Confirms selections within menus.
- **RETURN**: Goes back to the previous menu or screen.
- **CH LEVEL/TOP MENU** and **HOME/CONTROL**: Specific menu navigation buttons.

4.5 Playback Controls

- **PLAY (►), PAUSE (||), STOP (■), REWIND (◄◄), FAST FORWARD (►►), SKIP+ (►|), SKIP- (|◄)** Standard playback controls for connected media devices.

4.6 Audio Modes and Settings

- **MULTIEQ, DYN EQ, DYN VOL**: Buttons for audio equalization and dynamic volume settings.
- **CINEMA, MUSIC, SIMU, RESTORER**: Sound mode presets.
- **DIMMER**: Adjusts display brightness.
- **STATUS**: Displays current status information.

5. Troubleshooting

5.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new AAA alkaline batteries.
- **Line of Sight:** Make sure there is a clear line of sight between the remote control and the AV Receiver's infrared sensor. Obstructions can block the signal.
- **Receiver Power:** Confirm that the Denon AV Receiver is powered on.

5.2 Limited Functionality

- **Compatibility:** Verify that your Denon AV Receiver model (AVR-590, DHT590BA, AVR-1610) is listed as compatible. This remote is a replacement and may not support all advanced functions of the original remote for other models.
- **TV Control:** The "TV POWER" button's functionality for a connected TV is dependent on the AV Receiver's capabilities and may not be universally supported by this replacement remote.

6. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

7. Specifications

Feature	Detail
Model Number	RC-1120
Brand	ZdalaMit
Compatibility	Denon AV Receivers: AVR-590, DHT590BA, AVR-1610
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Dimensions	7 x 2 x 1 inches (approximately)
Item Weight	2.6 ounces (approximately)
Special Feature	Ergonomic design

8. Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the seller or retailer from whom the product was purchased. For technical support or inquiries, please contact the ZdalaMit customer service.
Note: The original Denon AV Receiver's warranty does not cover issues related to third-party replacement remote controls.

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CNQT1SC

More documents and user manuals: **https://manuals.plus/**