Aicook CM4329

Aicook CM4329 Drip Coffee Maker User Manual

Model: CM4329

Introduction

Thank you for choosing the Aicook CM4329 Drip Coffee Maker. This manual provides essential information for the safe and efficient use of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

Important Safety Instructions

- Read all instructions before operating the coffee maker.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The carafe is designed for use with this appliance. It must never be used on a range top.
- Do not place a hot carafe on a cold or wet surface.
- Do not use a cracked carafe or a carafe having a loose or weakened handle.

- Do not clean carafe with cleansers, steel wool pads, or other abrasive material.

Product Components

Familiarize yourself with the parts of your Aicook CM4329 Drip Coffee Maker:

- LCD Programmable Control Panel
- Water Reservoir
- Sprinkler Head
- Filter Basket (reusable)
- Anti-drip Valves
- 1.8L Large-capacity Glass Carafe
- Heat-Preservation Plate (Warming Plate)
- Power Cord



Figure 1: Overview of the Aicook CM4329 Drip Coffee Maker with key components labeled, including the LCD control panel, anti-drip valves, 1.8L glass carafe, and heat-preservation plate.

Setup Guide

Initial Cleaning Before First Use

1. Unpack the coffee maker and remove all packaging materials.

2. Clean all detachable parts, including the glass carafe and filter basket, thoroughly with hot water and mild detergent. Rinse well.
3. Fill the water reservoir to the maximum level with clean water.
4. Run the coffee maker through several brewing cycles without coffee grounds. This helps to clean the internal components and remove any manufacturing residues. Discard the water after each cycle.
5. Wipe the exterior of the coffee maker with a damp cloth.

Placement

- Place the coffee maker on a flat, stable, heat-resistant surface.
- Ensure there is adequate clearance around the unit for ventilation.
- Keep the coffee maker away from water sources and heat-emitting appliances.

Operating Instructions

Brewing Coffee

1. Open the top lid and fill the water reservoir with fresh, cold water to the desired level, indicated by the water level window. Do not exceed the MAX fill line.
2. Place the reusable filter basket into its designated position.
3. Add the desired amount of ground coffee into the filter basket. A general guideline is one tablespoon of coffee grounds per cup. Adjust to personal preference.
4. Close the top lid securely.
5. Place the empty glass carafe on the warming plate. Ensure it is properly seated to activate the anti-drip mechanism.
6. Plug the power cord into a standard electrical outlet.
7. Press the **ON/OFF** button to start the brewing process. The indicator light will illuminate.
8. The coffee maker will begin brewing, dispensing hot water (92°C-95°C) over the coffee grounds via the sprinkler head.
9. Once brewing is complete, the coffee maker will automatically switch to the keep warm function.



Figure 2: Detail of the sprinkler head for optimal brewing temperature and the warming plate for maintaining coffee temperature.

Using the 24-Hour Programmable Timer

The programmable timer allows you to set the coffee maker to start brewing automatically at a desired time.

1. Ensure the current time is set correctly on the LCD display. If not, press the **HOUR** and **MINUTE** buttons to adjust.
2. Prepare the coffee maker for brewing as described in steps 1-6 above (water, coffee grounds, carafe in place).
3. Press the **PROG** button. The display will show "PROG" or a clock icon.
4. Use the **HOUR** and **MINUTE** buttons to set your desired brew time.
5. Press the **PROG** button again to confirm the programmed time. The "AUTO" indicator will light up.
6. The coffee maker will automatically start brewing at the set time.



Figure 3: The 24-hour programmable timer allows for scheduled brewing.

Pause and Serve Function

The anti-drip system allows you to temporarily remove the carafe during the brewing cycle to pour a cup of coffee. The brewing process will pause and resume once the carafe is returned to the warming plate. Do not remove the carafe for more than 30 seconds to prevent overflow.

Keep Warm Function

After brewing, the warming plate will automatically keep the coffee hot at an optimal temperature (60°C-75°C) for up to 6 hours. The coffee maker will automatically shut off after 2 hours of inactivity to conserve energy and for safety.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your coffee maker.

Daily Cleaning

1. Always unplug the coffee maker and allow it to cool completely before cleaning.
2. Remove the filter basket and discard used coffee grounds. Wash the filter basket and glass carafe in warm, soapy water. Rinse thoroughly and dry. These parts are also top-rack dishwasher safe.
3. Wipe the exterior surfaces of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
4. Do not immerse the coffee maker's main body, cord, or plug in water or any other liquid.

Descaling (Mineral Deposit Removal)

Mineral deposits (calcium) can build up in your coffee maker over time, affecting its performance. Descale your coffee maker every 2-4 weeks, or more frequently if you have hard water.

1. Fill the water reservoir with a mixture of white vinegar and water (1:2 ratio).
2. Place an empty carafe on the warming plate.
3. Start a brewing cycle without coffee grounds.
4. After about half a cup has brewed, turn off the coffee maker and let it soak for at least 15 minutes to allow the vinegar solution to clean the internal components.
5. Turn the coffee maker back on and let the remaining solution brew through.
6. Discard the vinegar solution.
7. Run 2-3 cycles with fresh, clean water to rinse out any remaining vinegar taste or odor.

Troubleshooting

If you encounter issues with your coffee maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Coffee does not brew.	No power; water reservoir empty; carafe not properly placed.	Check power connection; fill water reservoir; ensure carafe is correctly seated on warming plate.
Coffee is too weak or too strong.	Incorrect coffee-to-water ratio; coffee grind size.	Adjust coffee grounds amount; use medium grind coffee.
Water overflows from filter basket.	Too much coffee grounds; filter basket clogged; carafe removed for too long.	Reduce coffee grounds; clean filter basket; return carafe quickly.
Coffee tastes bad.	Old coffee grounds; dirty coffee maker; poor water quality.	Use fresh coffee; clean coffee maker thoroughly (including descaling); use filtered water.
Coffee maker leaks.	Water reservoir overfilled; carafe not properly seated; damaged carafe.	Do not overfill; ensure carafe is correctly placed; inspect carafe for cracks.

If the problem persists after trying these solutions, please contact customer support.

Technical Specifications

Brand	Aicook
Model Number	CM4329
Capacity	1.8 Liters / 12 Cups

Rated Voltage	120 V
Rated Frequency	60 Hz
Rated Power	900 W
Product Dimensions (L x W x H)	19 x 20 x 30 cm (approx. 7.5 x 7.9 x 11.8 inches)
Net Product Weight	1.74 kg (approx. 3.84 lbs)
Material	Stainless Steel, Glass
Special Features	24-Hour Programmable Timer, Anti-drip Function, Keep Warm Function (up to 6 hours), Reusable Filter, Water Level Window

Warranty Information

The Aicook CM4329 Drip Coffee Maker comes with a **2-year warranty** for defective products. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

Customer Support

For any questions, concerns, or assistance with your Aicook CM4329 Drip Coffee Maker, please contact our customer service team. Our support is available 24 hours a day to help you.

Contact Information:

Website: www.aicook.com/support (Example Link)

Email: support@aicook.com (Example Email)

Phone: 1-800-XXX-XXXX (Example Number)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question