De'Longhi ECP3120

De'Longhi ECP3120 15 Bar Espresso Machine User Manual

Model: ECP3120
Brand: De'Longhi

Introduction

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your De'Longhi ECP3120 15 Bar Espresso Machine. Please read this manual thoroughly before first use and keep it for future reference.

Important Safety Information

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Scalding may occur if the water tank lid is removed during the brewing cycle.

Product Overview

Familiarize yourself with the components of your De'Longhi ECP3120 Espresso Machine.



Figure 1: Front view of the De'Longhi ECP3120 Espresso Machine, showcasing its compact design and control panel.



Figure 2: Overview of the machine's features including the steel drip tray, advanced frother, and twin brewing cycle. Water is shown being poured into the top-fill reservoir.



Figure 3: The 3-in-1 filter holder, designed for single shots, double shots, or Easy Serve Espresso (ESE) pods. Also shown are the ESE pods and the removable water tank for easy cleaning and refilling.

Included Components:

- De'Longhi ECP3120 Espresso Machine
- 3-in-1 Filter Holder (for 1 shot, 2 shots, or ESE pods)
- Scoop/Tamper
- Removable Water Tank
- Removable Drip Tray

Setup

1. Initial Cleaning

Before first use, wash all removable parts (water tank, filter holder, filters, drip tray) with warm water and mild detergent. Rinse thoroughly and dry. Wipe the exterior of the machine with a damp cloth.

2. Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill the tank with fresh, cold water up to the MAX level indicator. Do not exceed the MAX level.
3. Place the water tank back into its position, ensuring it is seated correctly.

3. Priming the Machine (First Use)

This step is crucial to ensure the internal circuits are filled with water and the machine is ready for use.

1. Ensure the water tank is filled.
2. Place a container under the coffee spouts and another under the steam wand.
3. Plug the machine into a grounded electrical outlet.
4. Turn the main switch to the "ON" position. The "READY" light will blink.
5. Once the "READY" light is steady, turn the selector knob to the coffee cup symbol (☕) and let water dispense until the tank is almost empty.
6. Turn the selector knob back to the "OFF" position.
7. Refill the water tank. The machine is now primed and ready for brewing.

Operating Instructions

Making Espresso

Your ECP3120 machine is equipped with a 15-bar professional pressure pump to ensure quality results.



Figure 4: The machine brewing espresso and a layered latte, demonstrating its capability for various coffee beverages with 15-bar professional pressure.

1. **Prepare the Filter Holder:** Insert the appropriate filter (1-shot, 2-shot, or ESE pod filter) into the filter holder.
2. **Add Coffee:** For ground coffee, use the scoop to add the desired amount of finely ground espresso coffee into the filter. Tamp the coffee firmly and evenly with the tamper end of the scoop. Remove any excess coffee from the rim. For ESE pods, place one pod into the ESE pod filter.
3. **Attach Filter Holder:** Insert the filter holder into the group head of the machine. Turn it firmly to the right until it is securely locked in place.
4. **Place Cups:** Place one or two espresso cups on the drip tray directly under the coffee spouts.
5. **Brew Espresso:** Ensure the machine is on and the "READY" light is steady. Turn the selector knob to the coffee cup symbol (☕). Coffee will begin to dispense.
6. **Stop Brewing:** Once the desired amount of espresso is brewed, turn the selector knob back to the "OFF" position to stop the flow.

Frothing Milk (Advanced Cappuccino System)

The manual frother mixes steam and milk to create a rich, creamy froth for cappuccinos and lattes.



Figure 5: The De'Longhi ECP3120 Espresso Machine in action, demonstrating the frothing of milk using its steam wand for creamy

beverages.

1. **Prepare Milk:** Fill a pitcher with cold milk (dairy or non-dairy) to about one-third full.
2. **Activate Steam:** Turn the selector knob to the steam symbol (♨). The "READY" light will blink as the machine heats up for steam.
3. **Purge Steam Wand:** Once the "READY" light is steady, briefly turn the steam knob on the side counter-clockwise to release any condensed water from the wand into a separate container. Turn the steam knob off.
4. **Froth Milk:** Immerse the steam wand into the milk, just below the surface. Turn the steam knob on. Move the pitcher up and down slowly to incorporate air and create froth. Once desired froth and temperature are achieved, turn the steam knob off.
5. **Clean Steam Wand:** Immediately wipe the steam wand with a damp cloth to prevent milk residue from drying. Briefly turn the steam knob on again to clear any internal milk residue.
6. **Return to Coffee Mode:** Turn the selector knob back to the "OFF" position. If brewing coffee immediately after steaming, you may need to cool the boiler by dispensing some hot water through the coffee spouts until the "READY" light becomes steady again.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your espresso machine.

Daily Cleaning

- **Drip Tray:** Empty and rinse the drip tray daily or when the red indicator floats up.
- **Filter Holder and Filters:** After each use, remove the filter holder, discard used coffee grounds, and rinse the filter holder and filter under running water. Use a brush to clean any coffee residue from the filter.
- **Steam Wand:** As mentioned in the operating instructions, wipe the steam wand immediately after each use and purge it briefly to prevent milk blockage.
- **Water Tank:** Rinse the water tank daily and refill with fresh water.

Periodic Cleaning (Descaling)

Mineral deposits from water can build up over time, affecting machine performance. Descale your machine regularly, depending on water hardness and frequency of use (e.g., every 2-3 months).

1. Use a commercial descaling solution specifically designed for espresso machines. Follow the descaler manufacturer's instructions carefully.
2. Fill the water tank with the descaling solution mixed with water according to the descaler's instructions.
3. Place a large container under the coffee spouts and steam wand.
4. Run half of the solution through the coffee spouts by turning the selector knob to the coffee cup symbol (☕).
5. Run the remaining half of the solution through the steam wand by turning the selector knob to the steam symbol (♨) and opening the steam knob.
6. After the descaling solution has run through, rinse the water tank thoroughly and fill it with fresh water.
7. Run several full tanks of fresh water through both the coffee spouts and the steam wand to thoroughly rinse the machine and remove any descaler residue.

Troubleshooting

This section addresses common issues you might encounter with your espresso machine.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No coffee dispenses or only drips	Coffee is ground too fine or tamped too hard; filter is clogged; machine needs descaling.	Use coarser grind or tamp less firmly. Clean the filter. Descale the machine.
Coffee is too weak	Coffee is ground too coarse; not enough coffee used; machine needs descaling.	Use finer grind. Increase coffee quantity. Descale the machine.
No steam from wand	Steam wand is clogged; machine not hot enough for steam.	Clean the steam wand hole with a pin. Wait for the "READY" light to be steady in steam mode.
Water leaking from machine	Water tank not seated correctly; drip tray is full; seal issue.	Ensure water tank is firmly in place. Empty drip tray. If problem persists, contact customer support.
Machine does not turn on	Not plugged in; power outlet issue.	Check power cord connection. Test outlet with another appliance.

Specifications

- **Brand:** De'Longhi
- **Model:** ECP3120
- **Color:** Black
- **Product Dimensions (D x W x H):** 9.6" x 7.2" x 11.9"
- **Item Weight:** 10.6 pounds
- **Coffee Maker Type:** Espresso Machine
- **Operation Mode:** Manual
- **Pressure:** 15 Bar
- **Voltage:** 110 Volts
- **Included Components:** 3-in-1 filter holder, Espresso Machine, Scoop/tamper
- **UPC:** 044387031202

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official De'Longhi website. For further assistance or technical support, please contact De'Longhi customer service.
You can also find additional information and a downloadable user guide PDF here:De'Longhi ECP3120 User Guide (PDF)

© 2025 De'Longhi. All rights reserved.