Holstein Housewares HH-090170001

Holstein Housewares HH-090170001 Ice Cream Maker Instruction Manual

Safety Information Product Components Setup Operating Instructions Care & Maintenance Troubleshooting Specifications Warranty & Support

1. Important Safety Information

Please read all instructions carefully before using the Holstein Housewares HH-090170001 Ice Cream Maker. Failure to follow these safety guidelines may result in electric shock, fire, or personal injury.

- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not immerse the motor base or electrical cord in water or other liquids.
- Keep hands and utensils out of the freezer bowl during operation to prevent injury and damage to the unit.
- Only use rubber, plastic, or wooden utensils to serve from the freezer bowl to prevent scratching or damaging the bowl.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Ensure the appliance is placed on a stable, level, heat-resistant surface.
- Close supervision is necessary when any appliance is used by or near children.

2. Product Components

Familiarize yourself with the parts of your Holstein Housewares Ice Cream Maker:

- **Motor Base / Control Box:** Houses the motor and electronic controls, including the digital LCD display. This part is detachable for easy cleaning.
- **Lid:** Features an opening for adding ingredients and a digital LCD display for time.
- **Mixing Paddle:** Designed to churn the ice cream mixture.
- **Freezer Bowl:** The double-insulated bowl that must be pre-frozen to chill the ingredients.
- **Stainless Steel Cover:** The outer casing of the appliance.



This image displays the Holstein Housewares HH-090170001 Ice Cream Maker in black and stainless steel, alongside a plate of three ice cream scoops. A key feature, the detachable control box for easy cleaning, is highlighted.



A detailed view of the Holstein Housewares HH-090170001 Ice Cream Maker's top panel, featuring the digital LCD display and control buttons for setting the timer and operating the device.

3. Setup and First Use

3.1 Unpacking and Initial Cleaning

1. Carefully remove all components from the packaging.
2. Wash the freezer bowl, mixing paddle, and lid in warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the motor base/control box with a damp cloth. Do not immerse the motor base in water.
4. Ensure all parts are completely dry before assembly.

3.2 Freezing the Freezer Bowl

For optimal results, the freezer bowl must be completely frozen before use. This typically takes 8 to 12 hours, or longer depending on your freezer's temperature.

- Place the empty freezer bowl in the coldest part of your freezer.
- Ensure the freezer temperature is set to 0°F (-18°C) or colder.
- The bowl is ready when the liquid inside is completely solid and no longer sloshes when shaken.

4. Operating Instructions

4.1 Preparing Your Ice Cream Mixture

- Prepare your desired ice cream, frozen yogurt, or sorbet mixture according to a recipe.
- Ensure the mixture is chilled in the refrigerator for at least 2-3 hours before churning. A cold mixture will yield better results.

4.2 Assembling the Ice Cream Maker

1. Place the frozen freezer bowl onto the motor base.
2. Insert the mixing paddle into the center of the freezer bowl.
3. Place the lid onto the freezer bowl, ensuring it is securely locked in place.

4.3 Churning Ice Cream

1. Plug the appliance into a standard electrical outlet.
2. Turn on the unit. The digital LCD display will illuminate.
3. Carefully pour your chilled ice cream mixture through the opening in the lid.
4. Set the desired churning time using the controls on the lid. Typical churning times range from 20 to 40 minutes, depending on the recipe and desired consistency.
5. Allow the machine to churn until the mixture reaches your desired consistency. The ice cream will be soft-serve consistency when finished.
6. Once churning is complete, turn off the unit and unplug it from the outlet.

4.4 Serving and Storage

- Remove the lid and mixing paddle.
- Use a rubber, plastic, or wooden spatula to scoop the ice cream from the freezer bowl. Avoid metal utensils to prevent damage to the bowl.
- For firmer ice cream, transfer the mixture to an airtight container and place it in the freezer for 2-4 hours.

5. Care and Maintenance

5.1 Cleaning

Regular cleaning ensures the longevity and hygiene of your ice cream maker.

1. Always unplug the appliance before cleaning.
2. Disassemble the lid, mixing paddle, and freezer bowl from the motor base.
3. Wash the lid, mixing paddle, and freezer bowl in warm, soapy water. These parts are not dishwasher safe.
4. The control box is detachable for easy cleaning. Wipe the motor base and detachable control box with a damp cloth. Do not immerse these parts in water.
5. Ensure all parts are thoroughly dried before reassembling or storing.

5.2 Storage

Store the ice cream maker in a clean, dry place when not in use. Do not store the freezer bowl in the freezer for extended periods if not intended for immediate use, as this can affect its lifespan.

6. Troubleshooting

If you encounter issues with your ice cream maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet issue; unit not assembled correctly.	Ensure the power cord is securely plugged into a working outlet. Check if the lid is properly seated.
Ice cream mixture is not freezing or is too soft.	Freezer bowl not sufficiently frozen; mixture not pre-chilled; too much mixture.	Ensure freezer bowl is frozen solid (8-12 hours). Pre-chill mixture in the refrigerator. Do not exceed the maximum fill line.
Mixing paddle stops during operation.	Mixture is too thick; too much mixture.	Ensure mixture consistency is appropriate for churning. Reduce the amount of mixture if overfilled.
Loud noise during operation.	Unit not assembled correctly; foreign object in bowl.	Check that the lid and mixing paddle are correctly installed. Ensure no foreign objects are in the bowl.

7. Product Specifications

Feature	Detail
Brand	Holstein Housewares
Model Name	HH-090170001
Color	Black/Stainless Steel
Material	Stainless Steel
Special Feature	Manual (Operation Mode: Automatic)
Included Components	Ice Cream Maker, Full Color Recipe Book
Item Weight	6 Pounds
UPC	813966024481

8. Warranty and Support

For warranty information, product registration, or customer support, please refer to the documentation included with your purchase or visit the official Holstein Housewares website.

You can also find more information and contact details on the **Holstein Housewares Brand Store on Amazon**.

© 2024 Holstein Housewares. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question