Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EUROSTAR ES111BK

EUROSTAR Single Burner with Cast-Iron Flat Plate - Model ES111BK User Manual

Your guide to safe and efficient use of your EUROSTAR countertop burner.

Introduction | Safety Instructions | Product Overview | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

Thank you for purchasing the EUROSTAR Single Burner with Cast-Iron Flat Plate, Model ES111BK. This appliance is designed for efficient and convenient cooking, ideal for various settings such as dorms, offices, RVs, or as an additional cooking surface at home. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block ventilation openings.

3. Product Overview

The EUROSTAR Single Burner ES111BK features a durable cast-iron flat plate for even heat distribution and a compact design for portability.



Image 1: Front view of the EUROSTAR Single Burner ES111BK, showing the cast-iron heating plate, temperature control knob, and power indicator light. The unit is black with a silver trim around the heating element.

Components:

- **Cast-Iron Flat Plate:** The primary heating surface, 165mm/6.5 inches in diameter, designed for durability and even heat retention.
- **Temperature Control Knob:** Used to adjust the heat level from minimum to maximum.
- **Power Indicator Light:** Illuminates when the burner is heating.
- **Non-Stick Rubber Feet:** Provides stability and prevents the unit from sliding during use.
- **Housing:** The main body of the appliance, containing internal components.

4. Setup and First Use

1. **Unpacking:** Carefully remove the burner from its packaging. Retain packaging for storage or disposal.
2. **Placement:** Place the burner on a flat, stable, heat-resistant surface, away from flammable materials. Ensure there is adequate ventilation around the unit. The non-stick rubber feet should firmly grip the surface.
3. **Initial Burn-Off:** Before first use, operate the burner without any cookware for approximately 5-10 minutes on the highest setting. This will burn off any manufacturing residues and odors. A slight smoke or odor is normal during this process. Ensure the area is well-ventilated.
4. **Cleaning:** After the initial burn-off and once the unit has completely cooled, wipe the cast-iron plate and exterior with

a damp cloth. Do not immerse the unit in water.

5. Operating Instructions

Follow these steps for safe and effective cooking with your EUROSTAR Single Burner:

1. **Connect Power:** Ensure the temperature control knob is set to the "OFF" position. Plug the power cord into a standard 120V AC electrical outlet.
2. **Place Cookware:** Place your desired cookware (pots, pans) directly onto the center of the cast-iron flat plate. Ensure the cookware has a flat bottom for optimal contact and heat transfer.
3. **Adjust Temperature:** Turn the temperature control knob clockwise to the desired heat setting. The power indicator light will illuminate, indicating that the burner is heating.
4. **Cooking:** The cast-iron plate will heat up, transferring heat to your cookware. Adjust the knob as needed during cooking. The indicator light may cycle on and off as the burner maintains the set temperature (auto safety shut-off feature).
5. **Finish Cooking:** Once cooking is complete, turn the temperature control knob counter-clockwise to the "OFF" position. The power indicator light will turn off.
6. **Cool Down:** Unplug the appliance from the wall outlet. Allow the burner to cool completely before cleaning or storing. The cast-iron plate will remain hot for a significant period after use.



Image 2: The EUROSTAR Single Burner ES111BK with a frying pan placed on its cast-iron heating element, containing a colorful mix of vegetables. This illustrates the burner in active use.

Tips for Best Results:

- Use cookware with a flat, smooth bottom for maximum heat transfer efficiency.
- Preheat the burner for a few minutes before adding food for more consistent cooking.
- The cast-iron plate retains heat well, so you may need to adjust the temperature lower than expected for simmering.

6. Maintenance and Cleaning

Proper care ensures the longevity and performance of your EUROSTAR Single Burner.

1. **Always Unplug:** Before cleaning, always ensure the burner is unplugged from the power outlet and has completely cooled down.
2. **Cleaning the Plate:** For the cast-iron plate, wipe with a damp cloth and mild detergent. For stubborn food residues, a non-abrasive scrubber can be used. Ensure the plate is thoroughly dry before next use or storage to prevent rust. Do not use harsh abrasive cleaners or metal scouring pads, as these can damage the surface.
3. **Cleaning the Exterior:** Wipe the exterior housing with a soft, damp cloth. Do not use abrasive cleaners.
4. **Do Not Immerse:** Never immerse the burner unit, cord, or plug in water or any other liquid.
5. **Storage:** Store the cooled and cleaned burner in a dry place, away from moisture.

7. Troubleshooting

If you encounter issues with your EUROSTAR Single Burner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Burner does not heat up.	Not plugged in. Power outlet is not working. Temperature knob is set to "OFF". Internal wiring issue (less common).	Ensure the unit is securely plugged into a working outlet. Test the outlet with another appliance. Turn the temperature knob to a desired heat setting. If problem persists, contact customer support.
Indicator light is off, but burner is still warm.	Normal operation of auto safety shut-off. Burner is cooling down after use.	This is normal. The light cycles on/off to maintain temperature. Allow the unit to cool completely before handling.
Smoke or odor during first use.	Manufacturing residues burning off.	This is normal for initial burn-off. Ensure good ventilation. It should subside after 5-10 minutes.
Burner heats slowly or unevenly.	Cookware not flat or too small/large. Low power setting.	Use cookware with a flat bottom that matches the burner size. Increase the temperature setting.

If the problem persists after trying these solutions, please contact EUROSTAR customer support.

8. Specifications

Model Number:	ES111BK
Brand:	EUROSTAR
Color:	Black
Material:	Cast Iron
Heating Elements:	1
Plate Diameter:	165mm / 6.5 inches
Wattage:	1000 watts
Voltage:	120 Volts
Controls Type:	Knob
Product Dimensions:	9.84"D x 9.88"W x 3.43"H
Item Weight:	3.55 pounds
UPC:	852367002698

9. Warranty and Customer Support

EUROSTAR products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official EUROSTAR website. If you have any questions, require technical assistance, or need to report a problem, please contact EUROSTAR customer support.

Customer Support:

- **Website:** www.eurostar.com (*Note: This is a placeholder URL. Please refer to your product packaging for actual support contact information.*)
- **Email:** support@eurostar.com (*Note: This is a placeholder email.*)
- **Phone:** Please refer to your product documentation for the correct customer service number.

When contacting support, please have your model number (ES111BK) and purchase date available.

© 2023 EUROSTAR. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CZ3B4G1

More documents and user manuals: **https://manuals.plus/**