De'Longhi 8541893385

De'Longhi 2-Cup Filter Assembly Instruction Manual

Model: 8541893385

1. Product Overview

This manual provides essential information for the proper use and maintenance of your De'Longhi 2-Cup Filter Assembly. This filter is designed to replace or supplement the original filter basket in compatible De'Longhi espresso machines, ensuring optimal coffee extraction.

Compatible Models:

- De'Longhi EC860
- De'Longhi ECP3420
- De'Longhi EC680M
- De'Longhi ECP3630



Figure 1: De'Longhi 2-Cup Filter Assembly (Top View)

This image displays the top view of the 2-cup filter assembly, highlighting its stainless steel construction and the perforated filter screen at the bottom, designed for efficient coffee extraction.



Figure 2: De'Longhi 2-Cup Filter Assembly (Bottom View)

This image shows the underside of the filter assembly, illustrating its smooth, rounded base which ensures a secure fit within the portafilter of compatible espresso machines.

2. Setup and Installation

The 2-Cup Filter Assembly is designed for easy installation into your espresso machine's portafilter.

2.1 Preparing the Portafilter

1. Ensure your espresso machine is turned off and unplugged before handling components.
2. Remove the portafilter from the group head of your espresso machine.
3. If an old filter basket is present, carefully remove it. Some portafilters have a retaining clip that may need to be disengaged.

2.2 Installing the Filter Assembly

1. Place the De'Longhi 2-Cup Filter Assembly into the portafilter, ensuring it sits flush and securely within the portafilter's rim.
2. Press down firmly to ensure the filter basket is fully seated. It should not wobble or lift easily.
3. The filter is now ready for use.

3. Operating Instructions

This filter assembly is used for brewing two cups of espresso. Follow your espresso machine's specific operating instructions for grinding coffee and brewing.

3.1 Brewing Espresso

1. Ensure the 2-Cup Filter Assembly is correctly installed in the portafilter.
2. Grind fresh coffee beans to an appropriate fineness for espresso. For a 2-cup basket, typically 14-18 grams of coffee are used, depending on desired strength and bean type.
3. Fill the filter basket with the ground coffee.
4. Distribute the coffee evenly and tamp it down with a tamper, applying firm, even pressure.
5. Wipe any excess coffee grounds from the rim of the portafilter.
6. Insert the portafilter into the group head of your espresso machine and lock it into place.
7. Place two espresso cups under the spouts.
8. Initiate the brewing cycle according to your espresso machine's instructions.
9. Once brewing is complete, remove the portafilter and discard the used coffee grounds.

4. Maintenance and Cleaning

Regular cleaning of your filter assembly is crucial for maintaining optimal performance and taste. This filter is designed to be easy to clean.

4.1 Daily Cleaning

1. After each use, remove the used coffee grounds from the filter basket.
2. Rinse the filter assembly thoroughly under warm running water.
3. Use a small brush or cloth to remove any remaining coffee residue from the perforations and sides of the basket.
4. Ensure all holes are clear of debris.
5. Dry the filter assembly completely before storing or next use.

4.2 Deep Cleaning (Weekly/Bi-weekly)

1. For a more thorough clean, especially if you notice reduced flow or clogging, you can soak the filter assembly in a solution of warm water and a mild descaling agent or espresso machine cleaner. Follow the cleaner's instructions for dilution and soaking time.
2. Alternatively, some users find that boiling the filter assembly in plain water for a few minutes can help dislodge stubborn coffee oils and fine particles. Ensure the filter is fully submerged.
3. After soaking or boiling, rinse the filter assembly extensively under running water to remove any cleaning solution or loosened debris.
4. Ensure all perforations are clear before reassembling.

5. Troubleshooting

If you encounter issues with your filter assembly, consider the following common problems and solutions:

- **Slow or No Flow:**
  This often indicates a clogged filter. Perform a deep clean as described in Section 4.2. Ensure coffee grounds are not too fine or tamped too hard.

- **Coffee Grounds in Espresso:**
  Ensure the filter assembly is properly seated in the portafilter. Check for any damage to the filter screen. Ensure coffee grounds are not excessively fine.
- **Filter Not Fitting Securely:**
  Verify that you have the correct filter size for your specific De'Longhi portafilter model. Ensure there are no obstructions or debris preventing a flush fit.
- **Weak Espresso:**
  Ensure you are using enough coffee grounds for a 2-cup basket (typically 14-18g). Check your grind size; it might be too coarse.

6. Specifications

Feature	Detail
Product Name	De'Longhi 2-Cup Filter Assembly
Model Number	8541893385
Material	Stainless Steel
Capacity	2-Cup
Dimensions (L x W x H)	6.38 x 4.84 x 1.18 inches
Item Weight	2.11 ounces
Compatible Espresso Machines	De'Longhi EC860, ECP3420, EC680M, ECP3630

7. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the official De'Longhi website or the original product packaging. You may also contact the retailer from whom you purchased this filter assembly.

© 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question