Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schick 7442511

Schick Xtreme 3 Sensitive Disposable Razor User Manual

Model: 7442511

Introduction

The Schick Xtreme 3 Sensitive Disposable Razor is designed to provide a close and comfortable shave, especially for sensitive skin. Featuring three flexible blades and dual comfort strips enriched with Vitamin E and Aloe, this razor adapts to your facial contours while helping to protect against irritation. This manual provides essential information on how to use and maintain your razor for optimal performance.





Image: Schick Xtreme 3 Sensitive Disposable Razors, 24 Count pack.

Setup

1. **Unpack the Razor:** Carefully remove the razor from its packaging.
2. **Remove Protective Cap:** Gently slide off the clear plastic protective cap from the razor head to expose the blades. Retain the cap for storage.

Operating Instructions

1. **Prepare Your Skin:** Wet the area to be shaved with warm water. Apply a generous amount of shaving cream or gel to create a rich lather.
2. **Shaving Technique:** Hold the razor with a firm but comfortable grip. Shave in the direction of hair growth using light, even strokes. The triple-blade design and flexible head will pivot to adapt to your skin's contours, ensuring a close

shave.

3. **Lubrication:** The dual comfort strips, formulated with Vitamin E and Aloe, will release lubricants onto your skin during shaving to help reduce friction and protect against irritation.
4. **Rinsing During Shave:** Periodically rinse the razor head under running water to clear away hair and shaving cream buildup. The easy-rinse design helps prevent clogging.

Maintenance

1. **Rinse Thoroughly:** After each use, rinse the razor head thoroughly under running water to remove all hair and shaving cream.
2. **Shake Off Excess Water:** Gently shake the razor to remove excess water from the blades. Do not wipe the blades, as this can dull them and reduce their lifespan.
3. **Store Properly:** Replace the protective cap over the razor head. Store the razor in a dry place to prevent rust and maintain blade sharpness.
4. **Disposal:** As a disposable razor, replace it when the blades feel dull or when the lubricating strips fade, typically after several shaves depending on hair type and frequency of use. Dispose of used razors responsibly.

Troubleshooting

- **Skin Irritation/Razor Burn:**
  - Ensure your skin is well-lubricated with shaving cream or gel before shaving.
  - Shave with the grain of your hair, especially if you have sensitive skin.
  - Replace your razor more frequently if irritation persists.
- **Dull Blades:**
  - If the razor pulls at your hair or feels rough, it's time to replace it.
  - Avoid wiping the blades with a towel, as this can damage the sharp edges.
- **Clogging:**
  - Rinse the razor head frequently under running water during your shave.
  - The open-back cartridge design is intended to facilitate easy rinsing.

Specifications

Feature	Detail
Brand	Schick
Model Number	7442511
Number of Blades	3
Handle Material	Plastic
Lubricating Strips	Dual Comfort Strips with Vitamin E & Aloe
Blade Flexibility	Flexes and pivots to adapt to facial contours

Rinse Design	Easy Rinse Design to prevent clogging
Product Dimensions	1.97 x 1.57 x 2.76 inches
Weight	11.36 ounces (for 8 count pack)
UPC	841058031604

Warranty

This product is a disposable item and typically does not come with an extended manufacturer's warranty. For any concerns regarding product quality upon purchase, please refer to the retailer's return policy or contact Schick customer service directly.

Support

For further assistance or inquiries about your Schick Xtreme 3 Sensitive Disposable Razor, please visit the official Schick website or contact their customer support. You can often find FAQs and additional product information on their site.
Official Schick Store: Visit the Schick Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07D1YCX4Z

More documents and user manuals: **https://manuals.plus/**