Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Leggett & Platt 4B8740

Leggett & Platt 4B8740 Adjustable Bed Steel Legs

User Manual

1. Introduction

This manual provides essential instructions for the safe and proper installation, operation, and maintenance of your Leggett & Platt 4B8740 Adjustable Bed Steel Legs. These legs are designed to provide stable and adjustable support for compatible Leggett & Platt adjustable bed bases. Please read this manual thoroughly before installation and retain it for future reference.

2. Safety Information

- **Read all instructions:** Ensure you understand all steps before beginning installation.
- **Proper tools:** Use appropriate tools for installation. Avoid overtightening.
- **Weight capacity:** Ensure the bed base and legs are not overloaded beyond their specified weight capacity.
- **Stable surface:** Install the bed base with legs on a flat, stable, and level surface.
- **Regular inspection:** Periodically check all leg connections for tightness and stability.
- **Children and pets:** Keep children and pets away from the bed base during installation and adjustment.

3. Package Contents

Verify that all components are present before proceeding with installation.

- 4 x Height-Adjustable Steel Legs (Model 4B8740)

Note: Additional hardware for attaching legs to the bed base is typically pre-installed on the bed base or included with the bed base itself.

4. Setup and Installation

Follow these steps to install the adjustable legs onto your Leggett & Platt adjustable bed base.

4.1 Attaching the Legs

1. **Prepare the bed base:** Carefully place your adjustable bed base upside down on a clean, soft surface to prevent

damage. Ensure it is stable.

2. **Locate mounting points:** Identify the threaded receptacles or mounting plates on the underside of your adjustable bed base where the legs are to be attached. There are typically four such points, one near each corner.
3. **Thread the legs:** Align the threaded bolt at the top of each steel leg with a mounting point on the bed base. Carefully thread the leg into the receptacle by turning it clockwise.
4. **Hand-tighten:** Hand-tighten each leg until it is snug. Do not overtighten, as this can damage the threads. Ensure all four legs are securely attached.
5. **Flip the bed base:** With assistance, carefully flip the bed base right-side up, ensuring the legs are stable on the floor.



Image: Leggett & Platt 4B8740 Adjustable Bed Steel Legs. This image shows the four steel legs, highlighting their design and threaded attachment point.

4.2 Adjusting the Height

The 4B8740 legs offer height adjustment from 6 to 10 inches.

1. **Identify adjustment mechanism:** Each leg features an inner and outer tube. The height is adjusted by extending or retracting the inner tube.
2. **Loosen locking mechanism:** Locate the locking collar or pin on each leg. Loosen it to allow the inner tube to move freely. (Specific mechanism may vary slightly; refer to your bed base manual if unsure).
3. **Adjust height:** Carefully lift the bed base slightly to relieve pressure on the legs. Extend or retract the inner tube of each leg to the desired height. Ensure all four legs are adjusted to the same height for a level bed.
4. **Secure locking mechanism:** Once the desired height is achieved, tighten the locking collar or re-insert the pin on each leg to secure the adjustment.
5. **Verify stability:** Gently shake the bed base to ensure it is stable and level at the new height. Readjust if necessary.

5. Operation

Once installed and adjusted, the legs provide stable support for your adjustable bed base. No further operational steps

are typically required for the legs themselves, beyond occasional height adjustments as described in Section 4.2.

6. Maintenance

- **Cleaning:** Wipe the steel legs with a dry cloth to remove dust and debris. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Periodic inspection:** Every few months, inspect the legs and their attachment points to the bed base. Ensure all connections remain tight and that the legs are not bent or damaged. Tighten any loose connections by hand.
- **Lubrication (if applicable):** If the height adjustment mechanism becomes stiff, a small amount of silicone-based lubricant can be applied to the sliding surfaces, if accessible. Avoid oil-based lubricants that can attract dust.

7. Troubleshooting

7.1 Bed Base is Wobbly or Uneven

- **Check leg tightness:** Ensure all four legs are securely tightened to the bed base.
- **Verify height adjustment:** Confirm that all legs are adjusted to the exact same height. Use a measuring tape if necessary.
- **Level surface:** Ensure the floor surface where the bed base rests is level. If not, consider using shims under the lowest leg(s) or adjusting the legs to compensate for minor floor irregularities.

7.2 Difficulty Adjusting Leg Height

- **Relieve pressure:** Lift the bed base slightly to take weight off the legs before attempting to adjust the height.
- **Loosen locking mechanism:** Ensure the locking collar or pin is fully loosened.
- **Clean legs:** Dust or debris inside the leg tubes can impede movement. Clean the legs as described in the Maintenance section.

8. Specifications

Model	4B8740
Material	Steel (Alloy Steel finish)
Color	Black
Height Adjustment Range	6 to 10 inches
Number of Items	4
Mounting Type	Bed Frame Mount
Manufacturer	Leggett & Platt

9. Warranty and Support

9.1 Warranty Information

This product is covered by a **Standard furniture warranty**. For specific details regarding coverage, duration, and terms, please refer to the warranty documentation provided with your original Leggett & Platt adjustable bed base or contact

Leggett & Platt customer service directly. Keep your proof of purchase for warranty claims.

9.2 Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact Leggett & Platt customer support. Contact information can typically be found on the manufacturer's official website or in the documentation accompanying your adjustable bed base.
When contacting support, please have the following information ready:

- Product Model: 4B8740
- Date of Purchase
- Description of the issue

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question