Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Elite Gourmet EHB-2425X

Elite Gourmet EHB-2425X Immersion Hand Blender User Manual

Model: EHB-2425X

Introduction

The Elite Gourmet EHB-2425X Immersion Hand Blender is designed for efficient blending, pureeing, mixing, and chopping. Its powerful 150-watt motor and one-touch control make it suitable for preparing a variety of foods, including soups, sauces, and baby food. The thoughtful "stick" design allows for direct blending in pots, bowls, or pitchers, simplifying your cooking process and reducing cleanup.

Safety Instructions

Please read all instructions carefully before using the Elite Gourmet EHB-2425X Immersion Hand Blender. Keep this manual for future reference.

- Always unplug the appliance from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the motor unit in water or other liquids. Only the detachable blending shaft is designed for immersion.
- Keep hands, hair, clothing, and utensils away from the blending shaft during operation to prevent injury and damage to the appliance.
- Avoid contact with moving parts.
- Do not operate the blender with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure the blending shaft is securely attached to the motor unit before use.
- Use caution when blending hot liquids to prevent splashing.
- Blades are sharp. Handle with care during assembly, disassembly, and cleaning.

Parts Identification

Familiarize yourself with the components of your immersion hand blender.

- **Motor Unit:** The main body containing the motor and control button.
- **Blending Shaft:** The detachable shaft with stainless steel blades at the end.
- **Power Cord:** For connecting to an electrical outlet.



Image: The Elite Gourmet EHB-2425X Immersion Hand Blender showing the main motor unit and the detachable blending rod. The detachable design facilitates easy cleaning.

Setup

Before first use, wash the detachable blending shaft in warm, soapy water, then rinse and dry thoroughly. Wipe the motor unit with a damp cloth.

1. Ensure the motor unit is unplugged from the power outlet.
2. Align the blending shaft with the motor unit.
3. Twist the blending shaft clockwise until it locks securely into place. You should hear a click or feel it firmly seated.
4. Your hand blender is now assembled and ready for use.

Your browser does not support the video tag.

Video: This official product summary video demonstrates the assembly and basic features of the Elite Gourmet Immersion Hand Blender, including how to attach the blending wand to the motor unit.

Operating Instructions

The Elite Gourmet EHB-2425X features a simple one-touch operation for ease of use.

1. Prepare your ingredients and place them in a suitable container (pot, bowl, or pitcher).
2. Plug the hand blender into a standard electrical outlet.
3. Immerse the blending shaft into the ingredients, ensuring the blades are fully submerged.
4. Press and hold the power button to activate the blender. Blend until desired consistency is achieved.
5. Release the power button to turn off the blender.
6. Unplug the appliance from the outlet after use.

Tips for Best Results:

- For optimal blending, use a container that is deep enough to prevent splashing.
- Move the blender up and down gently through the ingredients to ensure even blending.
- Avoid running the blender continuously for more than one minute to prevent overheating. Allow it to rest between cycles.
- The stainless steel blades are durable and stain-resistant, suitable for various blending tasks.



Image: The hand blender in use, demonstrating its ability to blend ingredients directly in a pot, cup, or bowl for convenience.



Image: A visual representation of the diverse applications of the hand blender, including preparing soups, baby food, smoothies, dips, sauces, and desserts.



Image: Key features of the hand blender, emphasizing its compact design, versatility, and ease of use, including pulse button control and easy cleaning.

Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your hand blender.

1. Always unplug the hand blender before cleaning.
2. Twist the blending shaft counter-clockwise to detach it from the motor unit.
3. The detachable blending shaft with blades is dishwasher-safe for easy cleanup. Alternatively, wash it by hand in warm, soapy water, then rinse thoroughly and dry.
4. Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water or any other liquid.
5. Ensure all parts are completely dry before reassembling or storing.

Your browser does not support the video tag.

Video: This official product summary video demonstrates the detachable wand feature, highlighting its dishwasher-safe design for easy

cleaning.

Troubleshooting

If you encounter issues with your Elite Gourmet EHB-2425X Immersion Hand Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet malfunction; blending shaft not securely attached.	Ensure the power cord is firmly plugged into a working outlet. Check if the blending shaft is correctly locked into the motor unit.
Motor stops during operation or smells burnt.	Overheating due to continuous use; ingredients too thick; motor overload.	Unplug the blender immediately. Allow it to cool down for at least 10-15 minutes. Reduce the amount or thickness of ingredients. Avoid continuous operation for more than one minute.
Ineffective blending.	Insufficient liquid; blades not fully submerged; ingredients too large.	Add more liquid to the mixture. Ensure the blending head is fully immersed. Cut larger ingredients into smaller pieces before blending.
Splashing during blending.	Container too shallow; blending head not fully submerged.	Use a deeper container. Ensure the blending head is fully submerged before starting.

Specifications

Detailed technical specifications for the Elite Gourmet EHB-2425X Immersion Hand Blender.

- **Model Number:** EHB-2425X
- **Brand:** Elite Gourmet
- **Power:** 150 Watts (Motor), 360 Watts (Total)
- **Voltage:** 120V
- **Control Type:** Push Button (One-Touch)
- **Number of Speeds:** 1
- **Material:** Aluminum (Container), Stainless Steel (Blade)
- **Color:** White
- **Product Dimensions:** 2.37"D x 2.37"W x 13.25"H
- **Item Weight:** 1.1 pounds
- **Special Feature:** Detachable Attachment
- **Material Type Free:** BPA Free





Image: The Elite Gourmet EHB-2425X Immersion Hand Blender with its key dimensions indicated for reference.

Warranty and Support

For warranty information or product support, please refer to the documentation included with your purchase or visit the official Elite Gourmet website. Keep your purchase receipt as proof of purchase for any warranty claims.

Contact Information:

- **Brand Website:** Elite Gourmet Store on Amazon (for general product information)
- Refer to your product packaging for specific customer service contact details.

© 2023 Elite Gourmet. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07D7PM5R4

More documents and user manuals: **https://manuals.plus/**