Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kobalt KRS 124B-03

Kobalt 24V MAX Brushless One-Handed Reciprocating Saw User Manual

Model: KRS 124B-03 | Brand: Kobalt

Introduction

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your Kobalt 24V MAX Brushless One-Handed Reciprocating Saw. Please read this manual thoroughly before operating the tool to ensure proper use and to prevent injury or damage.



Image Description: This image displays the Kobalt 24V MAX Brushless One-Handed Reciprocating Saw, still in its retail packaging. The saw is prominently featured, showcasing its blue and black design. The packaging highlights key features such as '24V MAX Brushless', 'MAX Speed', 'MAX Runtime', 'Low Vibration', and 'MAX Motor Life'. The box also indicates 'LITHIUM-ION' compatibility and a '5YR' tool warranty. The model is identified as a 'One-Handed Reciprocating Saw (Tool Only)'.

Important Safety Information

Always follow basic safety precautions when using power tools to reduce the risk of fire, electric shock, and personal injury.

- **Read All Instructions:** Familiarize yourself with the tool's operation and safety guidelines before use.
- **Wear Eye Protection:** Always wear safety goggles or safety glasses with side shields.
- **Wear Hearing Protection:** Use ear protection during extended periods of operation.
- **Keep Work Area Clean:** Cluttered areas and dark conditions invite accidents.
- **Avoid Dangerous Environments:** Do not use power tools in damp or wet locations, or expose them to rain.
- **Prevent Accidental Starting:** Ensure the switch is in the off-position before connecting to a battery pack, picking up or carrying the tool.
- **Use the Right Tool:** Do not force the tool; use the correct tool for your application.
- **Secure Workpiece:** Always clamp or secure the workpiece to a stable platform.
- **Maintain Tools with Care:** Keep cutting tools sharp and clean for better and safer performance.
- **Disconnect Power:** Remove the battery pack from the tool before making any adjustments, changing accessories, or storing the tool.

Package Contents

Verify that all items listed below are included in your package:

- Kobalt 24V MAX Brushless One-Handed Reciprocating Saw (Bare Tool)
- Instruction Manual

Note: Battery pack and charger are sold separately.

Setup

Battery Installation and Removal

1. **To Install Battery:** Align the battery pack with the battery port on the tool. Slide the battery into the port until it clicks securely into place. Ensure it is fully seated.
2. **To Remove Battery:** Press the battery release button located on the battery pack. While holding the button, slide the battery pack out of the tool.

Blade Installation and Removal

WARNING: Always ensure the tool is OFF and the battery pack is removed before installing or removing blades.

1. **To Install Blade:**
    - Lift the blade clamp lever located on the front of the tool.
    - Insert the saw blade fully into the blade clamp opening.
    - Release the blade clamp lever. The blade should be securely locked in place. Gently tug on the blade to confirm it is secure.
2. **To Remove Blade:**
    - Lift the blade clamp lever.
    - Pull the saw blade out of the clamp opening.
    - Release the blade clamp lever.

Operating Instructions

1. **Starting and Stopping the Tool:**
   - To start the tool, depress the variable-speed trigger.
   - To stop the tool, release the variable-speed trigger.
2. **Variable Speed Control:** The tool features a variable-speed trigger, allowing you to control the strokes per minute (SPM) from 0 to 3,000 SPM. Apply more pressure to the trigger for higher speed, and less pressure for lower speed. This provides precise control for various materials and applications.
3. **Cutting Operation:**
   - Ensure the appropriate blade is installed for the material you intend to cut.
   - Hold the tool firmly with one hand, maintaining a secure grip.
   - Place the shoe plate firmly against the workpiece.
   - Start the tool by depressing the trigger before making contact with the material.
   - Apply steady, even pressure. Allow the blade to do the cutting; do not force the tool.
   - For plunge cutting (cutting directly into the material without a pilot hole), ensure the blade is sharp and the material is suitable for this technique.
4. **Built-in LED Light:** The integrated LED light illuminates the work area, providing improved visibility in low-light conditions. It activates automatically when the trigger is depressed.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your tool.

- **Cleaning:** Keep the tool's ventilation openings clear and free of debris. Use a soft, damp cloth to clean the exterior. Do not use harsh chemicals or abrasive cleaners.
- **Blade Care:** Always use sharp, undamaged blades. Replace dull or bent blades promptly to ensure efficient cutting and prevent strain on the tool.
- **Storage:** Store the tool in a dry, secure location, out of reach of children. Remove the battery pack from the tool before storing for extended periods.
- **Inspection:** Periodically inspect the tool for any signs of damage, loose screws, or worn components. If any issues are found, have the tool serviced by a qualified technician.

Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Tool does not start.	Battery pack is not charged.	Recharge the battery pack.
	Battery pack is not properly inserted.	Ensure the battery pack is fully seated and clicks into place.
	Trigger is not fully depressed.	Depress the variable-speed trigger fully.
Reduced cutting performance or overheating.	Blade is dull or damaged.	Replace with a sharp, new blade.

Problem	Possible Cause	Solution
	Tool is being forced or overloaded.	Reduce pressure and allow the tool to work at its own pace.
	Battery charge is low.	Recharge the battery pack.

Specifications

Feature	Detail
Brand	Kobalt
Model Number	KRS 124B-03
Power Source	Battery Powered
Voltage	24 Volts MAX
Motor Type	Brushless
Strokes Per Minute (SPM)	0-3,000 (Variable Speed)
Blade Material Compatibility	High Speed Steel (HSS) and other standard reciprocating saw blades
Tool Weight	Approximately 3.7 lbs (bare tool)
Special Features	Tool-free blade change, Built-in LED light, Ergonomic design
Included Components	Bare Tool (Battery and charger sold separately)

Warranty and Support

Warranty: This Kobalt 24V MAX Brushless One-Handed Reciprocating Saw is covered by a 5-year limited warranty. This warranty covers defects in material and workmanship. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, refer to the documentation included with your original purchase or visit the official Kobalt website.
Customer Support: For technical assistance, replacement parts, or any questions regarding your product, please contact Kobalt customer service. Contact information can typically be found on the Kobalt official website or on your product packaging.

© 2023 Kobalt. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DD4K2KW

More documents and user manuals: **https://manuals.plus/**