Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cylewet CLT1033

Cylewet CLT1033 Soil Moisture Sensor Module Instruction Manual

1. Introduction

This manual provides comprehensive instructions for the Cylewet CLT1033 Soil Moisture Sensor Module. Please read carefully before use to ensure proper installation, operation, and maintenance of your sensor.


2. Product Overview

The Cylewet CLT1033 is a resistive soil moisture detection module designed for use with microcontrollers like Arduino. It measures the volumetric water content in soil by detecting the electrical conductivity between its two probes. This sensor is ideal for projects requiring automatic watering systems or environmental monitoring. The sensor features a gilt surface on its probes for improved conductivity and enhanced corrosion resistance, contributing to a longer lifespan.

Package Contents:

- 2 x Cylewet CLT1033 Soil Moisture Sensor Modules

Product Images:



Front view of the Cylewet CLT1033 Soil Moisture Sensor Module, showing the electronic board with pins and the two conductive probes.



Angled view of the Cylewet CLT1033 Soil Moisture Sensor Module, highlighting the connection pins and the design of the probes.



Side view of the Cylewet CLT1033 Soil Moisture Sensor Module, showing the thickness of the board and the gilt surface on the probes.

3. Setup

The CLT1033 sensor operates on a voltage range of 3.3V to 5V. Follow these steps to connect and prepare your sensor for use:

Wiring Connections:

Connect the sensor to your microcontroller (e.g., Arduino) using the following pin assignments:

- **VCC:** Connect to the 3.3V or 5V power supply output of your microcontroller.
- **GND:** Connect to the Ground (GND) pin of your microcontroller.
- **S (Signal):** Connect to an analog input pin on your microcontroller (e.g., A0 on Arduino).

Sensor Placement:

Insert the two-pronged probe portion of the sensor into the soil to the desired depth. It is crucial to ensure that the electronic module (the top part of the sensor with the pins and components) remains above the soil and is not exposed to moisture or water. Exposure of the electronic module to moisture can damage the sensor and lead to inaccurate readings.

4. Operating Instructions

Once properly connected and placed, the CLT1033 sensor will provide an analog output signal that varies with the soil moisture level. This analog value can be read by your microcontroller and used to determine the soil's humidity.

Basic Operation:

1. **Power On:** Ensure your microcontroller and the connected sensor are powered on.
2. **Read Analog Value:** Use your microcontroller's Analog-to-Digital Converter (ADC) to read the analog value from the pin connected to the sensor's 'S' output.
3. **Interpret Readings:**
    - *Dry Soil:* Typically results in a high analog value (e.g., close to 1023 on a 10-bit ADC).
    - *Wet Soil:* Typically results in a low analog value (e.g., close to 0 on a 10-bit ADC).
4. **Calibration:** It is recommended to calibrate the sensor for your specific soil type and application. Soil composition, density, and the presence of fertilizers can affect readings. Perform readings in known dry and wet soil conditions to establish appropriate thresholds for your project.
5. **Automated Actions:** Based on the calibrated moisture levels, you can program your microcontroller to trigger actions, such as activating a water pump for automatic plant irrigation.

5. Maintenance

Proper maintenance will help ensure accurate readings and extend the operational life of your soil moisture sensor.

- **Protect Electronics:** Always keep the electronic module (the top part with components and pins) dry and away from direct contact with water or excessive humidity.
- **Clean Probes:** Periodically remove the sensor from the soil and gently clean the probes to remove any accumulated soil, mineral deposits, or corrosion. Buildup on the probes can significantly affect reading accuracy.
- **Storage:** When not in use, store the sensor in a dry, clean environment to prevent damage and corrosion.
- **Corrosion Resistance:** While the gilt surface enhances corrosion resistance, resistive sensors can still be susceptible to electrolysis and degradation over long periods of continuous DC current. For extended lifespan, consider pulsing the power to the sensor rather than keeping it continuously powered, if your application allows.

6. Troubleshooting

If you encounter issues with your Cylewet CLT1033 Soil Moisture Sensor, refer to the following troubleshooting tips:

No Reading or Inaccurate Readings:

- **Wiring Check:** Double-check all wiring connections (VCC, GND, Signal) to ensure they are secure, correctly connected to the appropriate pins on your microcontroller, and free from shorts.
- **Power Supply:** Verify that the power supply voltage (3.3V or 5V) to the sensor is stable and within the

specified operating range.

- **Probe Cleanliness:** Ensure the sensor probes are clean and free of any soil, rust, or other debris that could impede conductivity.
- **Calibration:** Recalibrate the sensor for your specific soil type. Readings can vary significantly between different soil compositions.
- **Electrolysis/Corrosion:** If the sensor has been continuously powered for a long time, the probes might have degraded due to electrolysis. Inspect the probes for visible damage. Consider implementing pulsed power to the sensor in your code to mitigate this issue.

Sensor Not Responding:

- **Microcontroller Input:** Confirm that the microcontroller's analog input pin is correctly configured and capable of reading values. Test the pin with a simple voltage divider circuit to ensure it is functioning.
- **Sensor Damage:** If all connections and software are verified, the sensor itself might be faulty. Test with another sensor if available.

7. Specifications

Feature	Specification
Model Number	CLT1033
Dimensions	20mm x 60mm (0.79 inches x 2.36 inches)
Operating Voltage	3.3V - 5V DC
Operating Current	<20mA
Output Type	Analog
Probe Surface	Gilt (Gold Plated)
Manufacturer	Qianxin

8. Warranty Information

This product is typically covered by a standard manufacturer's warranty against defects in materials and workmanship. The duration and terms of the warranty may vary. Please refer to your purchase documentation, the retailer's website, or contact the seller directly for specific warranty terms and conditions applicable to your purchase.

9. Support

For technical assistance, inquiries regarding product functionality, or troubleshooting beyond the scope of this manual, please utilize the following resources:

- **Retailer Support:** Contact the retailer from whom you purchased the product. They can often provide initial support or direct you to the appropriate manufacturer channels.
- **Online Communities:** For integration with microcontrollers like Arduino, numerous online forums and communities (e.g., Arduino official forums, Stack Exchange) offer extensive resources, example code, and peer support.

- **Manufacturer Information:** While specific manufacturer contact details are not provided here, searching for 'Qianxin' or 'Cylewet' online may lead to official support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DDJ7K9J

More documents and user manuals: **https://manuals.plus/**