Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TWTADE WH138 500 ohm

TWTADE WH138 500 ohm Potentiometer Instruction Manual

Model: WH138 500 ohm

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your TWTADE WH138 500 ohm single turn rotary linear variable potentiometer. Please read this manual thoroughly before use to ensure optimal performance and safety.

2. Product Features

- Product Type: Rotary Potentiometer
- Model: WH138 500 ohm
- Resistance Value: 500 ohm
- Type: Single Turn Rotary Linear Variable Potentiometer
- Includes: 3 potentiometers and 3 black aluminum alloy knobs
- Potentiometer Body Size: 24 x 10mm (Diameter x Height)
- Potentiometer Total Height: 26mm
- Screw Thread Diameter: 8mm
- Shaft Diameter: 6mm
- Shaft Length: 8mm
- Rotary Knob Size: 17 x 21mm (Height x Max. Diameter)
- Rated Power (Linear taper B): 0.5W
- Rated Power (Other Tapers): 0.25W
- Switch Circuit: S.P.S.T.
- Rated Power (Switch): 1A at AC/DC 125V
- Rotational Life (Potentiometer): 10,000 Cycles
- Rotational Life (Joystick): 100,000 Cycles Min.
- Material: Carbon

3. Product Components




Image 3.1: Overview of three TWTADE WH138 500 ohm potentiometers and their corresponding black aluminum alloy knobs.



Image 3.2: A potentiometer with a knob installed, alongside a separate potentiometer and knob, illustrating how they fit together.



Image 3.3: The splined shaft of the potentiometer and the matching internal structure of the knob for secure attachment.

4. Installation and Setup

Potentiometers are variable resistors commonly used to control electrical signals such as volume, tone, or brightness. Proper installation is crucial for functionality and safety.

4.1. Safety Precautions

- Always disconnect power to the circuit before installing or replacing components.
- Ensure proper soldering techniques are used to prevent cold joints or short circuits.
- Verify the potentiometer's specifications (resistance, power rating) match your circuit requirements.

4.2. Wiring a Potentiometer

A typical potentiometer has three terminals:

1. **Terminal 1 (End Terminal)**: Connect to one end of the voltage source or signal input.

2. **Terminal 2 (Wiper)**: This is the output terminal. Its resistance varies as the shaft is rotated.
3. **Terminal 3 (End Terminal)**: Connect to the other end of the voltage source or ground.

For variable resistance applications (e.g., current limiting), you can use only two terminals: one end terminal and the wiper. For voltage divider applications (e.g., volume control), all three terminals are typically used.

4.3. Mounting the Potentiometer

1. Drill an 8mm diameter hole in the panel where the potentiometer will be mounted.
2. Insert the potentiometer shaft through the hole.
3. Secure the potentiometer with the provided nut and washer on the front side of the panel.
4. Press the black aluminum alloy knob onto the splined shaft until it is firmly seated.



Image 4.1: Potentiometer with mounting hardware (washer and nut).

5. Operation

Once installed and wired correctly, the potentiometer operates by rotating the attached knob. This rotation moves the wiper contact along the resistive track, changing the resistance between the wiper and the two end terminals.

- **Clockwise Rotation**: Typically increases the resistance between Terminal 1 and the wiper, and decreases resistance between the wiper and Terminal 3.
- **Counter-Clockwise Rotation**: Typically decreases the resistance between Terminal 1 and the wiper, and increases resistance between the wiper and Terminal 3.

The specific effect of rotation depends on how the potentiometer is wired into the circuit (e.g., as a rheostat or voltage divider).

6. Maintenance

Potentiometers are generally low-maintenance components. However, certain practices can extend their lifespan and ensure reliable operation:

- **Keep Clean**: Avoid exposing the potentiometer to dust, dirt, or moisture, which can degrade the resistive track and wiper contact.
- **Avoid Excessive Force**: Do not apply excessive rotational force to the knob, as this can damage the internal mechanism or shaft.
- **Regular Inspection**: Periodically check wiring connections for looseness or corrosion.
- **Storage**: Store unused potentiometers in a dry, clean environment.

7. Troubleshooting

If you encounter issues with your potentiometer, consider the following troubleshooting steps:

- **No Change in Resistance/Output**:
  - Check all wiring connections for continuity and proper soldering.
  - Ensure the wiper terminal is correctly connected.
  - Verify the potentiometer is not damaged internally (e.g., broken resistive track).
- **Intermittent or Scratchy Sound (in audio applications)**:
  - This often indicates a dirty or worn resistive track. Cleaning with a specialized electronic contact cleaner may help, but replacement is often the best solution for severe cases.
- **Resistance Value Incorrect**:
  - Use a multimeter to measure the resistance across the end terminals (should match the rated value) and between an end terminal and the wiper as you rotate the shaft.
  - Ensure you have selected the correct resistance value for your application.
- **Knob Loose or Not Turning**:
  - Ensure the mounting nut is tightened securely.
  - Check if the knob is properly seated on the splined shaft.
  - If the shaft itself is stiff or broken, the potentiometer may need replacement.

8. Specifications

Attribute	Value
Product Name	Potentiometer
Model	WH138 500 ohm
Type	Rotary Potentiometer
Potentiometer Body Size	24 x 10mm (D * H)
Potentiometer Total Height	26mm
Screw Thread Diameter	8mm
Shaft Diameter	6mm
Shaft Length	8mm
Rotary Knob Size	17 x 21mm (H * Max. D)
Rated Power (Linear taper B)	0.5W
Rated Power (Other Tapers)	0.25W
Switch Circuit	S.P.S.T
Rated Power (Switch)	1A at AC/DC 125V
Rotational Life (Potentiometer)	10,000 Cycles
Rotational Life (Joystick)	100,000 Cycles Min.
Item Weight	1.76 ounces (for 3 pieces)
Material	Carbon
Manufacturer	TWTADE

9. Contact and Support

For further assistance or inquiries regarding your TWTADE potentiometer, please refer to the official TWTADE store or contact their customer support channels.
Official TWTADE Store: TWTADE Store on Amazon

© 2025 TWTADE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DHG7WNJ

More documents and user manuals: **https://manuals.plus/**