Razer RZ03-01870200-R3U1

Razer Huntsman Elite Gaming Keyboard Instruction Manual

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Razer Huntsman Elite Gaming Keyboard. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

What's in the Box

- Razer Huntsman Elite Keyboard
- Magnetic Plush Wrist Rest
- Important Product Information Guide (not included in this digital manual)

Setup

1. Connecting the Keyboard

Connect the keyboard's USB cable to an available USB port on your computer. The keyboard is plug-and-play, but for full functionality and customization, software installation is recommended.

2. Attaching the Magnetic Plush Wrist Rest

Align the magnetic connectors on the wrist rest with the corresponding points at the bottom front edge of the keyboard. The wrist rest will snap into place securely. This provides ergonomic support and extends the Chroma RGB lighting.



Image: The Razer Huntsman Elite Gaming Keyboard with its magnetic plush wrist rest, showcasing the integrated RGB lighting effects.

3. Software Installation (Razer Synapse 3)

For advanced customization, including RGB lighting effects, key remapping, and macro creation, download and install Razer Synapse 3 from the official Razer website. Follow the on-screen instructions for installation and setup.

Operating the Keyboard

Razer Opto-Mechanical Switches

The Razer Huntsman Elite features Opto-Mechanical switches, which utilize optical technology for rapid actuation. Each keypress is registered with light-based actuation, providing a fast and precise response with a satisfying clicky feedback.

Razer Chroma RGB Lighting

The keyboard offers 16.8 million customizable color options for individual key backlighting and underglow. Use Razer Synapse 3 to personalize lighting effects, sync with other Razer Chroma-enabled devices, and integrate with supported games.



Image: A detailed view of the Razer Huntsman Elite's keys and the vibrant underglow, demonstrating the extensive Chroma RGB lighting capabilities.

Multi-Function Digital Dial and Media Keys

Located on the top right of the keyboard, the multi-function digital dial and dedicated media keys provide quick access to volume control, track skipping, and other programmable functions. These can be customized via Razer Synapse 3.



Image: A close-up shot of the multi-function digital dial and media control buttons, showing their textured surface and illuminated icons.

Razer Hypershift for Macro Support

Razer Hypershift allows you to assign secondary functions to any key, accessible by holding down a designated Hypershift key. This enables complex macro execution and expanded control options.

Ergonomic Magnetic Wrist Rest

The included plush leatherette wrist rest attaches magnetically, providing comfort during extended use. It also features integrated underglow lighting that syncs with the keyboard's Chroma effects.



Image: The Razer Huntsman Elite keyboard paired with its ergonomic magnetic wrist rest, both displaying synchronized RGB lighting, set up on a desk.

Maintenance

Cleaning the Keyboard

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keycaps and chassis.
- Avoid excessive moisture and do not spray cleaners directly onto the keyboard.
- Use compressed air to remove dust and debris from between the keys.

Wrist Rest Care

Wipe the plush leatherette wrist rest with a soft, damp cloth. Avoid harsh chemicals or abrasive materials that could damage the surface.

Troubleshooting

Keyboard Not Responding

- Ensure the USB cable is securely connected to your computer.
- Try connecting the keyboard to a different USB port.
- Restart your computer.
- Check if Razer Synapse 3 is running and updated.

Lighting Issues

- Verify that Razer Synapse 3 is installed and updated.
- Check lighting settings within Razer Synapse 3 to ensure effects are enabled.
- Ensure the wrist rest is properly attached for its underglow lighting to function.

Keys Not Registering or Double-Typing

- Clean the affected key to remove any debris.
- Update Razer Synapse 3 and keyboard firmware.
- If the issue persists, contact Razer Support.

Specifications

- **Model Number:** RZ03-01870200-R3U1
- **Switch Type:** Razer Opto-Mechanical (Clicky Optical Switch)
- **Connectivity:** Wired - Attached USB
- **Lighting:** Razer Chroma RGB (16.8 million customizable colors, individual key backlighting, underglow)
- **Wrist Rest:** Magnetic Plush Leatherette with Underglow
- **Media Controls:** Multi-function Digital Dial, Dedicated Media Keys
- **Macro Support:** Fully Programmable with Razer Hypershift
- **Construction:** Quality Aluminum Top Frame
- **Keycaps:** Regular ABS
- **Durability:** Up to 100 million keystrokes
- **Dimensions (L x W x H):** Approximately 17.64 x 9.22 x 1.42 inches (44.8 x 23.4 x 3.6 cm)
- **Weight:** Approximately 3.76 pounds (1.71 kg)
- **Compatible Devices:** PC

Warranty and Support

Manufacturer's Warranty

The Razer Huntsman Elite Gaming Keyboard comes with a 2-year manufacturer warranty. Please retain your proof of purchase for warranty claims.

Technical Support

For further assistance, technical support, or warranty inquiries, please visit the official Razer support website or contact their customer service directly. You can find detailed support resources, FAQs, and contact information on their website.
Online Support: www.razer.com/support

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question