Ikea 402.680.06

IKEA Silveran Leg User Manual

Model: 402.680.06 | Brand: Ikea

Introduction

The IKEA Silveran adjustable legs are designed to provide stable and versatile support for various furniture pieces, particularly kitchen cabinets and bathroom furniture. This manual provides essential information regarding assembly, safe operation, maintenance, and product specifications to ensure optimal performance and longevity of your Silveran legs.

Safety Information

Important Safety Precautions:

- Always ensure legs are securely fastened to the furniture piece to prevent tipping.
- Tighten screws regularly to maintain stability.
- Do not adjust leg height while furniture is in use or under load.
- Ensure the furniture is level after installation to prevent uneven stress on the legs.

Product Overview

The IKEA Silveran legs are adjustable furniture supports, sold in a pack of two. They feature a robust steel construction with an epoxy/polyester powder coating for durability and a grey finish. The adjustable foot is made of polyamide, designed to protect against wet floors and increase stability.



Image: Two IKEA Silveran adjustable furniture legs, showing their design and adjustable foot.

Product Dimensions:

- Min. height: 11.5 cm (4 1/2 ")
- Max. height: 17 cm (6 3/4 ")
- Package quantity: 2 pack

Setup and Installation

The IKEA Silveran legs require assembly and are designed for screw-in installation. Follow these general steps for proper setup:

1. Identify the designated mounting points on your furniture piece. Ensure the surface is clean and free of debris.
2. Position the leg bracket flush against the furniture's base, aligning the screw holes.
3. Securely fasten the leg using appropriate screws (not included, typically provided with the furniture piece). Ensure all screws are tightened to prevent wobbling.
4. Once all legs are attached, carefully turn the furniture upright.
5. Adjust the height of each leg by rotating the lower cylindrical part until the furniture is level and stable. Refer to the 'Operating' section for detailed adjustment instructions.



Image: A hand demonstrating the adjustment of an IKEA Silveran leg on a cabinet, highlighting the adjustable mechanism.



Image: IKEA Silveran legs supporting various pieces of bathroom furniture, illustrating their application and aesthetic integration.

Operating

The Silveran legs feature adjustable feet designed to increase stability and provide protection against wet floors. To adjust the height:

- Ensure the furniture is not under heavy load or in use before attempting to adjust the leg height.
- Grasp the lower cylindrical part of the leg and rotate it clockwise to decrease the height or counter-clockwise to increase the height.
- Adjust each leg individually until the furniture is level and stable on the floor.
- Periodically check the stability and re-adjust if necessary.

Maintenance

Proper care will help maintain the appearance and functionality of your Silveran legs:

- Wipe clean using a damp cloth and a mild cleaner.
- Wipe dry immediately with a clean, dry cloth to prevent water spots or corrosion.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.

- Regularly check the tightness of the screws securing the legs to the furniture and tighten if loose.

Troubleshooting

If you encounter issues with your Silveran legs, consider the following:

- **Wobbling Furniture:** Ensure all legs are securely fastened and adjusted to the same height. Check the floor surface for unevenness.
- **Difficulty Adjusting Height:** Ensure the leg is clean and free of debris. If the mechanism is stiff, a small amount of silicone spray (avoiding contact with furniture surfaces) might help, but generally, they should adjust smoothly.
- **Legs Not Holding Position:** Re-tighten the adjustable foot. If the issue persists, inspect for damage to the internal threading.

Specifications

Attribute	Detail
Model Number	402.680.06
Brand	Ikea
Colour	Grey
Material	Steel (Leg/Bracket), Polyamide (Foot)
Style	Contemporary
Shape	Rectangular (Bracket), Cylindrical (Leg)
Number of Pieces	2
Installation Type	Screw-In
Leg Style	Straight, Adjustable
Recommended Uses	Indoor, Heavy-duty, Kitchen & Dining, Living Room
Specific Uses	Kitchen cabinets, Bathroom furniture

Warranty Information

For specific warranty details regarding your IKEA Silveran legs, please refer to the original purchase documentation or visit the official IKEA website. Warranty terms and conditions may vary by region and purchase date.

Customer Support

If you require further assistance, have questions not covered in this manual, or need to report a defect, please contact IKEA customer service. You can find contact information on the official IKEA website or by visiting your local IKEA store.

© 2023 Ikea. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question