Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Keurig K-Mini Plus

Keurig K-Mini Plus Single Serve Coffee Maker Instruction Manual

Model: K-Mini Plus

Introduction

This manual provides essential instructions for the safe and efficient use of your Keurig K-Mini Plus Single Serve Coffee Maker. Designed for convenience and compact spaces, this brewer delivers fresh, delicious coffee from K-Cup pods in minutes. Please read all instructions carefully before first use and retain for future reference.



Figure 1: Keurig K-Mini Plus Coffee Maker Overview

Setup

1. **Unpack:** Remove all packaging materials and tape from the coffee maker.
2. **Place:** Position the coffee maker on a stable, level surface.
3. **Clean Reservoir:** Wash the removable water reservoir with warm, soapy water, then rinse thoroughly.
4. **Fill Reservoir:** Fill the removable water reservoir with fresh water up to the MAX fill line.
5. **Power On:** Plug the coffee maker into a grounded outlet. The power button will illuminate.
6. **First Brew (Cleansing Brew):** Place a large mug (at least 10 oz) on the drip tray. Lift and lower the handle to close the K-Cup pod holder. Press the brew button. Do not insert a K-Cup pod for this initial cleansing brew. Discard the hot water.



Figure 2: Removable Water Reservoir



Figure 3: Cord Storage for Tidy Countertops

Your browser does not support the video tag.

Video 1: Demonstrating water addition and brewing process.

Operating Instructions

1. **Add Water:** Pour fresh water into the removable reservoir for each brew. The amount of water added will determine the brew size (6-12 oz).
2. **Insert K-Cup Pod:** Lift the handle and place a K-Cup pod into the K-Cup pod holder. Lower the handle

completely to close the lid.

3. **Select Brew Strength (Optional):** For a stronger, more intense cup, press the "STRONG" button located next to the power button. The indicator light will illuminate.
4. **Place Mug:** Place a mug on the drip tray. If using a travel mug up to 7.0 inches tall, remove the drip tray.
5. **Brew:** Press the illuminated brew button. The light will flash while brewing and remain solid when complete.
6. **Enjoy:** Your coffee is ready. The brewer will automatically turn off 90 seconds after the last brew to save energy.



Figure 4: Strong Brew Option



Figure 5: Brew Size Indication



Figure 6: Travel Mug Friendly Design

The K-Mini Plus also includes a convenient pod storage unit that holds up to 9 K-Cup pods and fits inside the brewer for ultimate portability and counter space saving.



Figure 7: Integrated Pod Storage

Maintenance

Cleaning

- **Drip Tray:** The drip tray can hold an accidental overflow. Remove and wash it with warm, soapy water.
- **Water Reservoir:** Clean the removable water reservoir regularly with warm, soapy water and rinse thoroughly.
- **K-Cup Pod Holder:** Remove the K-Cup pod holder and wash it with warm, soapy water. Ensure the exit needle is clear.
- **Exterior:** Wipe the exterior of the brewer with a damp cloth.

Descaling

Mineral deposits can build up in your coffee maker over time, affecting performance. Descale your brewer every 3 to 6 months, or more frequently if you have hard water. Refer to the official Keurig descaling solution instructions or use a vinegar solution:

1. Empty the water reservoir.
2. Fill the reservoir halfway with white vinegar and the rest with water.
3. Place a large mug on the drip tray (without a K-Cup pod).
4. Run several brew cycles until the reservoir is empty.
5. Rinse the reservoir and fill with fresh water. Run several fresh water cycles to flush out any vinegar residue.



Figure 8: Keurig Descaling Solution (sold separately)

Troubleshooting

Problem	Possible Cause	Solution
Brewer does not turn on.	Not plugged in; power outage.	Ensure the brewer is securely plugged into a grounded outlet. Check the circuit breaker.
No water or partial brew.	Insufficient water in reservoir; mineral buildup; clogged needles.	Ensure enough water is added for the desired brew size. Perform descaling. Clean the K-Cup pod holder and check for clogged needles.
Water overflowing from reservoir.	Clogged internal components.	This indicates a severe clog. Perform descaling immediately. If the issue persists, contact Keurig Customer Service.
Coffee grounds in cup.	K-Cup pod not seated correctly; exit needle clogged.	Ensure the K-Cup pod is properly inserted. Clean the K-Cup pod holder and exit needle.

Specifications

Brand: Keurig

Model Name: K-Mini Plus Maker

Model Number: K-Mini Plus (5000200240)

Dimensions (D x W x H): 4.5" x 11.3" x 12.1" (16.8" H with handle open)

Weight: 6.4 pounds

Capacity: Single-serve (6-12 ounces per brew)

Voltage: 120 volts

Wattage: 1500 watts

Compatible Pods: K-Cup pods

Special Features: Portable, Removable Tank, Strong Brew, Cord Storage, Travel Mug Friendly



Figure 9: Product Dimensions

Warranty and Support

For warranty information, product registration, and customer support, please visit the official Keurig website or refer to the documentation included with your product. You can also find additional resources and contact information on the Keurig Store on Amazon.

User Guide (PDF): Download

User Manual (PDF): Download

© 2024 Keurig. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DR69VLJ

More documents and user manuals: **https://manuals.plus/**