Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Seiko QXM379SRH

Seiko Melodies in Motion Wall Clock

MODEL QXM379SRH INSTRUCTION MANUAL

Product Overview

The Seiko Melodies in Motion Wall Clock, Model QXM379SRH, is an analog wall clock designed to provide both timekeeping and musical entertainment. On the hour, the clock's face opens to reveal a decorative turning wheel adorned with Swarovski crystals, accompanied by one of eighteen selectable Hi-Fi melodies. This clock features a metallic silver case, a glass enclosure, and a pendulum with Swarovski crystals. It includes a demonstration button, volume control, and an off/on switch for the melodies.



Figure 1: Front view of the Seiko Melodies in Motion Wall Clock (QXM379SRH).

Package Contents

Verify that all items are present in the package:

- Seiko Melodies in Motion Wall Clock (Model QXM379SRH)
- 4 x C Batteries
- Instruction Manual (this document)

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert 4 C batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Figure 2: Rear view of the clock with battery compartment and controls.

2. Setting the Time

1. Turn the time setting knob, usually located on the back of the clock, to set the correct time.
2. Ensure the clock hands move smoothly.

3. Mounting the Clock

The clock is designed for wall mounting. Use a sturdy screw or hook appropriate for the clock's weight (approximately 5.6 pounds or 2.5 kg) and wall material.

1. Select a suitable location on a wall, ensuring it is level and secure.
2. Install a wall anchor and screw, leaving a small portion of the screw head exposed.
3. Align the clock's hanging slot (located on the back) with the screw head and carefully hang the clock.
4. Verify the clock is securely mounted and level.



Figure 3: Side profile of the clock, illustrating its depth.

Operating Instructions

Melody Playback

The clock plays one of its melodies on the hour. During playback, the clock face opens, and the decorative wheel with Swarovski crystals rotates.



Figure 4: Clock face in open position during melody playback.

Volume Control

A volume control knob or switch is located on the back of the clock. Adjust it to your preferred sound level.

Melody Selection

The clock offers three sets of melodies. A selector switch on the control panel (typically on the back) allows you to choose

between these sets:

- **Set 1 (Classical):** The Four Seasons "Spring," Kanon, Eine Kleine Nachtmusik, Symphony No. 6 "Pastoral," "Morning" From Peer Gynt, La Traviata "Drinking Song."
- **Set 2 (Popular/Hymns):** Amazing Grace, The Planets "Jupiter," Waltz Of The Flowers, Salut d'Amour, Pictures At An Exhibition "Promenade," Dance Of The Reed Pipes.
- **Set 3 (Christmas):** Deck The Halls, O Tannenbaum, We Wish You A Merry Christmas, Joy To The World, Silent Night, Jingle Bells.

Demonstration Button

Press the demonstration button (located on the back or side) to play a melody and observe the motion sequence without waiting for the top of the hour.

Melody On/Off Switch

Use the On/Off switch to enable or disable the hourly melodies and motion. The clock will continue to keep time even when the melodies are off.

Maintenance

Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the finish and internal components.

Battery Replacement

Replace all 4 C batteries annually or when the melodies become faint, the motion slows, or the clock stops keeping accurate time. Always replace all batteries at once with new ones of the same type.

Troubleshooting

Problem	Possible Cause	Solution
Clock does not operate.	Batteries are incorrectly installed or depleted.	Check battery polarity. Replace all 4 C batteries with new ones.
Melodies do not play.	Melody On/Off switch is set to Off. Volume is too low. Light sensor is active in a dark room.	Ensure the melody switch is On. Increase volume. Ensure the clock is in a sufficiently lit area or disable the light sensor if applicable (refer to specific model features).
Motion mechanism is not working.	Batteries are low. Obstruction in the mechanism.	Replace batteries. Gently check for any visible obstructions. Do not force moving parts.
Time is inaccurate.	Low batteries. Incorrect time setting.	Replace batteries. Reset the time using the setting knob.

Specifications

Feature	Detail
Model Number	QXM379SRH

Feature	Detail
Dimensions (W x H x D)	Approximately 17.44" x 15.94" x 3.82" (44.3 cm x 40.5 cm x 9.7 cm)
Weight	Approximately 5.6 pounds (2.5 kg)
Power Source	4 x C Batteries (included)
Display Type	Analog
Special Features	Melodies in Motion, Swarovski Crystals, Adjustable Volume, Light Sensor (for melody activation)
Case Material	Plastic

Warranty and Support

Warranty Information

Seiko guarantees the workmanship and material quality of this product for**one year** from the date of purchase, under normal use conditions. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Seiko customer support. Refer to the official Seiko website or product packaging for the most current contact information.
You can also visit the official Seiko Store on Amazon for additional product information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DRRJHXY

More documents and user manuals: **https://manuals.plus/**