Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kobalt KOC 4024A-03

Kobalt 2-Piece 24-volt Cordless Power Equipment Combo Kit User Manual

Model: KOC 4024A-03

1. Product Overview

The Kobalt 24-Volt max leaf Blower and string trimmer Combo kit is designed to help maintain your yard efficiently. This kit includes a string trimmer with a 12-inch cutting swath and dual line feed for increased cutting efficiency, featuring a bump head for easy line advancement. The leaf blower utilizes a turbine fan to produce 410 CFM, effectively clearing fallen leaves and debris. Its removable tube allows for convenient storage. Both tools are powered by an interchangeable 24-Volt battery, offering lasting power and run time, and are equipped with high-efficiency brushless motors for enhanced durability. Variable speed triggers on both tools provide precise control for various tasks, simplifying outdoor chores.



Figure 1: Kobalt 2-Piece 24-volt Cordless Power Equipment Combo Kit components.

2. Safety Information

Always read and understand all safety warnings and instructions before operating this product. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- **Wear appropriate personal protective equipment (PPE):** Always wear eye protection (safety glasses), hearing protection, and heavy-duty gloves when operating the tools.
- **Keep work area clear:** Ensure the area is free of bystanders, children, and pets. Remove any objects that could be thrown by the tools.
- **Inspect tools before use:** Check for loose parts, damage, or any conditions that may affect safe operation. Do not use if damaged.
- **Use the correct battery and charger:** Only use Kobalt 24-volt batteries and chargers specified for this product.
- **Avoid wet conditions:** Do not operate in rain or wet conditions to prevent electric shock.
- **Secure grip:** Always maintain a firm grip on the tool handles during operation.
- **Proper storage:** Store tools and batteries in a dry, secure location away from children and heat sources.

3. Package Contents

Verify that all items listed below are included in your package:

- Kobalt 24-Volt Max String Trimmer
- Kobalt 24-Volt Max Leaf Blower
- Kobalt 24-Volt Lithium-Ion Battery (1 required)
- Kobalt 24-Volt Battery Charger
- String Trimmer Guard
- Leaf Blower Tube
- Operator's Manual

4. Setup

4.1 Battery Charging

1. Connect the charger to a standard electrical outlet.
2. Slide the 24-Volt battery into the charger until it clicks into place.
3. Allow the battery to charge fully. The indicator light on the charger will change to confirm a full charge.
4. Once charged, remove the battery from the charger.

4.2 String Trimmer Assembly

1. Attach the string trimmer guard to the trimmer head using the provided hardware. Ensure it is securely fastened.
2. If necessary, install the string trimmer line. This model features a dual line feed and a bump head for easy line advancement. Refer to the detailed instructions in the full manual for specific line replacement procedures.

4.3 Leaf Blower Assembly

1. Align the leaf blower tube with the blower's air outlet.
2. Push and twist the tube until it locks securely into place.

5. Operating Instructions

5.1 Battery Installation

- Ensure the tool is off.
- Slide the charged 24-Volt battery into the battery port on the tool until it clicks securely into place.
- To remove, press the battery release button and slide the battery out.

5.2 String Trimmer Operation

1. With the battery installed, hold the trimmer firmly with both hands.
2. Press the safety lock-off button (if applicable) and then squeeze the variable speed trigger to start the trimmer.
3. Adjust the trigger pressure to control the cutting speed.
4. To advance the line, gently tap the bump head on the ground while the trimmer is running.
5. Release the trigger to stop the trimmer.

5.3 Leaf Blower Operation

1. With the battery installed, hold the blower firmly.
2. Squeeze the variable speed trigger to start the blower.
3. Adjust the trigger pressure to control the airflow.
4. Direct the airflow to clear leaves and debris.
5. Release the trigger to stop the blower.

6. Maintenance

6.1 Cleaning

- Always remove the battery before cleaning or performing maintenance.
- Use a dry cloth to wipe down the exterior of the tools.
- Remove any grass, dirt, or debris from the trimmer head, guard, and blower tube.
- Do not use harsh chemicals or abrasive cleaners.

6.2 String Trimmer Line Replacement

- Refer to the detailed instructions in your full product manual for specific steps on replacing the trimmer line. Ensure you use the correct line diameter (0.08-inch or 0.065-inch).

6.3 Battery Care and Storage

- Store batteries in a cool, dry place, away from direct sunlight and extreme temperatures.
- Do not store batteries in a discharged state for extended periods. Charge them periodically if not in use.
- Remove batteries from tools before storage.

7. Troubleshooting

Problem	Possible Cause	Solution
Tool does not start.	Battery not charged or not properly inserted.	Ensure battery is fully charged and securely inserted.
Reduced power or run time.	Battery charge is low or battery is old.	Recharge battery. Consider replacing old batteries.
String trimmer line not advancing.	Line tangled or empty spool.	Inspect and untangle line. Replace spool if empty.
Blower has low airflow.	Blower tube obstructed or loose.	Clear any obstructions. Re-secure blower tube.

If troubleshooting steps do not resolve the issue, please contact customer support.

8. Specifications

Feature	Detail
Brand	Kobalt
Model Number	KOC 4024A-03
Power Source	Battery Powered (24-Volt Lithium Ion)
String Trimmer Cutting Width	12 Inches
Blower Airflow	410 CFM (Cubic Feet per Minute)
Item Weight	16.37 pounds (total kit)
Package Dimensions	36 x 11.8 x 8 inches
Assembly Required	Yes
UPC	692042007804

9. Warranty and Support

Kobalt products are manufactured to high-quality standards and are warranted for defects in material and workmanship. For specific warranty details, including duration and coverage, please refer to the warranty card included with your product or visit the official Kobalt website.

For technical support, replacement parts, or service inquiries, please contact Kobalt Customer Service. Contact information can typically be found in your product packaging or on the manufacturer's website.

© 2023 Kobalt. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DS43BT4

More documents and user manuals: **https://manuals.plus/**