Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hitachi 889146

Hitachi 889146 Handle Arm NR90AC5 Replacement Part Instruction Manual

Model: 889146

Introduction

This manual provides essential information for the proper installation and maintenance of the Hitachi 889146 Handle Arm NR90AC5 Replacement Part. This component is designed for use with specific Hitachi power tool products. Please note that Hitachi Power Tools has transitioned its branding to Metabo HPT, offering the same quality tools under a new name.

Product Overview



Figure 1: The Hitachi 889146 Handle Arm NR90AC5 replacement part, shown alongside other common power tool components such as wiring, a plastic bushing, an air filter, and carbon brushes. This image illustrates the handle arm and other parts that might be included in a general power tool repair kit.

The 889146 Handle Arm NR90AC5 is a genuine Hitachi replacement part. It is specifically designed to ensure compatibility and optimal performance with the designated power tool models.

Included Components:

- Hitachi 889146 HANDLE ARM NR90AC5 Replacement Part

Note: Other components shown in Figure 1 may not be included with the 889146 Handle Arm NR90AC5 replacement part unless specified.

Setup and Installation

1. **Safety First:** Always disconnect the power tool from its power source (unplug or remove battery) before

attempting any installation or repair.

2. **Identify the Part:** Locate the existing handle arm on your power tool that requires replacement.
3. **Removal:** Carefully remove any fasteners (screws, bolts, clips) securing the old handle arm. Note their positions for reassembly.
4. **Installation:** Position the new Hitachi 889146 Handle Arm NR90AC5 replacement part in the correct orientation.
5. **Secure:** Reinstall all fasteners, ensuring they are tightened securely but do not overtighten.
6. **Test:** After installation, perform a manual check to ensure the handle arm is firmly attached and functions as expected before reconnecting power.

Note: For detailed, tool-specific installation instructions, refer to the original instruction manual for your specific Hitachi (now Metabo HPT) power tool model.

Operating the Tool with the New Handle Arm

The handle arm is an integral part of your power tool's ergonomics and control. Once properly installed, it should provide a secure and comfortable grip, allowing for safe and effective operation of the tool. Ensure the handle arm does not interfere with any moving parts or safety features of the tool.

- Always maintain a firm grip on the handle arm during tool operation.
- Do not operate the tool if the handle arm feels loose or damaged.
- Refer to your power tool's main instruction manual for specific operating procedures and safety guidelines.

Maintenance

Proper maintenance extends the life of your power tool and its components. The handle arm itself requires minimal maintenance, but regular inspection is recommended.

- **Regular Inspection:** Periodically check the handle arm for any signs of damage, cracks, or excessive wear.
- **Fastener Check:** Ensure all screws or bolts securing the handle arm remain tight. Retighten if necessary.
- **Cleaning:** Keep the handle arm clean from dirt, dust, and debris. Use a damp cloth if needed, avoiding harsh chemicals.
- **Storage:** Store the power tool in a clean, dry environment to prevent degradation of components.

Troubleshooting

If you encounter issues related to the handle arm after installation, consider the following:

- **Loose Handle Arm:** Check all fasteners. Ensure they are correctly seated and tightened.
- **Improper Fit:** Verify that the 889146 Handle Arm NR90AC5 is the correct replacement part for your specific tool model. Refer to your tool's original manual or manufacturer's specifications.
- **Damage:** If the handle arm appears damaged upon receipt or during installation, do not use it. Contact your

supplier for a replacement.

For issues unrelated to the handle arm, consult the troubleshooting section of your power tool's main instruction manual.

Specifications

Feature	Detail
Manufacturer	Koki Holdings America, Ltd (formerly Hitachi Power Tools)
Part Number	889146
Item Model Number	889146
Item Weight	1 pounds
Product Dimensions	1 x 1 x 1 inches
Item Package Quantity	1
Measurement System	Metric
Included Components	Hitachi 889146 HANDLE ARM NR90AC5 Replacement Part
Batteries Required?	No
ASIN	B07DSXND48
Date First Available	June 16, 2018

Warranty Information

Specific warranty details for replacement parts may vary. Please refer to the warranty documentation provided with your original Hitachi (Metabo HPT) power tool or visit the official Metabo HPT website for current warranty policies. Keep your purchase receipt as proof of purchase.

Customer Support

For technical assistance, replacement part inquiries, or further support, please contact Metabo HPT customer service. You can typically find contact information on the official Metabo HPT website or within the original power tool's instruction manual.
Online Resources: www.metabo-hpt.com

© 2023 Koki Holdings America, Ltd. All rights reserved. Hitachi and Metabo HPT are registered trademarks.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DSXND48

More documents and user manuals: **https://manuals.plus/**