Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fungoto E12C26426

User Manual for Mitsubishi Electric Ductless Air Conditioner Remote Controller

Model: E12C26426 (KM07K)

Introduction

This manual provides detailed instructions for the proper use, setup, and maintenance of the Mitsubishi Electric Ductless Air Conditioner Remote Controller, model E12C26426. This genuine replacement remote is designed to provide seamless control over your Mitsubishi Electric Mr. Slim air conditioning unit.



Image 1: Front view of the Mitsubishi Electric E12C26426 Ductless Air Conditioner Remote Controller.

Package Contents

- 1 x Mitsubishi Electric E12C26426 Remote Controller
- (Batteries not included: Requires 2 x AAA batteries)

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote controller.
2. Slide the battery cover downwards to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Note: Always use new batteries of the same type. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.



Image 2: Back view of the remote controller, showing the battery compartment.

2. Initial Pairing (If Required)

Most Mitsubishi Electric remote controllers are pre-programmed and do not require manual pairing with the indoor unit. Simply point the remote at the indoor unit and press the ON/OFF button. If the unit does not respond, refer to your air

conditioner's main instruction manual for specific pairing or reset procedures, as these can vary by indoor unit model.

Operating Instructions

The remote controller features an ergonomic design with clearly labeled buttons for intuitive operation. Below is a guide to the main functions:

ON/OFF Button: Press to turn the air conditioner unit on or off.

MODE Button: Cycles through operating modes: Auto, Cool, Dry, Fan, Heat (if applicable).

FAN Button: Adjusts fan speed: Auto, Low, Medium, High.

VANE Button: Controls the vertical airflow direction (up/down).

WIDE VANE Button: Controls the horizontal airflow direction (left/right).

ECONO COOL Button: Activates the energy-saving cooling mode.

POWERFUL Button: Activates rapid cooling or heating for a short period.

TIME Button: Used for setting timer functions (On/Off timer).

Temperature Adjustment Buttons (▲ / ▼): Adjusts the desired temperature setting.

RESET CLOCK Button: Resets the internal clock of the remote.

For detailed instructions on setting specific functions like timers or advanced modes, please refer to the comprehensive manual provided with your Mitsubishi Electric air conditioning indoor unit.

Maintenance

Cleaning the Remote Controller

- Wipe the surface of the remote controller with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water and a mild detergent, then wipe dry immediately.
- Do not use volatile liquids such as benzene, thinner, polishing powder, or chemical-treated dusters, as these may damage the surface or cause discoloration.

Battery Replacement

Replace batteries when the display becomes dim or the remote controller's range decreases. Follow the battery installation steps outlined in the "Setup" section. Dispose of used batteries according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote not responding to AC unit.	◦ Dead or low batteries. ◦ Remote not pointed directly at the indoor unit's receiver. ◦ Obstruction between remote and unit. ◦ Infrared emitter on remote is faulty.	◦ Replace batteries with new ones. ◦ Ensure direct line of sight to the indoor unit. ◦ Remove any obstructions. ◦ Test remote's IR signal using a smartphone camera (point remote at camera, press button, look for light on screen). If no light, remote may be faulty.
Display is dim or blank.	Low or dead batteries.	Replace batteries.
Unit responds intermittently.	◦ Weak batteries. ◦ Interference from other electronic devices.	◦ Replace batteries. ◦ Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the IR signal.

If problems persist after trying the above solutions, please contact a qualified service technician or refer to your air conditioner unit's main user manual for further assistance.

Specifications

Model Number: E12C26426 (KM07K)

Compatible Devices: Mitsubishi Electric Mr. Slim Ductless Air Conditioners

Connectivity Technology: Infrared (IR)

Power Source: 2 x AAA Batteries (not included)

Product Dimensions: Approximately 2 x 8 x 8 inches (5.08 x 20.32 x 20.32 cm)

Item Weight: Approximately 3.2 ounces (90.7 grams)

Special Feature: Ergonomic design

Warranty and Support

This remote controller is a genuine replacement part. For specific warranty information, please refer to the documentation provided with your original Mitsubishi Electric air conditioning unit or contact the seller/distributor from whom you purchased this remote controller. Support for the air conditioning unit itself is typically provided by Mitsubishi Electric or authorized service centers.
For further assistance, you may also visit the official Mitsubishi Electric website or consult your local authorized dealer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DYCWLYS

More documents and user manuals: **https://manuals.plus/**