Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nespresso EN500B

Nespresso Lattissima One Original Espresso Machine

Model: EN500B

Product Overview

The Nespresso Lattissima One is a compact and fully automatic espresso machine designed for single-serve coffee and milk recipes. It features a unique single-serve milk system, allowing you to prepare perfect cappuccinos and lattes with a touch of a button. Its sleek design and intuitive interface make it an ideal addition to any kitchen.





Image: The Nespresso Lattissima One machine in black, featuring a milk frother and a glass filled with a layered latte.

Setup Guide

Unpacking and Initial Preparation

Carefully remove all components from the packaging. Ensure all parts are present: the machine, water tank, milk frother, drip tray, and used capsule container. Place the machine on a stable, flat surface away from heat sources.



Image: The Nespresso Lattissima One machine shown alongside a variety pack of Nespresso coffee capsules, illustrating the compatible pod system.

First Use & Rinsing

1. Rinse the water tank and milk frother components with fresh drinking water.
2. Fill the water tank with fresh water.
3. Place a container (minimum 0.5L) under the coffee outlet.
4. Press any coffee button to start the rinsing cycle. The machine will dispense hot water.
5. Repeat this process 2-3 times until clean water flows through. The machine is now ready for use.

Operating Instructions

Powering On/Off

Press the power button (located on the control panel) to turn the machine on. The buttons will illuminate and blink until the machine is ready. The machine will automatically turn off after 9 minutes of inactivity to save energy (this setting is programmable).



Image: A close-up view of the Nespresso Lattissima One's control panel, showing the three illuminated beverage selection buttons for espresso, lungo, and milk-based drinks, along with indicators for cleaning and descaling.

Making Espresso/Lungo

1. Fill the water tank with fresh water.
2. Lift the lever and insert a Nespresso Original capsule. Close the lever firmly.
3. Place a cup under the coffee outlet.
4. Press the Espresso button (small cup icon) for a 40 ml shot or the Lungo button (large cup icon) for a 110 ml shot.
5. The machine will stop automatically once the selected volume is dispensed. Lift the lever to eject the used capsule into the container.





Image: The Nespresso Lattissima One machine brewing a shot of espresso into a small clear glass cup, showcasing the rich crema.

Making Milk-Based Recipes (Cappuccino/Latte Macchiato)

1. Fill the milk jug with the desired amount of fresh milk. Do not exceed the MAX fill line indicated on the jug.
2. Attach the milk jug to the machine's milk frother connection.
3. Place a suitable cup (tall for latte macchiato, standard for cappuccino) under the milk spout and coffee outlet.
4. Insert a Nespresso Original capsule and close the lever.
5. Press the Milk Recipe button (cup with foam icon). The machine will first froth and dispense milk, then brew the coffee into the same cup.
6. After milk dispensing, press the "Clean" button on the milk frother to rinse it.





Image: A front view of the Nespresso Lattissima One machine, highlighting the detachable milk frother container on the side, ready for preparing milk-based coffee beverages.

Maintenance and Cleaning

Daily Cleaning

- After each milk preparation, press the "Clean" button on the milk frother to initiate a quick rinse cycle.
- Empty and rinse the milk jug and its components thoroughly with warm water.
- Empty the drip tray and used capsule container daily. Wash them with warm, soapy water.

Descaling

The "Descaling" indicator light will illuminate when descaling is required. This is crucial for maintaining machine performance and coffee quality. Follow the instructions provided with the Nespresso descaling kit. Descale at least once a year, or more frequently depending on water hardness and usage.

General Cleaning

- Wipe the machine's exterior with a damp cloth. Do not use abrasive cleaners or immerse the machine in water.

- All removable parts (water tank, milk jug components, drip tray, used capsule container) can be washed by hand with mild detergent or in a dishwasher (top rack only).

Troubleshooting

Problem	Possible Cause	Solution
No coffee flow	Water tank empty or improperly seated	Fill water tank and ensure it is correctly positioned.
No coffee flow	Machine not heated	Wait for the coffee buttons to stop blinking and remain steady.
No milk froth or poor quality froth	Milk jug components not clean or incorrect milk type/temperature	Clean milk jug components thoroughly. Use fresh, cold, semi-skimmed milk (4°C/39°F).
Machine leaks	Drip tray full or capsule not inserted correctly	Empty the drip tray. Ensure the capsule is properly seated and the lever is fully closed.
Descaling light on	Machine needs descaling	Perform the descaling procedure as per the Nespresso descaling kit instructions.

Specifications

- **Brand:** Nespresso
- **Model:** EN500B
- **Dimensions (D x W x H):** 6.06" x 12.75" x 10.07"
- **Weight:** 9.3 pounds
- **Voltage:** 220 Volts
- **Coffee Maker Type:** Espresso Machine
- **Operation Mode:** Fully Automatic
- **Special Feature:** Programmable
- **Included Components:** Milk Frother

Warranty and Support

For detailed warranty information, product registration, and customer support, please refer to the official Nespresso website or contact their customer service directly. It is recommended to keep your proof of purchase for any warranty claims.

You can also find additional resources and frequently asked questions on theNespresso Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DYJVXL4

More documents and user manuals: **https://manuals.plus/**