Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY YB1FAF

YING RAY Replacement Air Conditioner Remote Control User Manual

MODEL: YB1FAF

1. Introduction

This manual provides comprehensive instructions for the YING RAY replacement air conditioner remote control, model YB1FAF. This remote is designed as a direct replacement for various Frigidaire air conditioner models, ensuring seamless operation without the need for complex programming. It displays temperature in Fahrenheit.

Compatible Air Conditioner Models include: FFHP092SQ2, FFHP092WQ2, FFHP092WQ20, FFHP122SQ2, FFHP122WQ2, FFHP122WQ20, FFHP182SQ2, FFHP182WQ2, FFHP182WQ20, FFHP222SQ2, FFHP222WQ2, FFHP222WQ20, FFHP302SQ2, FFHP302WQ2, FFHP302WQ20, FFHP362SQ2, FFHP362WQ2, FFHP362WQ20, FFMS181SQ2, FFMS181WQ2, FFMS181WQ20, FFMS221SQ2, FFMS221WQ2, FFMS221WQ20, FRS09PYS1, FRS09PYW1, FRS09PYW10, FRS124YW1, FRS124YW10, FRS12PYS1, FRS12PYW1, FRS12PYW10, FRS184YS2, FRS184YW2, FRS184YW20, FRS18PYS2, FRS18PYW2, FRS18PYW20, FRS224YS2, FRS224YW2, FRS224YW20, FRS22PYS2, FRS22PYW2, FRS22PYW20.

2. Setup

The YING RAY replacement remote control requires two 'AAA' 1.5V ordinary batteries (not included). No programming is necessary; the remote will function immediately upon battery insertion.

2.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two 'AAA' 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.



Image of the YING RAY replacement air conditioner remote control, showing its display and button layout.

3. Operating Instructions

Point the remote control directly at the air conditioner unit's receiver. Ensure there are no obstructions between the remote and the unit.

3.1 Button Functions

- **OFF/ON:** Powers the air conditioner unit on or off.
- **MODE:** Cycles through available operating modes (e.g., Cool, Fan, Dry).
- **- / +:** Adjusts the temperature setting. Press '-' to decrease and '+' to increase the temperature.
- **FAN:** Controls the fan speed (e.g., Low, Medium, High, Auto).
- **(Fan icon with waves):** Activates or adjusts the air swing/louver function.
- **HEALTH/SAVE:** Engages special functions such as energy-saving mode or air purification (if supported by the AC unit).
- **BLOW:** Initiates a fan-only operation to dry internal components and prevent mold.
- **HUMIDITY:** Activates or adjusts the dehumidification mode.
- **TIME:** Sets the timer for automatic power on/off.
- **TURBO:** Activates rapid cooling or heating for quick temperature changes.
- **SLEEP:** Engages sleep mode, which gradually adjusts temperature for comfortable sleep and energy efficiency.
- **(Light bulb icon):** Controls the display light or LED indicator on the air conditioner unit.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's display becomes dim or the remote fails to operate the air conditioner. Always replace both batteries simultaneously with new 'AAA' 1.5V ordinary batteries. Do not mix old and new batteries or different types of batteries.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can

damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new 'AAA' 1.5V batteries.
  - Ensure there are no obstructions between the remote and the air conditioner unit.
  - Verify that the remote is pointed directly at the air conditioner's receiver.
- **Air conditioner not responding to specific commands:**
  - Some functions may not be available on all compatible air conditioner models. Refer to your air conditioner's manual for its specific features.
  - Ensure the remote's display shows the desired setting before sending the command.
- **Temperature display is incorrect:**
  - This remote displays temperature in Fahrenheit only. If your AC unit is set to Celsius, the remote will still send Fahrenheit commands, which the AC unit should interpret correctly if it supports both.

6. Specifications

- **Model:** YB1FAF
- **Battery Type:** 2 x 'AAA' 1.5V Ordinary Batteries (not included)
- **Display:** Fahrenheit
- **Compatibility:** Designed for specific Frigidaire air conditioner models (refer to Introduction for list).
- **Manufacturer:** ZHUHAI YINGRAY TRADING CO., LTD.

7. Warranty and Support

Specific warranty information for this replacement remote control is not provided in the product details. For any support inquiries, warranty claims, or questions regarding compatibility, please contact the seller, YING RAY, directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DZ6LHXB

More documents and user manuals: **https://manuals.plus/**