Skil SD561204

SKIL Rechargeable 4V Cordless Screwdriver User Manual

Model: SD561204

Introduction

The SKIL Rechargeable 4V Cordless Screwdriver is designed for everyday use, offering convenience and efficiency for various household tasks. Featuring patented Circuit Sensor Technology, an integrated rechargeable Lithium-Ion battery, and a comprehensive 45-piece bit set, this tool is an essential addition to any toolkit. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.



Image: The SKIL 4V Cordless Screwdriver kit, including the screwdriver, 45-piece bit set, and USB charging cable, neatly organized within its durable carrying case.

Setup

Charging the Screwdriver

Your SKIL 4V Cordless Screwdriver comes with an integrated rechargeable Lithium-Ion battery. Before first use, fully charge the screwdriver. Use the provided USB charging cable to connect the screwdriver to a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status. A full charge ensures maximum performance and runtime.

Installing Bits

The screwdriver features a 1/4-inch hex chuck for quick and easy bit changes. To install a bit, simply push the desired bit firmly into the chuck until it clicks into place. To remove a bit, pull it straight out. The included 45-piece bit set provides a wide variety of bits for different screw types and applications.

Operating Instructions

Forward and Reverse Operation

To operate the screwdriver, rotate the collar located near the chuck. Turn the collar clockwise for forward (tightening) rotation and counter-clockwise for reverse (loosening) rotation. The direction indicator on the collar will align with the corresponding arrow.

LED Work Light

The screwdriver is equipped with a dual LED work light that illuminates the work area. The lights automatically activate when the screwdriver is in operation (either forward or reverse), providing improved visibility in dimly lit spaces.



Image: The screwdriver's dual LED work light provides clear illumination for tasks in low-light conditions, as demonstrated while working on a wall switch.

Circuit Sensor Technology

The patented Circuit Sensor Technology detects live electrical current in outlets, switches, cords, and fixtures from up to one inch away. To use this feature, hold the screwdriver near the suspected source of electricity and press the detection button (indicated by a lightning bolt symbol). If a live circuit is detected, a red light will illuminate and an audible alert will sound. This feature helps ensure safety by identifying live circuits before you begin work.



Image: The Circuit Sensor Technology in action, showing the screwdriver detecting live wires in an electrical fixture, with a red light indicating the presence of current.

Maintenance

To ensure the longevity and optimal performance of your SKIL Cordless Screwdriver, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe down the tool with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Bit Care:** Keep the bit set clean and free of debris. Store bits in their designated slots within the carrying case to prevent loss and damage.
- **Battery Storage:** For long-term storage, ensure the battery is partially charged (around 50%). Store the tool in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Overloading:** Do not force the screwdriver beyond its intended capacity. This can damage the motor and reduce battery life.

Troubleshooting

Problem	Possible Cause	Solution
Screwdriver not turning on	Battery is depleted	Charge the screwdriver using the provided USB cable.
Bit slips or does not engage screw head	Incorrect bit size/type; Worn bit; Bit not fully inserted	Ensure you are using the correct bit for the screw head. Replace worn bits. Push the bit firmly into the chuck until it clicks.
Circuit Sensor not detecting live wires	Not pressing detection button; Distance too far; No live current	Ensure the detection button is pressed. Hold the screwdriver within one inch of the source. Verify if the circuit is indeed live.
Reduced power or speed	Low battery; Overheating; Obstruction	Recharge the battery. Allow the tool to cool down. Check for any obstructions preventing smooth operation.

Specifications

Brand: Skil

Model Name: Rechargeable 4V Cordless Screwdriver

Model Number: SD561204

Voltage: 4 Volts

Speed: 230 RPM

Torque: 0.9 Inch Pounds

Battery Type: Lithium Ion (integrated)

Battery Capacity: 1.5 Amp Hours

Power Source: Battery Powered

Special Features: Cordless, Rechargeable, Circuit Sensor Technology, Dual LED Light

Included Components: Slim Magnetic Bit Collar, 4V Screwdriver with Circuit Sensor™ Technology, 16pc 1" bits, USB Charging Cable, 7pc 2" slim bits, 20pcs 1" security bits, 60mm Magnetic Bit Holder

Item Weight: 1.68 Pounds

Product Dimensions: 6.89 x 4.72 x 2.8 inches

Country of Origin: China

Warranty and Support

The SKIL Rechargeable 4V Cordless Screwdriver comes with a **5-Year Limited Warranty**. For detailed warranty information, service, or support, please refer to the official user manual PDF or visit the manufacturer's website.
You can access the full User Manual (PDF) here.

© 2025 SKIL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question