Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool W10432544

Whirlpool W10432544 Gas Range Griddle Instruction Manual

Brand: Whirlpool | **Model:** W10432544

1. Product Overview

The Whirlpool W10432544 Genuine OEM Cast Aluminum Gas Range Griddle is designed to fit over your gas burners, providing a flat, non-stick surface for a variety of cooking tasks. This accessory measures 7 3/4 inches by 19 3/4 inches and is ideal for preparing foods such as eggs, pancakes, and more. It features recessed drain channels with two divided grease wells for convenient fat collection.

This griddle is a genuine OEM part, specifically designed by Whirlpool to meet engineering standards and ensure the quality and longevity of your appliance. It is compatible with most major gas range brands and models, and its replacement does not require specialized tools, appliance disassembly, or repair experience.



Image: Top-down view of the Whirlpool W10432544 Gas Range Griddle, showcasing its rectangular shape and non-stick surface.



Image: Front view of the griddle, highlighting the integrated handles and grease channels.

2. Setup and Installation

The Whirlpool W10432544 Gas Range Griddle is designed for simple placement directly over your gas range burners. No tools or complex installation procedures are required.

1. Ensure your gas range is turned off and cool before placing the griddle.
2. Position the griddle evenly over two adjacent gas burners, typically one large and one small burner, to ensure balanced heat distribution.
3. Verify that the griddle sits securely on the grates of your range.

Before first use, wash the griddle thoroughly with warm, soapy water and dry completely.

3. Operating Instructions

This griddle provides a versatile cooking surface for various foods. Its non-stick coating makes it particularly suitable for items like eggs, pancakes, and more.

- **Preheating:** Place the griddle on your gas range and turn the burners to a medium-low setting. Allow the griddle to preheat for 5-10 minutes to ensure even heat distribution across the entire surface.
- **Cooking:** Once preheated, add a small amount of cooking oil or butter if desired, though the non-stick surface may not require it for all foods. Place food directly onto the griddle. Adjust burner heat as necessary to maintain desired cooking temperature.
- **Grease Management:** The recessed drain channels and divided grease wells are designed to collect excess fats and oils, making cooking healthier and cleanup easier. Periodically check and empty the grease wells during extended cooking sessions if necessary.
- **Temperature Control:** Monitor the heat carefully. While the griddle is designed for gas burners, excessive high heat can damage the non-stick coating over time.

Accessories
WHIRLPOOL CORPORATION

CAST ALLUMINUM GAS RANGE GRIDDLE



Part No. W10432544

For use with gas burners. Non-stick and great for cooking eggs, pancakes and more!

Whirlpool® KitchenAid® MAYTAG® AMANA® JENNAIR®

Image: The griddle positioned on a gas range, demonstrating its intended use.



Image: A closer view of the griddle in use on a gas range, showing its cooking surface.

4. Maintenance and Care

Proper care will extend the life and maintain the non-stick properties of your griddle.

- **Cleaning:** Allow the griddle to cool completely before cleaning. Wash by hand with warm, soapy water and a soft sponge or cloth. Do **NOT** use abrasive cleaners, scouring pads, or metal utensils, as these can damage the non-stick surface.
- **Dishwasher Safety:** This griddle is **NOT** dishwasher safe. Hand washing is required.
- **Storage:** Store the griddle in a dry place to prevent moisture buildup. If stacking with other cookware, place a soft cloth or paper towel between surfaces to protect the non-stick coating.

5. Troubleshooting

For a product like a griddle, troubleshooting is generally straightforward. Most issues relate to usage rather than product malfunction.

- **Uneven Heating:** Ensure the griddle is centered over your burners. Adjust burner flame size to achieve more even heat distribution. Some gas ranges may naturally have hot spots; adjust griddle position or food placement accordingly.
- **Food Sticking:** Ensure the griddle is properly preheated. While non-stick, some foods or insufficient preheating can cause sticking. Use a small amount of cooking oil or butter if food continues to stick. Avoid using metal utensils that can scratch the non-stick surface, leading to sticking.
- **Excessive Smoke:** This may indicate that the griddle is too hot or that too much oil/fat is being used. Reduce burner heat and ensure proper ventilation.

6. Specifications

Feature	Detail
Model Number	W10432544
Material	Cast Aluminum
Color	Black
Product Dimensions (L x W x Th)	21" x 9" x 1.9"
Item Weight	5.79 pounds (2.63 Kilograms)
Non-stick Coating	Yes
Dishwasher Safe	No
Recommended Uses	Cooking various food items on a gas range

7. Warranty Information

Specific warranty details for the Whirlpool W10432544 Gas Range Griddle are typically provided at the point of purchase or included with the product packaging. For the most accurate and up-to-date warranty information, please refer to the documentation that came with your griddle or contact Whirlpool customer support directly. Protection plans may also be available for purchase separately.

8. Customer Support

For further assistance, questions, or to purchase additional genuine Whirlpool parts and accessories, please contact Whirlpool Customer Service. You can typically find contact information on the official Whirlpool website or within your appliance's main user manual.

Whirlpool Official Website: www.whirlpool.com

When contacting support, please have your griddle's model number (W10432544) readily available.

© 2025 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07F32XQ7V

More documents and user manuals: **https://manuals.plus/**