ZdalaMit XRT132

ZdalaMit XRT132 Replacement Remote Control User Manual

For Vizio TV Models: M80-D3, M60-D1, M65-D0, P55-C1, P50-C1, P65-C1, M50-D1, M55-D0, M70-D3, P75-C1, E65-D0, E65-D1, E65U-D1, E65U-D3, E70U-D3, M60-C3, E49U-D1, E50-D1, E50U-D2, E55-D0, E55U-D0, E55U-D2, E60U-D3, D40U-D1, E32-D1, E40-D0, E43-D2, E43U-D2, E48-D0, E48U-D0

Introduction

This manual provides instructions for the setup, operation, and maintenance of your ZdalaMit XRT132 Replacement Remote Control. This remote is designed to function as a direct replacement for various Vizio TV models without requiring any programming.



Image: Front view of the ZdalaMit XRT132 Replacement Remote Control. It is black with clearly labeled buttons for power, input, volume, channel, mute, and picture settings.

Setup: Battery Installation

1. **Locate the Battery Compartment:** Turn the remote control over to find the battery compartment cover on the back.
2. **Open the Cover:** Gently slide the battery compartment cover downwards or press the latch and lift to open it.

3. **Insert Batteries:** Insert two (2) 1.5V AAA alkaline batteries into the compartment. Ensure the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment.
4. **Close the Cover:** Replace the battery compartment cover by sliding it back into place until it clicks securely.

No programming or pairing is required after battery installation. The remote is ready for immediate use with compatible Vizio TVs.



Image: Back view of the ZdalaMit XRT132 remote control, illustrating the open battery compartment where two AAA batteries are to be inserted.

Operating Instructions

The ZdalaMit XRT132 remote control provides standard functions for your Vizio TV. Point the remote directly at your television when operating.

- **Power Button:** Turns the television on or off.
- **Input Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Volume Up/Down (VOL + / -):** Adjusts the audio volume level.
- **Channel Up/Down (CH + / -):** Changes the television channel.
- **Mute Button:** Toggles sound on or off.
- **Picture Button (PIC):** Accesses picture settings or modes.
- **Navigation/OK Buttons (Directional Pad and Play/Pause):** Used for menu navigation and selection. The central button typically acts as "OK" or "Enter," and the play/pause button may function as a media control.

Compatible Vizio TV Models

This replacement remote control is compatible with the following Vizio TV models:

- M80-D3, M60-D1, M65-D0
- P55-C1, P50-C1, P65-C1
- M50-D1, M55-D0, M70-D3, P75-C1
- E65-D0, E65-D1, E65U-D1, E65U-D3, E70U-D3
- M60-C3, E49U-D1, E50-D1, E50U-D2
- E55-D0, E55U-D0, E55U-D2, E60U-D3
- D40U-D1, E32-D1, E40-D0, E43-D2, E43U-D2, E48-D0, E48U-D0

If your Vizio TV model is not listed, please verify compatibility with the seller before use.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of batteries in general household waste.

Troubleshooting

Problem	Solution
Remote is not working.	• Ensure batteries are inserted correctly with the correct polarity (+/-). • Replace old batteries with new 1.5V AAA alkaline batteries. • Ensure there are no obstructions between the remote and the TV's infrared sensor. • Confirm the remote is compatible with your specific Vizio TV model.
Buttons are unresponsive or sticky.	• Clean the remote control surface with a soft, dry cloth. • Avoid spilling liquids on the remote.

Specifications

- **Model:** XRT132
- **Brand:** ZdalaMit
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Product Dimensions:** 5.56 x 1.67 x 0.55 inches (approximately)
- **Item Weight:** 1.41 ounces (approximately)
- **Color:** Black
- **Compatible Devices:** Vizio Televisions (specific models listed above)

Warranty and Support

This instruction manual does not contain specific warranty information. For details regarding warranty coverage, technical support, or any product-related queries, please contact the seller directly through your purchase platform.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question