CKPSMS 032270116

CKPSMS 110V 3-Prong Foot Control Pedal Instruction Manual

Model: 032270116

1. Product Overview

This document provides instructions for the CKPSMS 110V 3 Uneven Prong Foot Control Pedal, designed as a replacement part for various Kenmore brand sewing machines. This pedal allows for variable speed control of your sewing machine.

Part Number: 032270116 110V

Alternative Part Numbers: 033770114F, 033770114FC, 482-P, 482-J, 033770114, 031870119, 31870119, 33770114, 3C-135-B, 6811, 6812, 6815, 6816, DPX6811, FC-LC10



Image 1.1: The CKPSMS 110V 3-Prong Foot Control Pedal. This image displays the complete foot pedal unit with its attached power cord and 3-prong connector.

2. Compatibility

This foot control pedal is compatible with a wide range of Kenmore brand sewing machine models. It is designed for 110V voltage systems. Before installation, verify that your sewing machine requires a 3-uneven prong connector and operates on 110V.

Compatible Kenmore 148 Series Models:

- 148.14501, 148.14571, 148.11150, 148.12011, 148.12040, 148.12060, 148.12071, 148.12140, 148.1217, 148.12170, 148.12180, 148.12181, 148.12190, 148.12200, 148.12210, 148.13100, 148.13101, 148.13110, 158.14310, 148.15210, 148.15600, 148.15700, 148.19371, 148.19372

Compatible Kenmore 158 Series Models:

- 158.1010180, 158.10300, 158.10304, 158.10401, 158.10402, 158.10600, 158.10601, 158.10690, 158.10691, 158.10692, 158.12020, 158.12110, 158.12111, 158.12112, 158.12120, 158.12260, 158.12270, 158.12271, 158.12272, 158.12292, 158.12312, 158.12411, 158.12470, 158.12472, 158.12510, 158.12511, 158.12512, 158.12520, 158.1255180, 158.1255181, 158.1262181, 158.1262182, 158.130, 158.13201, 158.13250, 158.13360, 158.13400, 158.1340180, 158.1340280, 158.1340281, 158.13410, 158.13411, 158.13412, 158.13413, 158.13450, 158.1345380, 158.1345381, 158.13471, 158.13500, 158.1350180, 158.1350280, 158.13510, 158.13511, 158.13512, 158.13520, 158.1355080, 158.13570, 158.13571, 158.13573, 158.14301, 158.14311, 158.1440180, 158.1450180, 158.1450181, 158.1450280, 158.14510, 158.1457180, 158.15150, 158.15250, 158.15251, 158.15510, 158.15511, 158.1561180, 158.1561280, 158.1561281, 158.15810, 158.1595280, 158.1595281, 158.16250, 158.16410, 158.16600, 158.16800, 158.16801, 158.16820, 158.16900, 158.17200, 158.17300, 158.17310, 158.17600, 158.1765180, 158.17741, 158.17810, 158.17811, 158.17812, 158.1783080, 158.1784080, 158.1784181, 158.1784182, 158.1784183, 158.1784184, 158.17850, 158.1786080, 158.1786081, 158.1787180, 158.1789280, 158.18150, 158.19130, 158.19141, 158.19310, 158.19311, 158.19400, 158.19410, 158.19411, 158.19412, 158.19460, 158.19461, 158.19470, 158.19471, 158.220

Compatible Kenmore 385 Series Models:

- 385.1011180, 385.101180, 385.11101590, 385.1154180, 385.1158180, 385.11607090, 385.1168280, 385.1168291, 385.12014590, 385.12116690, 385.12216, 385.12216790, 385.12314990, 385.12321, 385.1233180, 385.1233280, 385.12490, 385.1249380, 385.12514590, 385.1254180, 385.1258180, 385.12612090, 385.12614490, 385.12618890, 385.1264180, 385.12714090, 385.1274180, 385.1278180, 385.1278191, 385.12812690, 385.12814490, 385.1284180, 385.1564180, 385.157510, 385.1584180, 385.16631490, 385.16633790, 385.1664190, 385.16642090, 385.16655100, 385.1684180, 385.1695180, 385.17026590, 385.17124, 385.17124790, 385.17126, 385.17126690, 385.17526, 385.17622090, 385.17641, 385.1764180, 385.17724490, 385.1778180, 385.1778181, 158.17820, 385.17822490, 385.17824090, 385.1782480, 385.17826690, 385.17828490, 385.1788180, 385.17922090, 385.17928, 385.17928090, 385.18230790, 385.18330, 385.18830, 385.18830490, 385.18836, 385.18836090, 385.18841, 385.1884180

3. Setup and Installation

Follow these steps to correctly install your new foot control pedal:

1. **Verify Plug Type:** Before connecting, carefully compare the plug on your old foot pedal with the new CKPSMS pedal. Ensure both have a 3-uneven prong configuration. This pedal is designed for 110V-120V voltage.



Image 3.1: Visual guide for checking your old plug. This image highlights the importance of matching the 3-uneven prong configuration of your existing pedal's plug to ensure compatibility with the new CKPSMS pedal.

2. **Power Disconnection:** Always ensure your sewing machine is turned **OFF** and unplugged from the main power outlet before connecting or disconnecting any parts.
3. **Connect the Pedal:** Insert the 3-uneven prong connector of the new foot pedal firmly into the corresponding receptacle on your sewing machine.



Image 3.2: Close-up view of the 3-uneven prong connector. This image provides a detailed look at the specific plug type for proper identification and connection.

4. **Power Connection:** Once the pedal is securely connected, plug your sewing machine's power cord into a 110V-120V electrical outlet.

4. Operation

The CKPSMS foot control pedal operates identically to your original sewing machine pedal. To operate your sewing machine:

1. Turn on your sewing machine's power switch.
2. Gently press down on the foot pedal to start sewing. The harder you press, the faster the machine will sew.
3. Release pressure on the pedal to slow down or stop the machine.

5. Safety Guidelines

Adhere to the following safety guidelines when using the foot control pedal and your sewing machine:

- Do not use the product when your hands are wet.
- If the power cord is damaged, stop using the product immediately and replace it with a new one.
- Always disconnect the power supply before examining or servicing the product.
- Do not connect the product to a power source with a voltage that does not match the specified 110V-120V.

- Keep out of reach of children.
- Do not use upside down.

Product safety photos and guideline

For CKPSMS brand sewing machine parts and accessories



Needle Plate:
Always use the correct needle plate for your sewing machine model. Do not use a damaged or bent needle plate. When changing the needle plate, make sure the sewing machine is turned off and unplugged.



Bobbin Case:
Always use the correct bobbin case for your sewing machine model. Do not use a damaged or bent bobbin case. When changing the bobbin case, make sure the sewing machine is turned off and unplugged.



Presser Foot:
Always use the correct presser foot for your sewing machine model. Do not use a damaged or bent presser foot. When changing the presser foot, make sure the sewing machine is turned off and unplugged.



Fabric cleaner:
a. Do not spray towards the body, face, or hands of a person.
b. Keep out of reach of children.
c. Do not use upside down.
d. Do not connect to a power source with a voltage that does not match the product.
e. Do not modify the power cord or auxiliary tools of this product by yourself.



Foot pedal, auto bobbin winder and any other products which are required to connect to the power:
a. Do not use the product when your hands are wet.
b. If the power cord is damaged, stop using the product immediately and replace it with a new one.
c. Always disconnect the power supply before repairing the product.
d. Do not connect the product to a power source with a voltage that does not match.



Looper, thread cutter, blades and any other products which are sharp or incisive:
a. Take sufficient safety precautions to prevent injury to your fingers.
b. Before disassembling or assembling, understand the correct method and make sure to install it in the designated position.
c. Keep it in a place where children cannot touch it.
d. Store it in a sturdy packaging box and take measures to prevent rust and corrosion.

Product Safety Guidelines

Image 5.1: General product safety guidelines. This image illustrates various safety recommendations applicable to sewing machine parts, including the foot pedal, emphasizing safe handling and usage practices.

6. Maintenance

The foot control pedal requires minimal maintenance. Keep the pedal clean and free from dust and debris. Store it in a dry place when not in use to prevent rust or corrosion, especially if exposed to moisture.

7. Troubleshooting

If your sewing machine does not respond when the pedal is pressed:

- Ensure the pedal's connector is fully and securely inserted into the sewing machine.
- Verify that the sewing machine's power switch is turned on.
- Check that the sewing machine is properly plugged into a functional electrical outlet.
- Inspect the power cord for any visible damage. If damaged, discontinue use and replace.
- Confirm that the voltage of your power source matches the pedal's requirement (110V-120V).

If issues persist, refer to the support section for further assistance.

8. Specifications

Part Name	3 Uneven Prong Foot Control Pedal
Part Number	032270116
Voltage	110V - 120V
Package Dimensions	7 x 4.7 x 4 inches
Item Weight	13.6 ounces
Manufacturer	CKPSMS

9. Support

CKPSMS is dedicated to providing support for its products. If you require assistance with your foot control pedal, please contact us for:

- **Parts Recommendation:** Guidance on suitable and compatible parts for your specific machine.
- **Installation Guidance:** Assistance with the correct installation process.
- **Usage Assistance:** Advice on how to correctly use the parts with your sewing machine.

For further inquiries, please visit the official CKPSMS store or contact customer service through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question