Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zilan ZLN9171

Zilan ZLN9171 Multifunction Robot Cooker Instruction Manual

Model: ZLN9171 | Brand: Zilan

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Zilan ZLN9171 Multifunction Robot Cooker. Please read these instructions thoroughly before first use and keep them for future reference.



Image: The Zilan ZLN9171 Multifunction Robot Cooker, showcasing its sleek black and stainless steel design with an illuminated LED control panel.

Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Do not immerse the main unit in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance out of reach of children.
- Do not operate the appliance with a damaged cord or plug.
- Always unplug the appliance when not in use and before cleaning.
- Use only manufacturer-recommended accessories.
- Avoid touching hot surfaces. Use handles or knobs.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.

Product Components

Familiarize yourself with the parts of your Zilan ZLN9171 Multifunction Robot Cooker:

- Main Unit with Control Panel and LED Display
- Inner Cooking Pot (5 Liters capacity)
- Lid
- Measuring Cup
- Plastic Steamer Basket
- Rice Spoon
- Power Cable



Image: All included accessories for the Zilan ZLN9171, featuring the inner cooking pot, plastic steamer, measuring cup, and serving spoons.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials and inspect the appliance for any damage.
2. **Initial Cleaning:** Before first use, wash the inner cooking pot, measuring cup, plastic steamer, and rice spoon with warm soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the robot cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
4. **Power Connection:** Connect the power cable to the appliance and then plug it into a suitable electrical outlet. The LED display will illuminate.



Image: The Zilan ZLN9171 with its lid open, revealing the non-stick inner cooking pot and the lid's condensation collector.

Operating Instructions

The Zilan ZLN9171 features 16 automatic programs and a user-friendly LED display for easy operation.

Control Panel Overview:

- **LED Display:** Shows cooking time, program selection, and other relevant information.
- **Menu Button:** Cycles through the 16 automatic cooking programs.
- **Start Button:** Initiates the selected cooking program. Press and hold to confirm.
- **Keep Warm / Off Button:** Activates or deactivates the automatic keep warm function.
- **Preset Button:** Sets the delayed start timer (up to 24 hours).
- **Temp / Hr / Min Buttons:** Adjust temperature, hours, and minutes for manual settings or preset timer.

Cooking Programs and Functions:

Your robot cooker offers a wide range of functions, including:

- **Automatic Programs:** FRY, CAKES, STEAM, PASTA, SOUP, RICE, STEW, YOGURT, CRUST, OATMEAL, PIZZA, DESSERT, PORRIDGE, MILK PORRIDGE, WHEAT.
- **3D-Heating:** Ensures even cooking throughout the pot.
- **Sensor Use:** Automatically adjusts cooking parameters for optimal results.
- **Start Timer (Programador de inicio):** Delay the start of cooking for up to 24 hours.
- **Auto-warming (Autocalentamiento):** Keeps food warm automatically after cooking.
- **Reheating (Recalentamiento):** Warms up previously cooked food.
- **Fuzzy Logic Technology:** Intelligently adjusts cooking time and temperature based on ingredients.
- **Special Functions:** Preparation of yogurts, fondue, frying, dough cooking, pasteurization of liquid products, sterilization of dishes, warming baby food, and preparing products for preservation.

General Cooking Steps:

1. Place the desired ingredients into the inner cooking pot.
2. Insert the inner pot into the main unit and close the lid securely.
3. Plug in the appliance. The LED display will show the default setting or last used program.
4. Press the **Menu** button repeatedly to select your desired cooking program.
5. If necessary, adjust the cooking time or temperature using the **Hr** and **Min** buttons.
6. To use the delayed start function, press the **Preset** button and set the desired delay time.
7. Press and hold the **Start** button to begin the cooking process. The display will show the remaining cooking time.
8. Once cooking is complete, the appliance may automatically switch to the "Keep Warm" mode. Press **Keep Warm / Off** to cancel.
9. Carefully open the lid, avoiding steam. Serve the food.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your Zilan ZLN9171.

- Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
- **Dishwasher Safe Parts:** The 5-liter inner cooking pot and the measuring cup are dishwasher safe.
- **Hand Wash Only Parts:** The power cable, plastic steamer, and rice spoon should be washed by hand with warm

soapy water. Rinse thoroughly and dry.

- **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water.
- **Lid:** Clean the inside of the lid and the condensation collector with a damp cloth. Ensure all food residues are removed.
- Ensure all parts are completely dry before reassembling and storing the appliance.

Troubleshooting

If you encounter issues with your Zilan ZLN9171, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cable connection; verify power supply; try a different outlet.
Food not cooking evenly.	Incorrect program selected; insufficient liquid; lid not properly closed.	Ensure correct program for ingredients; add sufficient liquid; close lid securely.
Steam leaking from lid.	Lid not properly sealed; seal ring dirty or damaged.	Ensure lid is closed correctly; clean or replace the seal ring if necessary.
Display shows an error code.	Internal malfunction.	Unplug the appliance, wait a few minutes, then plug it back in. If the error persists, contact customer support.

For issues not listed here, please contact Zilan customer support.

Technical Specifications

- **Brand:** Zilan
- **Model:** ZLN9171
- **Model Number:** 9171
- **Power:** 860 W
- **Capacity:** 5 Liters
- **Dimensions (L x W x H):** 37 x 29 x 24 cm
- **Weight:** 4 kg
- **Color:** Black
- **Number of Automatic Programs:** 16
- **Display:** LED illuminated
- **Noise Level:** 30 Decibels
- **Special Features:** 3D-Heating, Sensor Use, Start Timer, Auto-warming, Reheating, Fuzzy Logic Technology, Yogurt, Fondue, Frying, Dough cooking, Liquid pasteurization, Dish sterilization, Baby food warming, Preservation.
- **Components Included:** Inner cooking pot, measuring cup, plastic steamer, rice spoon, power cable.



Image: A close-up view of the product label on the Zilan ZLN9171, indicating the model number (ZLN9171), voltage (230V~), and power (860W).

Warranty and Support

Zilan products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Zilan website. Keep your proof of purchase for any warranty claims.
For technical support, spare parts, or service inquiries, please contact Zilan customer service through their official channels. Contact details can typically be found on the product packaging or the manufacturer's website.

© 2023 Zilan. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FCQX9DQ

More documents and user manuals: **https://manuals.plus/**