Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nostalgia B07FDMKLCK

Nostalgia 128-Ounce Frozen Drink & Margarita Machine User Manual

Model: B07FDMKLCK | Brand: Nostalgia

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before operating this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or any part of the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.
- Ensure the blending chamber is securely locked onto the base before operation.
- Always ensure the lid is properly secured before operating the machine.

Product Overview

The Nostalgia 128-Ounce Frozen Drink & Margarita Machine is designed to create a variety of frozen beverages. Familiarize yourself with its main components:

- **Motorized Base:** Houses the motor and control switch.

- **Blending Chamber:** A clear, double-insulated container with a 1-gallon (128-ounce) capacity for mixing ingredients. Features a "MAX FILL" line for ice.
- **Lid:** Secures the blending chamber and includes an opening for adding ingredients.
- **Carry Handle:** Integrated into the lid for easy transport, also locks the lid in place.
- **Easy-Flow Spout:** Dispenses the frozen beverage.
- **On/Off Switch:** Controls the operation of the machine.
- **Grinding Cage:** Located inside the blending chamber, responsible for shaving ice.



Image: The Nostalgia Frozen Drink Maker showing its main components and dimensions (10"D x 12"W x 19.25"H).

Setup Instructions

1. **Unpack and Clean:** Carefully remove all components from the packaging. Wash the blending chamber, lid, and spout assembly with warm, soapy water. Rinse thoroughly and dry. Do not immerse the motor base in water.
2. **Position the Base:** Place the motorized base on a stable, level, and dry surface, away from the edge of the counter.

3. **Attach Blending Chamber:** Align the blending chamber with the base and rotate it clockwise until it securely locks into place. Ensure the locking tabs on the base engage with the chamber.

Your browser does not support the video tag.

Video: Product Overview demonstrating how to assemble the blending chamber and other features.

4. **Add Ice:** Fill the blending chamber with ice cubes up to the "MAX FILL" line. Do not overfill.



Image: Step 1 of the operation, showing ice being added to the blending chamber up to the MAX fill line.

5. **Add Liquid Ingredients:** Pour your desired liquid ingredients (e.g., margarita mix, fruit juice, soda) into the blending chamber. Ensure the liquid level does not exceed the ice level.
6. **Secure the Lid:** Place the lid onto the blending chamber and rotate the carry handle upwards until it locks the lid securely in place. This ensures safe operation and prevents spills.

Operating Instructions

1. **Power On:** Plug the appliance into a standard electrical outlet. Flip the ON/OFF switch to the "ON" position. The machine will begin to shave and mix the ice and liquid.
2. **Monitor Consistency:** Allow the machine to operate until the desired frozen consistency is achieved. The double-insulated chamber helps maintain the cold temperature.

3. **Dispense Drink:** Once the drink reaches the desired slushy consistency, place a glass under the easy-flow spout. Push the spout lever down to dispense the frozen beverage. Release the lever to stop the flow.
4. **Power Off:** When finished, flip the ON/OFF switch to the "OFF" position and unplug the machine from the outlet.



Image: The machine in operation, creating a green frozen drink, demonstrating its versatility.

Your browser does not support the video tag.

Video: Demonstration of the Nostalgia Frozen Drink Maker in use, showing the blending and dispensing process.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and longevity of your frozen drink maker.

1. **Unplug:** Always ensure the machine is unplugged from the power outlet before cleaning.
2. **Disassemble:** Lift the carry handle to unlock the lid, then remove the lid. Rotate the blending chamber counter-clockwise to detach it from the motor base.

3. **Remove Grinding Cage:** The grinding cage can be removed for thorough cleaning. Refer to the product diagram for specific removal instructions, usually involving unscrewing a small fastener.
4. **Wash Components:** Wash the blending chamber, lid, spout assembly, and grinding cage with warm, soapy water. Use a soft brush for hard-to-reach areas. Rinse thoroughly. These parts are generally not dishwasher safe.
5. **Clean Base:** Wipe the exterior of the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
6. **Dry and Store:** Ensure all parts are completely dry before reassembling and storing the machine. Store in a cool, dry place.



Image: The blending chamber being cleaned in soapy water, highlighting its detachable design for easy maintenance.

Your browser does not support the video tag.

Video: A short clip demonstrating the easy removal of the grinding cage for cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power switch off; blending chamber not securely locked; lid not properly secured.	Ensure unit is plugged into a working outlet. Flip switch to "ON". Ensure blending chamber is locked onto the base and the lid handle is in the upright, locked position.
Ice is not shaving or mixing properly.	Too much ice; not enough liquid; ice cubes are too large.	Do not exceed the "MAX FILL" line for ice. Ensure sufficient liquid is added. Use standard-sized ice cubes.
Liquid leaks from the spout.	Spout not fully closed; seal around spout is damaged or improperly installed.	Ensure the spout lever is fully in the closed position. Check the spout's internal seal for proper placement and damage.
Motor stops during operation.	Overheating; obstruction in grinding mechanism.	Unplug the unit and allow it to cool for 15-20 minutes. Check for any obstructions in the grinding cage and remove them. Restart the machine.

Specifications

- **Model Number:** B07FDMKLCK
- **Brand:** Nostalgia
- **Capacity:** 128 Ounces (1 Gallon)
- **Dimensions (D x W x H):** 10" x 12" x 19.25"
- **Weight:** 3.9 kg
- **Material:** Stainless Steel (Blade, Container), BPA Free
- **Power Source:** Corded Electric
- **Wattage:** 150 watts
- **Voltage:** 120V
- **Number of Speeds:** 1
- **Control Type:** Manual (Physical Buttons/Knobs)
- **Special Features:** Cord Storage, Portable, Pour Spout, Double Insulated
- **UPC:** 082677020000



Image: Detail showing the integrated cord storage feature for convenience.

Warranty and Support

This Nostalgia appliance is covered by a **1-Year Limited Warranty** from the date of purchase. For warranty service or technical support, please contact Nostalgia customer service.
EU spare parts availability duration: 5 years.
For more information, visit the official Nostalgia Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FDMKLCK

More documents and user manuals: **https://manuals.plus/**