Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY LT1016CER, LW1216HR, LW1516ER, LW1816ER, LW2516ER

YING RAY Replacement Remote Control User Manual

For LG Window Air Conditioner Models: LT1016CER, LW1216HR, LW1516ER, LW1816ER, LW2516ER

Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your YING RAY replacement remote control for specific LG Window Air Conditioner models. Please read this manual thoroughly before using the remote control.

Important Compatibility Note: This remote control is specifically designed for LG Window Air Conditioner models LT1016CER, LW1216HR, LW1516ER, LW1816ER, and LW2516ER. It is not a universal remote control and may not function with other LG or non-LG air conditioner models. If you are unsure about compatibility, please verify your air conditioner model number.

Setup

1. Battery Installation

The remote control requires two (2) AAA 1.5V ordinary batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover until it clicks securely into place.

Note: *Ensure batteries are inserted with correct polarity. Incorrect installation can prevent the remote from functioning.*

Operating Instructions

Point the remote control directly at the air conditioner's receiver window. Ensure there are no obstructions between the remote and the air conditioner.



This image displays the front face of the YING RAY replacement remote control. Key buttons visible include Power (blue, top), Temperature Up/Down (triangle buttons), Fan Speed (oval button), Timer (oval button), Mode (oval button), Energy Saver (oval button), and Auto Swing (oval button).

Button Functions:

- **Power Button (Blue, Top):** Turns the air conditioner ON or OFF.

- **Temp ▲ / ▼ (Triangle Buttons):** Adjusts the desired temperature setting. ▲ increases temperature, ▼ decreases temperature.
- **Fan Speed Button:** Cycles through available fan speed settings (e.g., Low, Medium, High, Auto).
- **Timer Button:** Sets or cancels the timer function for automatic ON/OFF operation. Refer to your air conditioner's manual for specific timer programming details.
- **Mode Button:** Selects the operating mode of the air conditioner (e.g., Cool, Fan, Dry, Auto).
- **Energy Saver Button:** Activates or deactivates the energy-saving mode, if available on your air conditioner model.
- **Auto Swing Button:** Controls the automatic oscillation of the air conditioner's louvers for wider air distribution.

Maintenance

Battery Replacement:

Replace batteries when the remote control's range decreases or if it stops responding. Always replace both batteries at the same time with new AAA 1.5V batteries. Do not mix old and new batteries or different types of batteries.

Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can damage the remote's surface or internal components.

Storage:

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote not responding:**
  - Ensure the remote is pointed directly at the air conditioner's receiver.
  - Check if there are any obstructions between the remote and the air conditioner.
  - Replace the batteries with fresh AAA 1.5V batteries.
  - Verify that the battery positive (+) and negative (-) terminals are correctly aligned.
- **Remote works intermittently or has reduced range:**
  - Batteries may be low. Replace them.
  - **Battery Contact Issue:** If the remote does not work, gently pull the battery spring out a little (as shown in some product images for 'Type B' remotes) to ensure better contact with the battery's positive pole.
- **Air conditioner does not respond to specific commands:**
  - Ensure the remote control is compatible with your specific LG air conditioner model (LT1016CER, LW1216HR, LW1516ER, LW1816ER, LW2516ER).
  - Some functions may be specific to your air conditioner model and might not be fully supported or displayed by the remote.

Specifications

Feature	Detail
Brand	YING RAY
Compatible Air Conditioner Models	LG LT1016CER, LW1216HR, LW1516ER, LW1816ER, LW2516ER
Battery Type	2 x AAA 1.5V (not included)
Item Weight	1.44 ounces
Package Dimensions	6.42 x 5.47 x 0.87 inches
Special Feature	Ergonomic design
Max Number of Supported Devices	1

Warranty Information

Specific warranty details for this YING RAY replacement remote control are not provided in the product information. Please refer to the seller's return policy or contact the seller directly for warranty inquiries.

Customer Support

For further assistance or troubleshooting not covered in this manual, please contact the seller or manufacturer directly. Contact information may be available on your purchase receipt or the product packaging.

© 2023 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FM16X28

More documents and user manuals: **https://manuals.plus/**