DJI CP.AS.AA000008.01

DJI Osmo Action Hanging Neck Mount User Manual

Model: CP.AS.AA000008.01

1. Introduction

This user manual provides essential information for the safe and effective use of your DJI Osmo Action Hanging Neck Mount. Please read this manual thoroughly before use and retain it for future reference.
The DJI Osmo Action Hanging Neck Mount is designed to provide a comfortable and versatile solution for capturing hands-free, first-person view (FPV) footage with compatible action cameras. Its unique silica gel material allows for easy reshaping and comfortable wear.

2. Product Overview

The DJI Osmo Action Hanging Neck Mount is a flexible, wearable accessory that allows users to attach compatible action cameras for hands-free recording. It features a soft, pliable neckband and a robust mounting point for your camera.



Figure 2.1: Front view of the DJI Osmo Action Hanging Neck Mount.



Figure 2.2: The neck mount with its locking screw detached, showing the camera attachment point.



Figure 2.3: Dimensions of the DJI Osmo Action Hanging Neck Mount, approximately 15 cm wide and 17 cm high.

3. What's in the Box

Upon opening the package, verify that all the following items are included:

- Osmo Action Hanging Neck Mount × 1
- Osmo Locking Screw × 1

4. Setup

1. **Unpack the Mount:** Carefully remove the Osmo Action Hanging Neck Mount and the Osmo Locking Screw from their packaging.
2. **Attach Your Camera:** Align your compatible action camera (e.g., Osmo Action, DJI Action 2, Osmo Action 3, Osmo Action 4, Osmo Action 5 Pro) with the mounting point on the neck mount. Secure the camera using the provided Osmo Locking Screw. Ensure the screw is tightened firmly to prevent camera movement during use.
3. **Wear the Mount:** Place the neck mount around your neck. The unique silica gel material allows for reshaping to fit comfortably. Adjust the mount so that the camera is positioned optimally for your desired first-person view.



Figure 4.1: Example of the neck mount being worn with an action camera attached, ready for use.

5. Operating Instructions

The DJI Osmo Action Hanging Neck Mount is designed for ease of use, allowing you to capture hands-free footage in various scenarios.

- **Hands-Free Recording:** Once your camera is securely attached and the mount is comfortably worn, you can begin recording hands-free FPV footage. This is ideal for activities such as fishing, travel vlogging, or any situation where you need your hands free.
- **Adjusting Position:** The flexible silica gel material allows for minor adjustments to the mount's shape to optimize camera angle and comfort.
- **Compatibility:** This mount is compatible with Osmo Action, DJI Action 2, Osmo Action 3, Osmo Action 4, and Osmo Action 5 Pro cameras.

6. Maintenance

To ensure the longevity and proper function of your DJI Osmo Action Hanging Neck Mount, follow these maintenance guidelines:

- **Cleaning:** Wipe the mount with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the silica gel or plastic components.
- **Storage:** Store the mount in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the mount for any signs of wear, tear, or damage, especially around the camera mounting point and the flexible neckband.

7. Safety Information

Important Safety Precautions:

- **Extreme Sports:** Use caution when participating in certain extreme sports like rock climbing and diving. The mount is designed for general use and FPV footage, but its suitability for high-impact or underwater activities should be assessed carefully.
- **Suffocation Risk:** Ensure that no foreign objects get caught around your neck while wearing the mount to avoid the risk of suffocation. Always maintain awareness of your surroundings and the position of the mount.
- **Weight Limit:** Do not exceed the recommended maximum weight for attached devices (10 Kilograms).

8. Troubleshooting

Problem	Possible Cause	Solution
Camera feels loose on mount	Locking screw is not tightened sufficiently.	Ensure the Osmo Locking Screw is fully tightened. Check for any debris in the screw threads.
Mount is uncomfortable or does not fit well	Incorrect shaping or adjustment.	Reshape the silica gel neckband to better conform to your neck. Ensure it is not twisted.
Mount appears damaged	Physical stress or improper handling.	Discontinue use if the mount is visibly damaged. Contact DJI support for assistance.

9. Specifications

Feature	Detail
Product Dimensions	1.49 x 6.3 x 9.96 inches (3.78 x 16.0 x 25.3 cm)
Item Weight	5 ounces (141.75 grams)
Model Number	CP.AS.AA000008.01
Brand	DJI
Compatible Devices	Osmo Action, DJI Action 2, Osmo Action 3, Osmo Action 4, Osmo Action 5 Pro
Maximum Weight Recommendation	10 Kilograms
Country of Origin	China
UPC	190021087569

10. Warranty and Support

For information regarding warranty coverage and technical support for your DJI Osmo Action Hanging Neck Mount, please refer to the official DJI website or contact DJI customer service directly.
DJI Official Website: www.dji.com
For further assistance, you may also visit theDJI Store on Amazon.

© 2025 DJI. All rights reserved.