Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nikai NWM800SPN3

Nikai NWM800SPN3 Semi-Automatic Top Load Washing Machine User Manual

Model: NWM800SPN3

1. Safety Information

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

General Safety

- Ensure the washing machine is placed on a stable, level surface to prevent vibration and noise.
- Do not operate the machine if the power cord or plug is damaged. Contact qualified service personnel for repair.
- Keep children and pets away from the appliance during operation.
- Do not wash items that are soiled with flammable or explosive substances.
- Always unplug the machine before cleaning, maintenance, or if it will be unused for an extended period.

Electrical Safety

- Connect the machine to a properly grounded electrical outlet with the correct voltage (240 Volts).
- Do not use extension cords or adapters.
- Never touch the power plug with wet hands.

2. Product Overview

The Nikai NWM800SPN3 is a semi-automatic top load washing machine designed for efficient and convenient laundry care. It features a dual-tub system for separate washing and spinning functions.

Key Features

- **Dual Tub Design:** Separate tubs for washing and spinning.
- **Powerful Pulsator:** Ensures effective cleaning action.
- **Wash Mode Selection:** Allows selection of appropriate wash settings.
- **Lightweight and Portable:** Easy to move and position.

- **Low Noise Operation:** Designed for quiet performance.
- **Safety Switch for Spin Tub:** Enhances user safety during spin cycles.
- **Rust-Resistant Plastic Body:** Durable construction for longevity.

Components Diagram

The image below illustrates the main components of the Nikai NWM800SPN3 washing machine.



Image: Front view of the Nikai NWM800SPN3 semi-automatic top load washing machine, showing the wash tub on the left and the spin tub on the right, with control knobs located on the top panel.

3. Setup and Installation

Unpacking

- Carefully remove the washing machine from its packaging.
- Check for any damage during transit. If damaged, do not operate and contact your retailer.
- Remove all packing materials, including any protective films or tapes.

Placement

- Place the machine on a firm, flat, and level surface. Uneven surfaces can cause excessive vibration and noise.
- Ensure there is adequate ventilation around the machine.
- Avoid direct sunlight or placing near heat sources.

Water Connection

- Connect the water inlet hose (included) to a water tap.
- Ensure the connection is secure to prevent leaks.
- The machine uses a manual water fill system, so you will need to control the water flow from the tap.

Drainage

- Position the drain hose to allow water to flow freely into a sink or drain.
- Ensure the drain hose is not kinked or blocked.

Electrical Connection

- Plug the power cord into a grounded 240V electrical outlet.
- Do not share the outlet with other high-power appliances.

4. Operating Instructions

This semi-automatic washing machine requires manual transfer of clothes between the wash and spin tubs, and manual control of water filling and draining.

Washing Cycle

1. **Load Laundry:** Open the wash tub lid and place clothes loosely inside. Do not overload the machine beyond its 8kg capacity.
2. **Add Water:** Turn on the water tap and fill the wash tub to the desired level. You can manually control the water temperature by mixing hot and cold water if your tap allows.
3. **Add Detergent:** Add the appropriate amount of detergent directly into the wash tub.
4. **Select Wash Mode:** Turn the wash timer knob to select the desired wash duration and intensity (e.g., Gentle, Normal, Strong).
5. **Start Washing:** The pulsator will begin to agitate the clothes.
6. **Drain Water:** Once the wash cycle is complete, turn the drain selector knob to drain the water from the wash tub.

Rinsing Cycle

1. **Refill Water:** After draining, refill the wash tub with clean water for rinsing.
2. **Rinse Clothes:** Run a short wash cycle (e.g., 3-5 minutes) to rinse the clothes.

3. **Drain Water:** Drain the rinse water from the wash tub. Repeat rinsing if necessary.

Spin Cycle

1. **Transfer Clothes:** Carefully transfer the washed and rinsed clothes from the wash tub to the spin tub. Distribute them evenly to prevent imbalance.
2. **Close Lid:** Close the spin tub lid securely. The safety switch ensures the spin cycle only operates when the lid is closed.
3. **Set Spin Timer:** Turn the spin timer knob to select the desired spin duration (e.g., 1-5 minutes).
4. **Start Spinning:** The spin tub will rotate at high speed to remove excess water.
5. **Remove Clothes:** Once the spin cycle is complete and the tub has stopped, open the lid and remove the spun clothes.

5. Maintenance and Care

Cleaning the Exterior

- Wipe the exterior of the machine with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic body.

Cleaning the Lint Filter

- Regularly check and clean the lint filter located inside the wash tub.
- Remove any accumulated lint or debris to ensure efficient operation.

Storage

- If storing the machine for an extended period, ensure all water is drained from both tubs and hoses.
- Unplug the power cord and store it safely.
- Store in a dry, well-ventilated area, away from direct sunlight and extreme temperatures.

6. Troubleshooting

Before contacting service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Machine does not start	Power cord not plugged in; Power outage; Timer knob not set.	Ensure power cord is securely plugged in; Check household power supply; Set the wash/spin timer.
No water filling	Water tap is off; Water pressure is too low; Water inlet hose is kinked.	Turn on the water tap; Check water supply pressure; Straighten the water inlet hose.
Machine vibrates excessively or is noisy	Machine is not level; Laundry is unevenly distributed in the tub.	Adjust the machine to be level; Redistribute laundry evenly in the wash or spin tub.
Water does not drain	Drain hose is kinked or blocked; Drain selector knob is not set to 'Drain'.	Straighten or clear the drain hose; Turn the drain selector knob to the 'Drain' position.

Problem	Possible Cause	Solution
Spin tub does not spin	Spin tub lid is open; Safety switch engaged; Laundry is severely unbalanced.	Ensure spin tub lid is fully closed; Redistribute laundry evenly.

7. Specifications

Brand	Nikai
Model	NWM800SPN3
Type	Semi-Automatic Top Load Washing Machine
Capacity	8 kg (8 Liters)
Dimensions (L x W x H)	77 x 44 x 90 cm
Weight	25 kg
Voltage	240 Volts
Material	Plastic
Color	White
Special Feature	Portable
Included Components	Pipe accessories

8. Warranty and Support

The Nikai NWM800SPN3 washing machine typically comes with a 1-year manufacturer's warranty, as indicated in the product description. Please refer to your purchase documentation for specific warranty terms and conditions.

For technical support, service, or warranty claims, please contact your retailer or the authorized Nikai service center in your region. Keep your proof of purchase handy when seeking support.

For further assistance, you may visit the official Nikai website or consult the contact information provided with your product packaging.

© 2026 Nikai. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FTLN6D3

More documents and user manuals: **https://manuals.plus/**