Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lenco DAR-060

Lenco DAR-060 DAB+ Table Radio User Manual

Model: DAR-060

1. Introduction

The Lenco DAR-060 is a compact and stylish table radio designed for versatile audio entertainment. This unit combines modern digital radio (DAB+) with traditional FM reception, a built-in CD player, Bluetooth connectivity for wireless streaming, and an AUX input for wired external devices. Its user-friendly interface makes it suitable for various environments, including kitchens, living rooms, and bedrooms.

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Lenco DAR-060 to ensure optimal performance and longevity.



Figure 1: The Lenco DAR-060 radio, front view. It features a central display, control knob, various function buttons, a CD tray, and two speaker grilles. The telescopic antenna is extended. The included remote control is shown to the right of the unit.

2. Setup

2.1 Unpacking

- Carefully remove the unit from its packaging.
- Check that all accessories are present: Lenco DAR-060 unit, remote control, and this instruction manual.
- Retain the packaging for future transport or storage.

2.2 Power Connection

1. Ensure the unit is placed on a stable, flat surface.
2. Plug the AC power cord into the power inlet on the rear of the unit.
3. Insert the other end of the power cord into a standard AC wall outlet (230V ~ 50Hz).



Figure 2: The rear panel of the Lenco DAR-060 radio. It shows the fixed power cable extending from the left side and the retracted telescopic antenna mounted horizontally across the back. Two bass reflex ports are visible on either side.

2.3 Antenna Adjustment

- For optimal DAB+ and FM radio reception, fully extend the telescopic antenna.
- Adjust the angle and direction of the antenna to achieve the best signal quality.

2.4 Initial Power On

- Press the **POWER** button on the unit or remote control to turn on the radio.
- The display will illuminate, and the unit will typically start in the last used mode or DAB+ mode.

3. Operating Instructions

3.1 General Controls

- **POWER:** Turns the unit on or off (standby).
- **MODE:** Switches between DAB+, FM, CD, Bluetooth, and AUX modes.
- **VOLUME +/-:** Adjusts the audio output level.
- **TUNE/SELECT Knob:** Rotates to navigate menus or tune frequencies, press to confirm selections.
- **PLAY/PAUSE:** Starts or pauses playback in CD and Bluetooth modes.
- **SKIP ◀◀ / ▶▶:** Skips tracks/stations or fast forwards/rewinds.

3.2 DAB+ Radio Operation

1. Press the **MODE** button until DAB+ mode is selected.
2. Upon first use, the radio will automatically perform a full scan for available DAB+ stations. This may take a few minutes.
3. Once the scan is complete, a list of available stations will be displayed.
4. Rotate the **TUNE/SELECT** knob to browse through the station list.
5. Press the **TUNE/SELECT** knob to select and listen to a station.

3.3 FM Radio Operation

1. Press the **MODE** button until FM mode is selected.
2. To auto-scan for stations, press and hold the **TUNE/SELECT** knob or the **SCAN** button (if available on remote). The radio will scan and stop at the next strong station.
3. To manually tune, rotate the **TUNE/SELECT** knob to adjust the frequency.

3.4 CD Player Operation

1. Press the **MODE** button until CD mode is selected.
2. Gently insert a CD into the CD slot with the label side facing up. The unit will automatically load the CD.
3. Playback should begin automatically. If not, press the **PLAY/PAUSE** button.
4. Use the **SKIP ◀◀ / ▶▶** buttons to navigate between tracks.
5. Press **PLAY/PAUSE** to pause or resume playback.

3.5 Bluetooth Operation

1. Press the **MODE** button until Bluetooth mode is selected. The display will show "Bluetooth Pairing" or similar, indicating it's ready to connect.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "DAR-060" from the list of devices.
4. Once paired, the unit will confirm the connection. You can now play audio from your device through the DAR-060.

5. Use your connected device or the DAR-060's controls for playback (play/pause, skip).

3.6 AUX Input Operation

1. Connect an external audio device (e.g., MP3 player) to the AUX IN jack on the DAR-060 using a 3.5mm audio cable (not included).
2. Press the **MODE** button until AUX mode is selected.
3. Play audio from your connected external device. The sound will be output through the DAR-060 speakers.
4. Control playback and volume primarily from your external device.

4. Maintenance

4.1 Cleaning

- Always unplug the unit from the power outlet before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces of the unit.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- For the CD lens, use a specialized CD lens cleaner disc if necessary.

4.2 Storage

- If the unit will not be used for an extended period, unplug it from the power outlet.
- Store the unit in a cool, dry place, away from direct sunlight and extreme temperatures.
- It is recommended to store the unit in its original packaging to protect it from dust and damage.

5. Troubleshooting

Before contacting customer support, please refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
No power	Power cord not properly connected.	Check if the power cord is securely plugged into the unit and the wall outlet.
No sound	Volume is too low or muted. Incorrect audio source selected.	Increase the volume. Press the MODE button to select the correct audio source.
Poor radio reception	Antenna not extended or poorly positioned. Interference from other devices.	Fully extend and adjust the telescopic antenna. Try repositioning the unit away from other electronic devices.
Bluetooth not connecting	Unit not in pairing mode. Device too far away. Bluetooth disabled on external device.	Ensure the DAR-060 is in Bluetooth pairing mode. Move your device closer to the unit. Enable Bluetooth on your external device.
CD not playing	CD inserted incorrectly. CD is dirty or scratched.	Ensure the CD is inserted with the label side up. Clean the CD with a soft cloth or try another CD.

6. Specifications

Model Number	DAR-060
Power Source	AC 230V ~ 50Hz
Power Output	30 Watts
Connectivity	Bluetooth, AUX-in
Radio Tuner	DAB+, FM
Supported Audio Format	CD Audio
Audio Output Mode	Stereo
Dimensions (L x W x H)	38 x 21.2 x 13.9 cm
Weight	3.3 kg (3300 Grams)

7. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Lenco website. For technical support or service inquiries, please contact Lenco customer service through their official channels.

You can find more information and support resources on the official Lenco website:www.lenco.com

© 2023 Lenco. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FXWV2V9

More documents and user manuals: **https://manuals.plus/**