Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Victrola VTA-65-MAH

Victrola 3-in-1 Turntable User Manual

Model: VTA-65-MAH

Brand: Victrola

Introduction

This user manual provides essential information for the safe and efficient operation of your Victrola 3-in-1 Turntable. Please read this manual thoroughly before using the product and retain it for future reference.

Safety Information

Always adhere to the following safety guidelines to prevent electric shock, fire, or injury:

- Do not expose the unit to rain or moisture.
- Do not block any ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the unit during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

Package Contents

Verify that all items are present in the package:

- Victrola 3-in-1 Turntable (VTA-65-MAH)
- Removable Dust Cover
- Power Adapter
- User Manual (this document)

Product Overview

Familiarize yourself with the main components of your Victrola 3-in-1 Turntable.



Figure 1: Front view of the Victrola 3-in-1 Turntable with the dust cover open, highlighting the turntable platter, tonearm, and the front control panel with buttons and knobs.



Figure 2: Side view of the Victrola 3-in-1 Turntable, illustrating the integrated speaker grille on the side and the layout of the control panel from a different angle.

- **Turntable Platter:** Where records are placed for playback.
- **Tonearm:** Holds the stylus (needle) for reading grooves on records.
- **Dust Cover:** Protects the turntable from dust when not in use.
- **Control Panel:** Includes power button, mode selection, tuning, and volume controls.
- **Built-in Stereo Speakers:** Integrated speakers for audio output.
- **RCA Output:** For connecting to external audio systems.
- **Headphone Jack:** For private listening.

Setup

1. **Unpacking:** Carefully remove the unit from its packaging. Retain the packaging for future transport or storage.
2. **Placement:** Place the turntable on a flat, stable surface away from direct sunlight, heat sources, or excessive dust. Ensure adequate ventilation around the unit.
3. **Dust Cover Installation:** Gently attach the clear acrylic dust cover to the hinges at the back of the unit.
4. **Power Connection:** Connect the supplied power adapter to the DC IN jack on the back of the unit, then plug the adapter into a wall outlet.
5. **Initial Power On:** Press the Power button on the front panel to turn on the unit.

Operating Instructions

Playing Records

1. Open the dust cover.
2. Place a record on the turntable platter.
3. Select the appropriate speed (33 1/3, 45, or 78 RPM) using the speed selector switch.
4. Release the tonearm lock.
5. Lift the tonearm using the cueing lever.
6. Position the tonearm over the desired track of the record.
7. Gently lower the tonearm onto the record using the cueing lever. The record will begin to play.
8. Adjust the volume using the VOLUME knob.
9. At the end of the record, the tonearm will automatically return to its rest position (auto-stop feature). Lift the tonearm, return it to the rest, and engage the tonearm lock.

Bluetooth Operation

The unit can stream music wirelessly from a Bluetooth-enabled device.

1. Turn on the unit and select Bluetooth mode using the mode button. The Bluetooth indicator will flash.
2. Enable Bluetooth on your external device (e.g., smartphone, tablet) and search for "Victrola Turntable".
3. Select "Victrola Turntable" to pair. Once paired, the Bluetooth indicator will stop flashing and remain solid.
4. You can now play music from your device through the turntable's speakers. Adjust volume on both the turntable and your device.

FM Radio Operation

Listen to your favorite FM radio stations.

1. Turn on the unit and select FM mode using the mode button.
2. Extend the FM antenna for optimal reception.
3. Use the tuning knob to select your desired radio station.
4. Adjust the volume using the VOLUME knob.

Maintenance

Proper maintenance ensures the longevity of your turntable.

- **Cleaning the Unit:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Cleaning the Stylus:** Use a soft brush to gently clean the stylus from back to front. Do not touch the stylus with your fingers.
- **Dust Cover:** Keep the dust cover closed when not in use to prevent dust accumulation on the platter and stylus.

Troubleshooting

Problem	Possible Cause	Solution
No Power	Power cord not connected; Power outlet not active.	Ensure power cord is securely connected. Try a different outlet.
No Sound from Speakers	Volume too low; Incorrect mode selected.	Increase volume. Select the correct input mode (PHONO, BT, FM).
Record Skips	Record is dirty or scratched; Stylus is worn or dirty; Turntable not level.	Clean the record. Clean or replace the stylus. Ensure the turntable is on a level surface.
Bluetooth Pairing Fails	Device too far; Bluetooth not enabled on external device.	Move device closer. Ensure Bluetooth is enabled and "Victrola Turntable" is selected.

Specifications

- **Model:** VTA-65-MAH
- **Dimensions:** 10.79 x 5.14 x 12.74 inches (W x H x D)
- **Weight:** 4.89 pounds
- **Speeds:** 33 1/3, 45, 78 RPM
- **Connectivity:** Bluetooth, 3.5mm Aux-In, RCA Output
- **Features:** FM Radio, Built-in Stereo Speakers, Dust Cover
- **Material:** Acrylic (Dust Cover)

Warranty and Support

Victrola products are designed with quality and reliability in mind. For detailed warranty information and customer support, please refer to the official user manual provided with your product or visit the Victrola website. You can also find additional support and FAQs at the Victrola Store on Amazon.
For a downloadable PDF version of the user manual, please visit:Official User Manual (PDF)

© 2024 Victrola. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07G29PBH5

More documents and user manuals: **https://manuals.plus/**