HXSJ HD 720P USB Webcam

HXSJ HD 720P USB Webcam User Manual

Model: HD 720P USB Webcam

1. Introduction

This manual provides instructions for the HXSJ HD 720P USB Webcam. This device is designed for video communication and recording on personal computers, offering high-definition video and integrated audio capabilities.



Image 1.1: Overview of the HXSJ HD 720P USB Webcam, showing its design and key features like HD 720P resolution, integrated camera, and microphone.

2. Setup

2.1 Package Contents

- HXSJ HD 720P USB Webcam
- User Manual (this document)

2.2 Connecting the Webcam

1. Unpack the webcam from its packaging.
2. Locate an available USB port on your computer (desktop or laptop).
3. Insert the USB cable of the webcam into the computer's USB port. The webcam is plug-and-play and typically does not require additional driver installation for most operating systems (e.g., Windows 10, macOS).



Image 2.1: Rear view of the webcam, illustrating the integrated USB cable for connection to a computer.

2.3 Placing the Webcam

The webcam features a versatile clip-on design, allowing it to be securely mounted on various surfaces.

- **On a Monitor/Laptop Screen:** Open the clip base and place it over the top edge of your monitor or laptop screen. Adjust the angle to ensure the webcam is stable and facing you.
- **On a Flat Surface:** Fold the clip base to form a stand, and place the webcam on a desk or other flat surface.



Image 2.2: Illustrations demonstrating the adjustable clip-on base for mounting on screens or standing on flat surfaces.



Image 2.3: The webcam positioned on top of a laptop screen, ready for use.

3. Operating Instructions

3.1 Initial Use

1. After connecting the webcam, your operating system should automatically detect it.
2. Open your preferred video conferencing or recording application (e.g., Skype, Zoom, Microsoft Teams, OBS Studio).
3. In the application's settings, select the HXSJ HD 720P USB Webcam as your video input device and its integrated microphone as your audio input device.



Image 3.1: A computer screen displaying a video call, indicating the webcam's functionality for online communication.

3.2 Adjusting Focus

The webcam features a manual focus lens. To adjust the image clarity:

- Gently rotate the outer ring of the lens until the image on your screen appears sharp and clear.

3.3 Microphone Usage

The webcam includes a built-in noise-canceling microphone. Ensure it is selected as the audio input device in your application settings for optimal sound quality during calls or recordings.

4. Maintenance

4.1 Cleaning

- Use a soft, dry cloth to clean the webcam's body.

- For the lens, use a lens cleaning cloth and a specialized lens cleaning solution if necessary. Avoid abrasive materials or harsh chemicals.

4.2 Storage

- When not in use, store the webcam in a clean, dry place away from direct sunlight and extreme temperatures.
- Protect the lens from scratches and dust.

5. Troubleshooting

If you encounter issues with your HXSJ HD 720P USB Webcam, refer to the following common solutions:

- **Webcam not detected or not working:**
  - Ensure the USB cable is securely connected to a working USB port on your computer.
  - Try connecting the webcam to a different USB port.
  - Restart your computer.
  - Check your operating system's Device Manager (Windows) or System Information (macOS) to see if the webcam is listed.
  - Verify that your video conferencing software is updated to the latest version.
- **Poor image quality or blurry video:**
  - Manually adjust the focus by rotating the lens ring until the image is clear.
  - Ensure adequate lighting in your environment.
  - Clean the webcam lens with a soft, lint-free cloth.
- **No audio or poor audio quality:**
  - Confirm that the webcam's built-in microphone is selected as the audio input device in your application's settings and your operating system's sound settings.
  - Check the microphone volume levels in your system and application settings.
  - Ensure there are no obstructions covering the microphone openings on the webcam.
- **Video appears green or distorted:**
  - Try connecting the webcam to a different USB port or another computer to rule out a port or system issue.
  - Restart your computer and the application you are using.

6. Specifications




Image 6.1: Dimensions of the HXSJ HD 720P USB Webcam.

Feature	Specification
Brand	HXSJ
Model	HD 720P USB Webcam
Video Capture Resolution	720p
Photo Sensor Technology	CMOS
Connectivity Technology	USB
Special Feature	Low Light
Lens Type	Zoom (Manual Focus)
Effective Still Resolution	1 MP
Hardware Platform	Mac, PC, Laptop
Item Weight	3.52 ounces
Package Dimensions	4.5 x 4.25 x 2 inches
ASIN	B07G6WV9YJ
Date First Available	August 16, 2018

7. Warranty and Support

For information regarding warranty coverage or technical support, please refer to the documentation provided at the time of purchase or contact the retailer. Keep your purchase receipt as proof of purchase.

© 2023 HXSJ. All rights reserved.