Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro TQL32R4PR005

Instruction Manual for Passion-Electro Replacement Remote Control for POLAROID TQL32R4PR005 TV

1. Introduction

This manual provides instructions for the Passion-Electro Replacement Remote Control, designed specifically for the POLAROID TQL32R4PR005 television model. This remote control offers similar functionality to your original remote and requires no programming.



Image: Front angled view of the Passion-Electro replacement remote control, showing the brand logo and main buttons.

2. Setup

2.1 Installing Batteries

Before using your new remote control, you must install two AAA batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two 1.5V AAA (LR03) batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control, illustrating the location of the battery compartment cover.



Image: Straight back view of the remote control, clearly showing the battery compartment.

3. Operating Instructions

This replacement remote control is pre-programmed for the POLAROID TQL32R4PR005 TV and requires no additional setup. Once batteries are installed, it is ready for immediate use.

3.1 Basic Functions

- **Power Button:** Press to turn the TV on or off.
- **Channel Buttons (0-9):** Enter channel numbers directly.
- **Channel Up/Down:** Navigate through channels sequentially.
- **Volume Up/Down:** Adjust the sound level.
- **Mute Button:** Silence the TV audio.

- **Menu Button:** Access the TV's on-screen menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and confirm selections.
- **Source/Input Button:** Select different input sources (HDMI, AV, etc.).



Image: Front view of the remote control, highlighting the power, mute, and numerical input buttons.



Image: Side view of the remote control, providing a comprehensive view of all buttons and their arrangement.

4. Maintenance

4.1 Battery Replacement

When the remote control's performance degrades or the LED indicator no longer lights up, it is time to replace the batteries. Follow the steps in Section 2.1 to replace the two AAA batteries.
Note: Always replace both batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

5. Troubleshooting

Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-).
- **Replace Batteries:** If the batteries are old or depleted, replace them with two new 1.5V AAA batteries.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the TV's infrared receiver. Obstructions can block the signal.
- **Remote Control Sensor:** Verify that the TV's remote control sensor is not blocked or dirty.
- **TV Compatibility:** Confirm that your TV model is indeed POLAROID TQL32R4PR005. This remote is specifically designed for this model.

6. Specifications

Brand	Passion-Electro
Compatible Devices	POLAROID TQL32R4PR005 Television
Model	Replacement Remote Control for TQL32R4PR005
Color	Black
Special Features	No programming required
Controller Type	Button Control
Battery Type	2 x 1.5V AAA (LR03) batteries (not included)
Country of Origin	China

7. Warranty and Support

Information regarding specific warranty details is not provided in the product description. For support or warranty inquiries, please contact your retailer or the manufacturer, Passion-Electro, directly.
You may find contact information on the packaging or through the retailer's website where the product was purchased.

© 2024 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07G6X7SQC

More documents and user manuals: **https://manuals.plus/**