Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro 22AV733G

Passion-Electro Replacement Remote Control for TOSHIBA 22AV733G TV User Manual

Model: 22AV733G

1. Introduction

This manual provides instructions for the Passion-Electro replacement remote control, specifically designed for TOSHIBA 22AV733G televisions. This remote offers full functionality comparable to the original remote control without requiring any programming. Simply insert the batteries and it is ready for use.



Image 1.1: Front view of the Passion-Electro Replacement Remote Control.

2. Safety Information

- Do not expose the remote control to direct sunlight, heat sources, or extreme temperatures.
- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not immerse the remote control in water or any other liquid.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage.
- Dispose of used batteries according to local regulations.

3. Package Contents

The package should contain:

- 1 x Passion-Electro Replacement Remote Control for TOSHIBA 22AV733G TV

Note: Batteries are not included and must be purchased separately.

4. Setup

4.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open it.



Image 4.1: Back view of the remote control showing the battery compartment.

3. Insert two (2) AAA 1.5V batteries (LR03-AAA) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.



Image 4.2: Close-up of the battery compartment, indicating correct battery polarity.

4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

The remote control is now ready for use with your TOSHIBA 22AV733G TV. No programming is required.

5. Operating Instructions

This remote control is designed to replicate the functions of your original TOSHIBA 22AV733G TV remote. Point the remote control directly at your television's infrared receiver.

5.1 Basic Functions

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** Selects TV channels directly.
- **Channel Up/Down:** Changes channels sequentially.
- **Volume Up/Down:** Adjusts the sound volume.
- **Mute Button:** Mutes or unmutes the TV sound.
- **Menu Button:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigates through TV menus and confirms selections.
- **Source/Input Button:** Changes the input source (e.g., HDMI, AV).
- **Exit Button:** Exits the current menu or function.
- **Info Button:** Displays information about the current program.

Note: The exact layout and labeling of buttons may vary slightly from the image provided or your original remote, but their functions remain consistent.



Image 5.1: Top view of the remote control, highlighting various function buttons.

6. Maintenance

- Clean the remote control regularly with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical agents.
- Keep the remote control free from dust and dirt.

7. Troubleshooting

7.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-).
- **Replace Batteries:** If the batteries are old or depleted, replace them with new AAA 1.5V batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared receiver.
- **Distance:** Ensure you are within the effective operating range of the TV's infrared receiver.

7.2 Specific Buttons Not Working

- **Clean Buttons:** Dirt or debris might be interfering with button contacts. Gently clean around the buttons with a soft, dry cloth.
- **Test Other Functions:** If only a few buttons are unresponsive, it might indicate a specific issue with those buttons. If the entire remote is unresponsive, refer to "Remote Control Not Responding" above.

8. Specifications

Brand	Passion-Electro
Compatible Devices	TOSHIBA 22AV733G TV
Connectivity Technology	Infrared

Controller Type	Button Control
Battery Type	2 x AAA 1.5V (LR03-AAA)
Color	Black
Special Feature	No Programming Required

9. Warranty and Support

For warranty information or technical support, please contact your retailer or the manufacturer, Passion-Electro, directly. Refer to your purchase documentation for specific warranty terms and contact details.
You can often find support information on the seller's page on the platform where you purchased the product. For Amazon purchases, visit the Passion-Electro seller page.

© 2026 Passion-Electro. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07G9JG45H

More documents and user manuals: **https://manuals.plus/**