Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro NB848

Passion-Electro Replacement Remote Control for FUNAI NB848 DVD/BD Player - Instruction Manual

Introduction

This manual provides instructions for the Passion-Electro replacement remote control, specifically designed for use with FUNAI NB848 DVD/BD players. This remote is a specialized replacement unit, not a generic universal remote, and requires no programming. Simply insert the batteries to begin operation.

Setup

1. Installing Batteries

The remote control requires two (2) AAA 1.5V (LR03-AAA) batteries. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Rear view of the Passion-Electro replacement remote control, showing the battery compartment cover. This is where two AAA batteries are inserted.



Bottom view of the Passion-Electro replacement remote control, highlighting the battery compartment cover. This view provides a clear indication of where to open the compartment for battery installation.

Operating

Basic Remote Control Functions

This replacement remote control offers functionality comparable to the original FUNAI NB848 remote. The button layout is designed for intuitive use. Point the remote directly at your FUNAI NB848 DVD/BD player for optimal performance.



Front view of the Passion-Electro replacement remote control. This image displays the full layout of buttons, including power, mute, input selection (TV, SAT, DVD, AUX), number pad, navigation cluster (OK, arrow keys), playback controls, and dedicated smart TV buttons. The Passion-Electro logo is visible at the bottom.

- **Power Button:** Located at the top left (red button), turns the device on or off.
- **Mute Button:** Located at the top right, mutes or unmutes the audio.
- **Input Selection:** Buttons like TV, SAT, DVD, AUX allow you to switch between different input sources.
- **Number Pad:** Use for direct channel selection or inputting numbers.
- **Navigation Cluster:** The central circular pad with **OK** button and arrow keys (up, down, left, right) is used for menu navigation and selection.
- **Playback Controls:** Buttons for Play, Pause, Stop, Fast Forward, Rewind, Skip Track.
- **Menu/Exit:** Access and exit device menus.
- **Volume/Channel:** Dedicated buttons for adjusting volume and changing channels.

Maintenance

Care and Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, or immerse it in liquids.

Troubleshooting

Troubleshooting Common Issues

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the FUNAI NB848 DVD/BD player.
  - Make sure you are pointing the remote directly at the device's infrared receiver.
- **Limited functionality:**
  - While this remote is designed to replicate original functions, some advanced or rarely used features specific to the original remote might behave differently.
  - Ensure the device you are trying to control (FUNAI NB848) is powered on and functioning correctly.

Specifications

Brand	Passion-Electro
Compatible Devices	FUNAI NB848 (DVD/BD Player)
Battery Type	2 x AAA (1.5V LR03-AAA) Alkaline batteries
Batteries Included	No

Item Weight	100 g
Special Features	No programming required

Warranty and Support

For any questions, issues, or support regarding your Passion-Electro replacement remote control, please contact the seller directly. Specific warranty details may vary and should be confirmed with the point of purchase or the seller, Passion-Electro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07G9K3PNS

More documents and user manuals: **https://manuals.plus/**