Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro DPVR-2600

Passion-Electro Replacement Remote Control User Manual

For FUNAI DPVR-2600 VCR and DVD/BD Players

Introduction

This manual provides instructions for the Passion-Electro replacement remote control, designed to operate your FUNAI DPVR-2600 VCR and DVD/BD player. This specialized remote control is engineered to replicate the functions of your original device remote without requiring complex programming.



Image: Front view of the Passion-Electro replacement remote control, showing all buttons and the brand logo at the bottom.

Setup

Battery Installation

The remote control requires two AAA (LR03) 1.5V batteries (not supplied). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

No programming is necessary. Once batteries are installed, the remote is ready for use.



Image: Back view of the remote control, highlighting the battery compartment cover.



Image: Bottom view of the remote control, showing the edge of the battery compartment.

Operating Instructions

This remote control is designed to provide functionality similar to your original FUNAI DPVR-2600 remote. Point the remote directly at your device for optimal performance. An LED indicator on the remote will illuminate with each button press.

Key Functions Overview

The remote features a standard layout for VCR and DVD/BD operations. While the exact button layout is depicted in the product images, common functions include:

- **Power:** Turns the device on or off.
- **Mute:** Mutes or unmutes audio.
- **TV/SAT/DVD/AUX:** Selects input sources.
- **Menu/Exit:** Navigates device menus.
- **Number Buttons (0-9):** For direct channel selection or inputting numbers.
- **Source:** Cycles through available input sources.
- **Navigation (Up/Down/Left/Right) & OK:** For menu navigation and selection.
- **Playback Controls:** Play, Pause, Stop, Fast Forward, Rewind (often represented by colored buttons or dedicated symbols).
- **Info/EPG:** Displays program information or Electronic Program Guide.
- **Volume Up/Down:** Adjusts audio volume.
- **Channel Up/Down:** Changes channels.



Image: Side view of the remote control, showing the top section with Power, Mute, and input selection buttons.



Image: Another side view of the remote control, focusing on the number pad and directional navigation buttons.



Image: Angled top view of the remote control, providing a comprehensive look at the entire button layout from Power to the colored function keys.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the LED indicator fails to light up consistently. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-).
- **Replace Batteries:** If the batteries are old or weak, replace them with fresh AAA batteries.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the infrared sensor on your FUNAI DPVR-2600 device. Obstructions can block the signal.
- **Distance:** Operate the remote within its effective range (up to 10 meters).

Some Functions Do Not Work

While this remote is designed to replicate the original remote's functions, some highly specific or advanced features of the original device might not be fully supported by a replacement remote. Verify that the function you are trying to use is a standard feature typically found on universal or replacement remotes. If a critical function is missing, consult the device's original manual for alternative control methods.

Specifications

Brand	Passion-Electro
Compatible Devices	FUNAI DPVR-2600 (VCR, DVD/BD)
Connectivity Technology	Infrared (IR)
Color	Black
Special Features	No programming required
Battery Type	2 x AAA (LR03) 1.5V (not supplied)
Maximum Range	10 Meters
Country of Origin	China

Warranty Information

Specific warranty details for this product are not provided in the available information. Please refer to your purchase documentation or contact the retailer for warranty terms and conditions.

Customer Support

For further assistance or inquiries regarding your Passion-Electro replacement remote control, please contact your point of purchase or refer to the contact information provided by the seller.

© 2023 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07G9KKS3Q

More documents and user manuals: **https://manuals.plus/**