Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro CU-A019

Passion-Electro Replacement Remote Control for PIONEER CU-A019 User Manual

Introduction

This manual provides detailed instructions for the Passion-Electro replacement remote control, designed for use with PIONEER CU-A019 HI-FI systems. This remote offers full functionality similar to the original remote control without requiring any programming.

Please read this manual carefully to ensure proper setup and operation of your new remote control.

Setup

1. Battery Installation

The remote control requires two 1.5V AAA (LR03) batteries (not supplied). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image 1: Back view of the remote control with the battery compartment. The compartment is located at the bottom rear of the remote, designed to hold two AAA batteries.

2. Initial Use

No programming is required for this replacement remote control. Once the batteries are correctly installed, the remote is ready for immediate use with your PIONEER CU-A019 HI-FI system.

Operating Instructions

This section details the functions of the various buttons on your remote control.



Image 2: Front view of the Passion-Electro remote control, displaying the layout of all buttons including power, number pad, navigation, and function keys.

POWER (Red Button): Turns the device on or off.

MUTE: Mutes or unmutes the audio output.

Number Buttons (0-9): Used for direct channel selection or inputting numerical values.

TV / **SAT** / **DVD** / **AUX:**Selects the corresponding input source.

MENU: Accesses the main menu of the connected device.

EXIT: Exits the current menu or function.

SHIFT: May activate secondary functions of certain buttons (refer to your device's manual for specific uses).

SOURCE: Cycles through available input sources.

SIZE / **SETUP** / **RUST:** These buttons typically access specific settings or display options. Their exact function depends on the connected device.

Navigation Pad (Up, Down, Left, Right, OK): Used to navigate through menus and confirm selections.

VOL +/-: Adjusts the volume level.

CH +/- (or P +/-): Changes channels or navigates through program lists.

BACK: Returns to the previous screen or menu.

SLEEP: Sets a sleep timer for the device.

TWOTV: Specific function, likely for picture-in-picture or dual-screen modes, if supported by your device.

INFO: Displays information about the current program or input.

EPG: Accesses the Electronic Program Guide.

FAV: Accesses favorite channels or content.

NETTV / **SMART:** Buttons for accessing smart TV features or internet-connected services.

Colored Buttons (Red, Green, Yellow, Blue): Often used for specific interactive functions within menus or smart TV applications.

Playback Controls (Play, Pause, Stop, Rewind, Fast Forward): Used for controlling media playback.

Note: The functionality of some buttons may vary slightly depending on the specific model and features of your PIONEER CU-A019 HI-FI system. Refer to your device's original manual for detailed information on specific functions.

Maintenance

Cleaning

To clean your remote control, use a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AAA (LR03) batteries. Do not mix old and new batteries, or different types of batteries.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage to the remote.

Troubleshooting

Remote control is not responding:

- Ensure the batteries are correctly installed with the correct polarity (+/-).
- Replace the batteries with fresh ones.
- Ensure there are no obstructions between the remote control and the device's infrared receiver.
- Make sure you are within the effective operating range (up to 10 meters).

Certain buttons do not work:

- Verify that the button's function is supported by your PIONEER CU-A019 HI-FI system. Some buttons may be specific to certain models or features.
- Clean the remote control, especially around the non-working buttons, to ensure no debris is interfering.

LED indicator does not light up:

- This indicates a power issue. Check or replace the batteries.

Specifications

Brand	Passion-Electro
Model Compatibility	PIONEER CU-A019 HI-FI systems
Color	Black
Batteries Required	2 x 1.5V AAA (LR03) (not supplied)
Maximum Range	10 Meters
Maximum Supported Devices	1

Warranty and Support

This Passion-Electro replacement remote control is a new product designed to offer functionality similar to an original remote. Specific warranty details are not provided in the product information. For any issues or support inquiries, please contact the seller, Passion-Electro, directly through your purchase platform.

Ensure to retain your purchase receipt for any potential support claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07G9KLG1C

More documents and user manuals: **https://manuals.plus/**