Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro RM-C1223

User Manual: Passion-Electro Replacement Remote Control

Model: RM-C1223
Brand: Passion-Electro

1. Introduction

This manual provides instructions for the Passion-Electro dedicated replacement remote control for JVC RM-C1223 TV models. This remote is designed to provide full functionality similar to the original remote without the need for complex programming. Simply insert the batteries, and it is ready for immediate use.



Image 1: Top view of the remote control, displaying all functional buttons.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA (LR03) 1.5V batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image 2: Back of the remote control with the battery compartment.

Once batteries are installed, the remote is ready for use. No additional programming is required.

3. Operating Instructions

This replacement remote control is designed to function immediately with your JVC RM-C1223 TV model after battery installation. Point the remote directly at your television's infrared (IR) receiver.

- **Power Button:** Press to turn the TV on or off.
- **Number Buttons (0-9):** Use to select channels directly.
- **Channel Up/Down:** Navigate through channels sequentially.
- **Volume Up/Down:** Adjust the television's volume.
- **Mute Button:** Temporarily silence the TV audio.
- **Menu Button:** Access the TV's on-screen menu.
- **Navigation Buttons (Arrow Keys & OK):** Use to navigate through menus and confirm selections.
- **Source/Input Button:** Switch between different input sources (e.g., HDMI, AV).
- **LED Indicator:** A small LED light on the remote will illuminate with each button press, confirming signal transmission.

Refer to your television's original user manual for specific functions and menu navigation details, as this remote replicates those functions.

4. Maintenance

4.1 Battery Replacement

When the remote control's performance degrades or the LED indicator no longer lights up, it is time to replace the batteries. Follow the battery installation steps outlined in Section 2.1.

- Always replace both batteries at the same time.
- Use new, high-quality AAA (LR03) 1.5V alkaline batteries for optimal performance.
- Do not mix old and new batteries, or different types of batteries.

- Remove batteries if the remote will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

4.2 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

5. Troubleshooting

If the remote control is not functioning as expected, consider the following troubleshooting steps:

- **Remote Not Responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh ones.
  - Check if the LED indicator lights up when a button is pressed. If not, batteries may be dead or incorrectly installed.
- **Remote Not Controlling TV:**
  - Ensure there is a clear line of sight between the remote control and the TV's IR receiver. Obstructions can block the signal.
  - Make sure you are within the effective operating range (up to 10 meters).
  - Verify that the remote control is indeed for the JVC RM-C1223 model.
- **Specific Buttons Not Working:**
  - This is rare for a dedicated replacement remote. If only a few buttons fail, try replacing batteries. If the issue persists, the remote may be faulty.

If these steps do not resolve the issue, please contact customer support.

6. Specifications

Feature	Detail
Brand	Passion-Electro
Model Number	RM-C1223
Compatibility	JVC RM-C1223 TV models
Color	Black
Battery Type	2 x AAA (LR03) 1.5V batteries
Maximum Range	10 Meters
Manufacturer	Passion-Electro
Country of Origin	China

7. Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact the seller

directly. As a dedicated replacement remote, this product is typically covered by the seller's standard return and replacement policies.

For technical support or further assistance, please contact Passion-Electro customer service through your purchase platform or the contact details provided by the seller.

© 2023 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GBDMSR9

More documents and user manuals: **https://manuals.plus/**