Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro RC-QW33

Passion-Electro Replacement Remote Control for JVC RC-QW33 HI-FI - Instruction Manual

1. Product Overview

This document provides instructions for the Passion-Electro Replacement Remote Control, model RC-QW33, designed for JVC HI-FI systems. This is a specialized replacement remote control, not a generic universal remote. It provides access to all functions of the original remote control. No programming is required. Simply insert batteries to begin use. The remote features an LED indicator. Please note that the button layout may vary slightly depending on the specific brand and model of the original remote it replaces.

- New product, ready for immediate use.
- No programming required for operation.
- Functions similarly to the original remote control.
- Requires 2 x 1.5V AAA batteries (not included).



Figure 1: Front view of the RC-QW33 Replacement Remote Control.

2. Setup

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with this product. Always use new batteries and dispose of old batteries responsibly.



Figure 2: Battery compartment located on the back of the remote control.

3. Operating Instructions

This remote control is designed to replicate the functions of your original JVC RC-QW33 HI-FI remote. Point the remote control directly at your JVC HI-FI system for optimal performance.

3.1 Basic Functions

- **POWER Button (Red):** Turns the HI-FI system on or off.
- **MUTE Button:** Temporarily silences the audio output. Press again to restore sound.
- **Volume Up/Down (V+/V-):** Adjusts the audio volume level.
- **Channel Up/Down (P+/P-):** Navigates through radio presets or tracks.
- **Number Buttons (0-9):** Used for direct input of track numbers, radio frequencies, or other numerical selections.

3.2 Source Selection and Navigation

- **TV, SAT, DVD, AUX Buttons:** Selects the corresponding input source on your HI-FI system.
- **MENU Button:** Accesses the system's main menu.
- **OK Button:** Confirms selections within menus.
- **Directional Arrows (Up, Down, Left, Right):** Navigates through menu options.
- **EXIT Button:** Exits the current menu or function.
- **SOURCE Button:** Cycles through available input sources.



Figure 3: Top section of the remote control with common function buttons.

4. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote control to direct sunlight, extreme temperatures, or high humidity.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA 1.5V batteries, ensuring correct polarity.
Remote control range is poor.	Weak batteries or obstruction between remote and HI-FI system.	Replace batteries. Ensure a clear line of sight to the HI-FI system's sensor.
Certain buttons do not respond.	Button malfunction or system not in correct mode.	Ensure the HI-FI system is in the correct input mode (e.g., DVD for DVD functions). If problem persists, contact support.
Remote control LED indicator does not light up.	No power from batteries.	Check battery installation and replace batteries if necessary.

6. Specifications

Brand	Passion-Electro
Model Number	RC-QW33
Color	Black
Compatible With	JVC HI-FI systems (original remote RC-QW33)
Battery Type	2 x AAA 1.5V (not included)
Maximum Range	10 Meters
Manufacturer	Passion-Electro
Country of Origin	China

7. Warranty and Support

Information regarding specific warranty terms for this product is not available in the provided details. For any issues or support inquiries, please refer to the retailer or manufacturer's customer service channels where the product was purchased.

Please retain your purchase receipt as proof of purchase for any warranty claims or support requests.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GBDTCY5

More documents and user manuals: **https://manuals.plus/**